



Workshop Manual

500 & 650

Unit Construction Twins

1966, 1967, and 1968 Models

Revised Edition 00-4123



WORKSHOP MANUAL
FOR 500cc AND 650cc TWINS

MODELS

A65 LIGHTNING

A65 THUNDERBOLT

A65 SPITFIRE Mk.II SPECIAL & Mk.IV SPECIAL

A65 HORNET (1966)

A65 FIREBIRD SCRAMBLER (1967-68)

A50 ROYAL STAR

A50 WASP

Service Department

B.S.A. MOTOR CYCLES LTD.


BIRMINGHAM 11

Telephone 021-772-2381


ARMOURY ROAD

00-4123-May-68


Printed in England at B.S.A. Press




BSA 650 c.c. LIGHTNING 1966




BSA 650 c.c. LIGHTNING 1967




BSA 650 c.c. LIGHTNING 1968




BSA 650 c.c. THUNDERBOLT 1966




BSA 650 c.c. THUNDERBOLT 1967




BSA 650 c.c. THUNDERBOLT 1968




BSA 650 c.c. SPITFIRE Mk. II SPECIAL 1966




BSA 650 c.c. SPITFIRE MK. III SPECIAL



BSA 650 c.c. SPITFIRE Mk. IV SPECIAL




BSA 650 c.c. HORNET 1966-67




BSA

650 c.c. FIREBIRD SCRAMBLER 1967




BSA


650 c.c. FIREBIRD SCRAMBLER 1968




BSA 500 c.c. ROYAL STAR 1966



BSA 500 c.c. ROYAL STAR 1967



BSA 500 c.c. ROYAL STAR 1968



BSA 500 c.c. WASP 1966

INTRODUCTION

This manual has been compiled to provide comprehensive service information for the B.S.A. owner and for the workshop fitter wishing to carry out basic maintenance or major repair work. It is written in great detail, nevertheless, because of the specialised skills or equipment required to carry out some of the repair work described, the inexperienced owner is strongly advised to consult his B.S.A. dealer whenever he is in doubt as to his own ability to carry out a satisfactory job.

All the information given in this manual is correct at the time of publication but, since in the course of the constant development of B.S.A. motor-cycles changes in specifications are inevitable, anyone finding the information given in this book to be at variance with the machine in his possession is advised to contact the Service Department. In such cases we will provide up-to-date information.

The manual is sub-divided into sections dealing with major assemblies and these are again broken down into the individual operations required for maintenance or repair. It is hoped that by this arrangement the manual will be useful as a quick work of reference even to the skilled mechanic.

ENGINE AND FRAME NUMBERS

The engine number is stamped on the left-hand side of the crankcase immediately below the cylinder base.

The frame number is stamped on the left-hand side of the frame steering head lug just forward and below the petrol tank, or on later models, on the front engine mounting lug.

Both the engine and frame numbers, together with prefix and suffix letters must be quoted in full in any correspondence relating to the machine or any enquiry regarding this manual, to either the dealer or the Service Department.

FACTORY SERVICE ARRANGEMENTS

(UNITED KINGDOM)

REPLACEMENT PARTS

B.S.A. replacement parts and exchange units are distributed through a national network of B.S.A. dealers, each of whom holds a stock of fast moving parts. Approximately 200 of these dealers have been selected for appointment as specialist B.S.A. replacement part stockists and each of these stockists holds a comprehensive stock of B.S.A. replacements. Lists of appointed stockists are available on request, and their names are printed in every B.S.A. Parts Catalogue.

GUARANTEE CLAIMS

In the interests of all concerned it is best that any owner of a new motor-cycle wishing to claim assistance under the guarantee should do so through the dealer from whom his machine was purchased. All B.S.A. dealers are familiar with the procedure designed by B.S.A. to give quick service to any owner of a B.S.A. motor-cycle who may find himself in difficulty.

REPAIRS

Most appointed B.S.A. dealers are able to carry out even major repair work, and owners are asked to make all repair arrangements through their chosen dealer.

In the great majority of cases local repair will be possible and this will avoid the expense, inconvenience and the possibility of the machine being damaged in transit to or from the works for repair.

Should your B.S.A. dealer decide that Service Department attention is required he will know best how to make suitable arrangements with the factory. It is important to remember that no machine can be accepted at the works without a prior appointment. This appointment can be made either by letter or by telephone.

Labour time will be greatly reduced if proprietary articles such as legshields, safety bars, carriers or fibre-glass fairings are removed before handing the machine over for repair. Accessories such as mirrors or badges should always be removed before entrusting a machine to an independent carrier.

TECHNICAL ADVICE

B.S.A. Service Department staff have long experience in dealing with technical problems of all kinds and will be pleased to help in the event of difficulty. The correct address of the Service Department is as follows:—

B.S.A. MOTOR CYCLES LIMITED,
SERVICE DEPARTMENT,
ARMOURY ROAD,
BIRMINGHAM 11.

Telephone No. 021-772-2381

**In all communications the full engine and frame numbers with all
prefix or suffix letters and figures must be quoted.**

SERVICE ARRANGEMENTS OVERSEAS

In most markets of the world B.S.A. has an appointed distributor to whom all service enquires should be addressed.

The names of these distributors appear in all B.S.A. Replacement Part Catalogues and they are repeated in a supplement to this manual when it is supplied overseas.

PROPRIETARY PARTS

Equipment not of our manufacture which is fitted to our motor-cycles is of the highest quality and is guaranteed by the manufacturers and not by us. Any complaints or repairs should be sent to the manufacturer concerned or their accredited agents who will give every possible assistance. The following are the manufacturers concerned:—

CARBURETTERS	Amal Limited, Holdford Road, Witton, BIRMINGHAM 6.
CHAINS	Renold Chains Limited, Wythenshawe, MANCHESTER.
ELECTRICAL EQUIPMENT	Joseph Lucas Limited, Gt. Hampton Street, BIRMINGHAM 18.
REAR DAMPERS	Girling Limited, Birmingham Road, WEST BROMWICH, Staffs.
SPARK PLUGS	Champion Sparking Plug Company Limited, Feltham, MIDDLESEX.
SPEEDOMETERS	Smith's Motor Accessories Limited, Cricklewood Works, LONDON N.W.2.
TYRES	Dunlop Company Limited, Fort Dunlop, BIRMINGHAM 24.

U.S.A. SERVICE ARRANGEMENTS

REPLACEMENT PARTS

B.S.A. replacement parts are available through a national network of B.S.A. dealers covering the entire United States.

These B.S.A. motor-cycle dealers are listed under "Motorcycles" in the yellow pages of your local telephone directory.

All requests for parts must be made through franchised B.S.A. dealers, they are not sold direct to B.S.A. owners by the two factory branches.

GUARANTEE CLAIMS

In the interest of all concerned the owner of a new motor-cycle wishing to claim assistance under the guarantee must do so through the dealer from whom his machine was purchased.

REPAIRS

B.S.A. dealers are capable of servicing and repairing B.S.A. motor-cycles, ask you dealer to help when repairs are needed.

Labour time will be greatly reduced if proprietary articles, such as legshields, crash bars, carriers or fibre-glass fairings, are removed before handing the machine over for repair. Accessories such as mirrors or badges should always be removed before entrusting a machine to an independent carrier.

TECHNICAL ADVICE

The B.S.A. Service Department staff at the two U.S.A. factory branches have long experience in dealing with technical questions of all kinds and will be pleased to help in the event of difficulty.

The factory branch addresses are shown below:—

EASTERN: B.S.A. INCORPORATED.
639 Passaic Avenue,
Nutley, New Jersey 07110.

WESTERN: B.S.A. MOTORCYCLES -- WESTERN.
2745 E. Huntington Drive,
Duarte,
CALIFORNIA 91010.

In all communications the full engine and frame numbers with all prefix and suffix letters and figures must be quoted as well as the year and model of the motor-cycle in question.

OVERSEAS DISTRIBUTORS — REMOVING THE MOTOR-CYCLE FROM THE CASE

NOTE:—Check that the packing case is RIGHT SIDE UP before dismantling. The TOP has stencilled markings on it, the bottom does not.

1. Prise off the top boards with a suitable pinch bar.
2. Take out the top packing and loose parts from around the motor-cycle.
3. Remove one side of the case and take out the motor-cycle and any remaining loose parts. Check that you have all the small parts before discarding the wrappings. Retain the TEST CARD in case you find it necessary to report any loss of parts or damage during transit.
4. The ignition keys and steering lock keys will be found in the tool roll.

INSTALLING THE FORKS (except U.S.A. West Coast)

1. Put the machine on the centre stand and place a suitable support under the engine.
2. Check that both cups in the steering head are seated correctly in the frame. If they are at an angle, tap lightly with a mallet until they seat properly.
3. Wipe out all the old grease from the cups in the frame and the cone on the fork stem. Clean the fork legs making sure there is no excisor or dirt inside the fork shafts.
4. Fill the cups in the steering head with fresh grease.
5. Clean the ball bearings (which are found in the bag of small parts), by rolling them in a clean rag. There should be 20 balls for each steering head cup. Press them firmly down into the grease.
6. Insert the front fork stem into the frame steering head, being careful not to disturb the ball bearings.
7. Assemble the top bearing cone, painted dust cap and steering stem adjusting sleeve on to the front fork stem.
8. Tighten the steering stem adjusting sleeve until slight "drag" is felt as the front fork assembly is turned from side to side.
9. Fit the fork top yoke into position and tighten the pinch bolt. Screw on the adjusting sleeve dust cap.
10. Fill each fork leg with approximately $\frac{1}{3}$ pint of correct grade oil (see page A.3 and A.4) and fit fork tube washers, cable guides and nuts. NOTE:—The front fork assembly is installed before transit on West Coast models.

INSTALLING THE STEERING DAMPER ASSEMBLY

1. Slip the small spring washer on to the damper rod and insert the rod into the hole in the chrome cover nut.
2. Place the large fibre washer, anchor plate, and star washer on to the end of the damper rod in that order, and secure with the special nut.
3. Attach the anchor plate to its fixing point on the frame, placing the thick washer between the frame cross piece and the bracket.

INSTALLING THE FRONT FENDER AND WHEEL

1. Place the front fender between the forks, and fit the braces.
2. Pull out the wheel spindle from the fork ends and fit the front wheel. Insert the spindle from the left-hand side and use a suitable bar to screw the spindle right home. It has a left-hand thread.
3. Tighten the pinch bolts in the fork ends and secure the brake anchor strap with fender braces.
4. The support can now be removed from under the engine.

INSTALLING THE HANDLEBAR — ATTACHING THE CABLES

1. Place the handlebar in position fit the handlebar clips and after adjusting for suitable position, secure with the four fixing bolts.
2. Feed cables through the appropriate guide on top of the fork legs.
3. Re-position all control levers.
4. Attach the clutch, front brake and air control cables to their respective levers. The front brake cable will be found among the loose parts.
5. Attach the throttle control complete with cable(s) and tighten the fixing screws.

INSTALLING THE TACHOMETER (when fitted) AND SPEEDOMETER

1. Secure the instrument plate to the top yoke with two bolts and washers, and connect drive cable(s) to instrument head(s).
2. To connect the instrument head lighting wires it will be necessary to first remove the headlamp front (secured by one screw at top).
3. Pass the wires through the base of the headlamp and connect each wire with appropriate connector.
4. Replace the headlamp front and check for correct illumination of instrument dials.

FITTING THE SEAT

Hook the front of the seat on to the frame member and secure at the rear with two bolts, washers and distance pieces which enter from below and on each side of the sub-frame.

INSTALLING THE KICKSTAND AND FOOT PEGS

1. Fix the stand leg to the frame lug with the nut and bolt, and connect the spring.
2. Mount each foot peg on to its stud and adjust to desired height before tightening the fixing nuts. Check, by "sighting" from the rear of the machine, that each foot peg is mounted at the same height.

SPARK PLUG, TYRE PUMP, TOOLS

1. Take out and discard the plastic plugs from the spark plug holes, fit the spark plugs and attach the plug lead connectors. The plugs supplied with the machine are best suited to all round operating conditions and should not be changed without the advice of a plug specialist.
2. Snap the tyre pump into its mount under the seat on the right-hand side of the frame.
3. The tools, instruction manual and other literature can now be placed in the toolbox.

BATTERY

Batteries are supplied in dry charged condition. Do not fill unless it is known that the machine is to be sold within a few days.

To Fill and Charge the Battery

All plates in this battery have been charged fully and dried completely by special process. The tape across the vent holes prevents the ingress of moisture or air and insures perfect condition of the plates during transportation and storage. This tape must only be removed immediately before the battery is brought into service. Dilute sulphuric solution S.G. 1.260 can be prepared by slowly pouring 1 part of concentrated sulphuric acid into 3 parts of distilled water (by volume) or of S.G. 1.210 by adding 1 part of concentrated sulphuric acid to 4 parts of distilled water (by volume).

A glass, earthenware or lead vessel should be used and the mixture well stirred. Allow to cool to the temperature of the surrounding atmosphere before using.

IMPORTANT:— On dry charged batteries the filling of each cell with acid must be completed in one operation and levels restored after standing by syphoning off excess acid.

FILL EACH CELL WITH PURE DILUTE SULPHURIC ACID TO $\frac{1}{8}$ INCH ABOVE PLATE PACK AT ONE OPERATION. The temperature of the acid and battery should be between 60°F. and 80°F. (see below).

	TEMPERATE Climates ordinarily below 80°F. (27°C.) shade temperature	TROPICAL Climates frequently above 80°F. (27°C.) shade temperature
Specific gravity for filling new cells	1.260 (at 60°F.)	1.210 (at 60°F.)
Specific gravity at completion of charge to be adjusted if necessary, to be between	1.270 and 1.290 (at 60°F.)	1.210 and 1.230 (at 60°F.)

1. Batteries which have been stored at lower temperature than 60°F. should have their temperatures raised before filling by allowing the battery to stand in a warm room until it attains room temperature.
2. AFTER FILLING AND STANDING FOR 1 HOUR OR MORE SYPHON OFF AND DISCARD ANY ACID FROM ANY CELL WHERE IT HAS RISEN HIGHER THAN THE PLATE PACK TO BRING IT BACK TO PLATE PACK LEVEL.
3. Batteries used under these conditions are up to 90% charged, but if time permits a freshening charge of 4 hours at the normal re-charge rate would be beneficial. If the acid level rises after this freshening charge restore levels as directed in paragraph (2).

NOTE:—Re-charge rate 0.8 ampere.

Keep acid just level with plate pack by adding distilled water only.

FINAL CHECK

It is the duty of the dealer to see that every nut, bolt and screw is tight and correctly installed before the motor-cycle leaves his shop. You will be responsible if the customer returns and complains of rattles, missing nuts or fractures caused by vibration. It should be noted that 90% of all vibration problems can be traced to loose engine mountings. Do not take it for granted that the factory has done everything right. **Check everything yourself.**

STARTING THE MOTOR-CYCLE

Fill the oil tank, primary drive and gearbox with correct grades of oil (see pages A.3 and A.4).

Before starting the engine, make sure that there is no packing material in or around the carburetter air intake(s).

While the engine is running take off the oil tank filler cap and check that the oil is circulating correctly through the return pipe. After replacing the oil tank cap the machine will be complete and ready for use.

CONTENTS

	<i>Section</i>	<i>Page</i>
GENERAL DATA	GD	.. 1 to 31
LUBRICATION	A	.. 1 to 15
ENGINE	B	.. 1 to 53
CARBURETTER AND CARBURATION	C	.. 1 to 21
FRAME AND FITTINGS	D	.. 1 to 15
FRONT FORKS	E	.. 1 to 11
WHEELS, BRAKES AND TYRES	F	.. 1 to 19
ELECTRICAL EQUIPMENT	G	.. 1 to 28
SERVICE TOOLS	H	.. 1 to 8

INDEX

U.S.A. MODELS

A65 Lightning (650 c.c.):

Page

Pistons, Piston Rings, Gudgeon Pins, Small-end Bushes, Connecting Rods ..	GD.2
Crankshaft, Oil Pump, Valves, Guides	GD.3
Springs, Valve Timing, Timing Gear, Tapper Clearances, Ignition Timing ..	GD.4
Camshaft, Camshaft Bushes, Barrel, Tappets, Cylinder Head, Inlet Balance Pipe	GD.5
Carburettors, Clutch	GD.6
Sprockets, Primary Chain, Gearbox and Gear Detail	GD.7
Gearbox Bearings, Kickstart Ratchet, Selector, Quadrant, etc., Steering Head	GD.8
Swinging Arm, Rear Dampers, Front Forks, Bushes	GD.9
Wheels, Brakes, Tyres	GD.10-11
Electrical Equipment, Spark Plugs	GD.11
Capacities, Dimensions, Weights	GD.12
A65 Thunderbolt (650 c.c.)	GD.13
A65 Hornet (650 c.c.) 1966/7 and Firebird Scrambler 1968	GD.14-15
A65 Spitfire Mk. II Special (650 c.c.)	GD.16-17
A50 Wasp (500 c.c.)	GD.18-19
A50 Royal Star (500 c.c.)	GD.20-21

HOME AND STANDARD EXPORT MODELS

A65 Lightning (650 c.c.)	GD.22
A65 Thunderbolt (650 c.c.)	GD.23
A65 Hornet (650 c.c.) 1966/7 and Firebird Scrambler 1968	GD.24
A65 Spitfire Mk. II Special (650 c.c.)	GD.25
A50 Wasp (500 c.c.)	GD.26
A50 Royal Star (500 c.c.)	GD.27
Speedometer Gears	GD.28
Gearbox Ratios	GD.28
Finding the Ratio	GD.29
Piston Displacement and Crankshaft Degrees	GD.30
Torque Wrench Setting	GD.31

MODEL A65 LIGHTNING (650 c.c.)

PISTON

Material	"Lo-Ex" Aluminium alloy
Compression ratio	9.0 : 1
Clearance—bottom of skirt0032"—.0035" (.0813—.0889 mm.)
Clearance—top of skirt0062"—.0065" (.1575—.1651 mm.)
<i>(both measured on major axis).</i>	
Gudgeon pin hole diameter750"—.7502" (19.05—19.055 mm.)

PISTON RINGS

Material	Cast-iron
Compression ring—lower ring is tapered to same dimensions:	
Width0615"—.0625" (1.5621—1.5875 mm.)
Thickness114"—.121" (2.9972—3.0734 mm.)
Clearance in groove001"—.003" (.0254—.0762 mm.)
Fitted gap008"—.013" (.2032—.3302 mm.)
Oil control ring:	
Width124"—.125" (3.1496—3.175 mm.)
Thickness114"—.121" (2.9972—3.0734 mm.)
Clearance in groove001"—.003" (.0254—.0762 mm.)
Fitted gap008"—.013" (.2032—.3302 mm.)

GUDGEON PIN

Material	Nickel-chrome high tensile steel
Diameter750"—.7502" (19.05—19.055 mm.)
Length	2.368"—2.373" (60.147—60.275 mm.)

SMALL-END BUSH

Material	Phosphor bronze
Outside diameter (before fitting)8775"—.8785" (22.2885—22.3139 mm.)
Length940"—.950" (23.876—24.130 mm.)
Finished bore (fitted)7503"—.7506" (19.0576—19.0652 mm.)
Interference fit in rod002"—.004" (.0508—.1016 mm.)

CONNECTING RODS

Length between centres	6.0" (152.394 mm.)
Big-end bearing type	Vandervell VP.D2
Rod side clearance024" (.6049 mm.)
Bearing diametrical clearance001"—.0025" (.0254—.0635 mm.)
Small-end bore diameter8745"—.8755" (22.212—22.237 mm.)

CRANKSHAFT

Type	One-piece forged, two-throw crank with bolt-on flywheel.
Main bearing (drive-side)	Hoffman RM.111L (roller)
Journal diameter	1.125" (28.574 mm.)
Outer diameter	2.812" (71.435 mm.)
Width812" (20.637 mm.)
Main bush (gear-side):						
Inner diameter	1.5000"—1.5005" (38.10—38.113 mm.)
Outer diameter	1.6245"—1.6255" (41.262—41.288 mm.)
Width940"—.960" (23.876—24.384 mm.)
Crankpin diameter	1.6865"—1.687" (42.837—42.849 mm.)
Minimum regrind	-.010" (.254 mm.)
Second regrind	-.020" (.508 mm.)
Third regrind	-.030" (.762 mm.)
Gear-side journal regrind (two only)	-.010" (.254 mm.)
						-.020" (.508 mm.)
Crankshaft end-float0015"—.003" (.038—.076 mm.)
Crank throw	1.4567" (37.00 mm.)

OIL PUMP

Pump body material	Zinc-base alloy
Pump type	Double gear
Pump drive ratio	1 : 3
Pump non-return valve spring free length8125" (20.637 mm.)
Pump non-return valve ball, size	1/4" (6.35 mm.)
Oil pressure relief valve spring free length609" (15.478 mm.)
Oil pressure relief valve ball size	5/16" (7.937 mm.)
Blow-off pressure	50 lbs. per square inch

VALVES

Seat angle (inclusive)	90
Head diameter:					
Inlet	1.595"—1.60" (40.513—40.64 mm.)
Exhaust	1.407"—1.412" (35.737—35.864 mm.)
Stem diameter:					
Inlet3095"—.310" (7.861—7.874 mm.)
Exhaust309"—.3095" (7.848—7.861 mm.)

VALVE GUIDES

Material	Cast-iron (high grade)
Bore diameter, inlet and exhaust312"—.313" (7.9248—7.950 mm.)
Outside diameter, inlet and exhaust5005"—.501" (12.7127—12.7254 mm.)
Length, inlet and exhaust	1.96"—1.97" (49.784—50.038 mm.)

VALVE SPRINGS

Free length, inner	1 $\frac{5}{8}$ "	(41.275 mm.)
					*1 $\frac{7}{16}$ "	*(36.512 mm.)
Fitted length, inner	1.3"	(33.02 mm.)
Free length, outer	2 $\frac{1}{32}$ "	(51.5937 mm.)
					*1 $\frac{3}{4}$ "	*(44.45 mm.)
Fitted length, outer	1.37"	(34.798 mm.)

VALVE TIMING (Sports Camshaft)

Tappets set to .015" (.381 mm.) for checking purposes only:

Inlet opens	51	B.T.D.C.
Inlet closes	68	A.B.D.C.
Exhaust opens	78	B.B.D.C.
Exhaust closes	37	A.T.D.C.

TIMING GEAR

Crankshaft pinion:

Number of teeth	22	
Fit on shaft	-.0005" — .0005"	(.0127 mm.)

Camshaft pinion:

Number of teeth	44	
Interference fit0000" — .001"	(.0254 mm.)

Idler pinion:

Number of teeth	44	
Idler pinion spindle dimensions (both ends)6860" — .6865"	(17.4371 mm.)
Idler pinion bush dimensions (both), inside6885" — .6875"	(17.4625 mm.)
Idler pinion bush dimensions (both), outside8775" — .8785"	(22.3012 mm.)
Spindle working clearance0005" — .002"	(.0127 — .0508 mm.)

TAPPET CLEARANCE (Cold)

Inlet008"	(.2032 mm.)
Exhaust010"	(.254 mm.)

IGNITION TIMING (Standard Ignition System)

Piston position (B.T.D.C.) full advanced304"	(7.216 mm.)
Crankshaft position (B.T.D.C.) full advanced	34°	
Contact breaker gap setting015"	(.381 mm.)

*Figures for 1968 models onwards.

CAMSHAFT

Journal diameter, left810"—.8105"	(20.574—20.586 mm.)
Journal diameter, right8735"—.874"	(22.188—22.2 mm.)
End float	Nil (spring-loaded)	
Cam lift306"	(7.772 mm.)
Base circle diameter812"	(20.624 mm.)

CAMSHAFT BEARING BUSHES

Bore diameter, fitted (left-hand)8115"—.8125"	(20.612—20.637 mm.)
Outside diameter (left-hand)906"—.907"	(23.012—23.037 mm.)
Interference fit in case (left-hand)002"—.004"	(.0508—.1016 mm.)
Bore diameter, fitted (right-hand)875"—.876"	(22.225—22.25 mm.)
Outside diameter (right-hand)	1.065"—1.066"	(27.051—27.076 mm.)
Interference fit in case (right-hand)002"—.004"	(.0508—.1016 mm.)
Material	"Clevite 10" and Bronze	

CYLINDER BARREL

Material	Cast-iron (close grained)	
Bore size (standard)	2.9521"—2.9530"	(74.983—75.0062 mm.)
Maximum oversize	2.9921"—2.9930"	(75.999—76.022 mm.)
Tappet bore size3745"—.375"	(9.5123—9.525 mm.)
Stroke	74 mm.	

TAPPETS

Material	20 Carbon Steel body (Stellite tipped)	
Tip radius	1.250"	(31.75 mm.)
Tappet diameter3735"—.375"	(9.488—9.5 mm.)
Clearance in barrel0005—.0015"	(.0127—.0381 mm.)

CYLINDER HEAD

Material	DTD.424 Aluminium alloy (B.S.)	
Inlet port size	1½"	(38.1 mm.)
Exhaust port size	1⅞"	(33.337 mm.)
Valve seatings	Cast-iron (cast-in)	

INLET BALANCE PIPE

Length	4"	(101.6 mm.)
Bore diameter	7/32"	(5.56 mm.)

CARBURETTERS (Standard)

Type	Amal 389/228 (right-hand float chamber)	
	Amal 689/228 (left-hand float chamber)	
Main jet	270	
Pilot jet	25	
Needle jet size106"	(2.6924 mm.)
Needle position	3	
Throttle valve	389/3 (right-hand)	689/3 (left-hand)
Nominal choke size	1-5/32"	(29.46 mm.)
Air cleaner type	Dry surgical gauze	
Throttle slide return spring (free length) ..	2½"	(63.5 mm.)
Air slide return spring (free length) ..	3"	(76.2 mm.)

CARBURETTER (Concentric) 1968 A65 LIGHTNING

Type	Amal R.930/21 (right-hand concentric)	
	Amal L.930/22 (left-hand concentric)	
Main jet	190	
Pilot jet	20	
Needle jet size106"	(2.6924 mm.)
Needle position	2	
Throttle valve	2½	
Nominal choke size	30 mm.	
Air cleaner type	Dry surgical gauze	
Throttle slide return spring	3" (free length)	(76.2 mm.)
Air slide return spring	2¾" (free length)	(69.8 mm.)

CLUTCH

Type	Multi-plate with built-in cush drive	
Number of plates:		
Driving (bonded)	6	
Driven (plain)	6	
Driving plate segments:		
Number	288	
Overall thickness140"—.145"	(3.556—3.683 mm.)
Clutch springs	3	
Free length	1-13/16"	(46.03 mm.)
Working coils	9½	
Spring rate	113 lbs. per inch	
Clutch sprocket:		
Number of teeth	58	
Bore diameter	1.8745"—1.8755"	(47.612—47.638 mm.)
Clutch hub bearing diameter	1.3733"—1.3743"	(34.882—34.907 mm.)
Clutch roller diameter (20)2495"—.250"	(6.337—6.35 mm.)
Clutch roller length231"—.236"	(5.8674—5.994 mm.)

SPROCKETS

					(Number of teeth)
Engine sprocket	28
Clutch sprocket	58
Final drive sprocket	20 solo (17 sidecar)

PRIMARY CHAIN

..	$\frac{3}{8}$ " triple roller (80 links)
----	----	----	----	----	--

CLUTCH OPERATING ROD

Length	$11\frac{1}{16}$ "	(280.987 mm.)
Diameter	$7/32$ "	(5.5562 mm.)

GEARBOX

					Top	3rd	2nd	1st
Internal ratios (standard)	1—1	1.144—1	1.60—1	2.51—1
Overall ratios (standard)	4.87—1	5.57—1	7.79—1	12.23—1

(see page GD.28 for alternative ratios).

GEAR DETAIL

MAINSHAFT TOP GEAR:

Bush diameter (fitted)813"—.814"	(20.6502—20.6756 mm.)
Bush length	$3\frac{1}{8}$ "	(79.375 mm.)
Bush protrusion	$31/64$ "	(12.3031 mm.)
Working clearance0027"—.0042"	(.0685—.1066 mm.)

LAYSHAFT FIRST GEAR:

Bush diameter (fitted)7495"—.7505"	(19.0273—19.0627 mm.)
Working clearance0005"—.001"	(.0127—.0254 mm.)

GEARBOX SHAFTS:

Mainshaft left-hand end diameter8098"—.8103"	(20.568—20.581 mm.)
Mainshaft right-hand end diameter7495"—.7499"	(19.047—19.057 mm.)
Length	$10\frac{5}{8}$ "	(269.875 mm.)
Layshaft left-hand end diameter7495"—.750"	(19.057—19.05 mm.)
Layshaft right-hand end diameter7495"—.750"	(19.057—19.05 mm.)
Length	$6-11/16$ "	(169.862 mm.)

GEARBOX BEARINGS

Mainshaft top gear bearing	2½" × 1¼" × ⅝" ball journal
Mainshaft bearing right side	¾" × 1⅞" × ⅜" ball journal
Layshaft bearing left side	1" × ¾" × ¾" needle roller
Layshaft bearing right side	1" × ¾" × ¾" needle roller

KICKSTART RATCHET

Pinion bore diameter937"—.938"	(23.799—23.825 mm.)
Bush (outside diameter)933"—.935"	(23.698—23.749 mm.)
Bush (inside diameter)750"—.751"	(19.05—19.0754 mm.)
Outer working clearance002"—.005"	(.0508—.127 mm.)
Inner working clearance0001"—.0015"	(.00254—.0381 mm.)
Ratchet spring free length	½"	(12.70 mm.)

GEAR SELECTOR QUADRANT

Plunger diameter3352"—.3362"	(8.514—8.539 mm.)
Housing diameter3427"—.3437"	(8.7045—8.729 mm.)
Working clearance0065"—.0085"	(.1651—.2159 mm.)

CAM-PLATE PLUNGER

Plunger diameter4355"—.4365"	(11.0617—11.0871 mm.)
Housing diameter437"—.4375"	(11.0998—11.1125 mm.)
Working clearance0005"—.002"	(.0127—.0508 mm.)
Spring free length	2¼"	(57.15 mm.)

FRAME AND FITTINGS

STEERING HEAD

Number of steel balls	40	
Diameter of balls	¼"	(6.35 mm.)

SWINGING ARM

Bush type	Bonded rubber	
Bush diameter	1.250"—1.253"	(31.75—31.826 mm.)
Housing diameter	1.247"—1.248"	(31.673—31.699 mm.)
Interference fit003"—.005"	(.0762—.127 mm.)
Spindle diameter810"—.811"	(20.57—20.595 mm.)

REAR SHOCK ABSORBERS

Type	Coil-spring hydraulically damped	
Springs:							
Fitted length (solo)	9.4"	(238.76 mm.)
Fitted length (sidecar)	9.4"	(238.76 mm.)
Spring rate (solo)	90 lb. per inch	
Spring rate (sidecar)	110 lb. per inch	
Colour identification (solo)	Green/white	
Colour identification (sidecar)	Red/white	

FRONT FORKS

Type	Coil-spring hydraulically damped	
Springs:							
Free length (solo)	10"	(254 mm.)
Free length (sidecar)	10½"	(266.7 mm.)
Spring rate (solo)	32½ lb. per inch	
Spring rate (sidecar)	40 lb. per inch	
Number of coils (solo)	21 (19½ working)	
Number of coils (sidecar)	19 (17½ working)	
Colour code (solo)	Yellow/green	
Colour code (sidecar)	Blue/white	

BUSHES

Material	Sintered bronze	
Outer diameter (top)	1.475"—1.4755"	(37.465—37.477 mm.)
Outer diameter (bottom)	1.473"—1.474"	(37.414—37.439 mm.)
Inner diameter (top)	1.25"—1.251"	(31.75—31.775 mm.)
Inner diameter (bottom)	1.2485"—1.2495"	(31.711—31.737 mm.)
Working clearance (top)0005"—.0015"	(.0127—.0381 mm.)
Working clearance (bottom)001"—.004"	(.0254—.1016 mm.)
Length (top)	2½"	(53.975 mm.)
Length (bottom)	1¼"	(31.75 mm.)
Shaft diameter	1.248"—1.249"	(31.699—31.7246 mm.)
Sliding tube bore diameter	1.477"—1.475"	(37.515—37.465 mm.)

WHEELS, BRAKES AND TYRES

WHEELS

Rim size and type, front	WM2-19
Rim size and type, rear	WM3-19 (East Coast)
				WM13-18 (West Coast)
Spoke sizes:				
Front, short (20)	10 s.w.g. \times 5-15/16"
Front, long (20)	10 s.w.g. \times 8 7/8"
<i>East Coast:</i>				
Rear, right-hand (20)	10 s.w.g. \times 7-29/32"
Rear, left-hand (20)	10 s.w.g. \times 7-27/32"
<i>West Coast:</i>				
Rear, right-hand (20)	10 s.w.g. \times 7-7/16"
Rear, left-hand (20)	10 s.w.g. \times 7 3/8"
*Front, right-hand (20)	8/10 s.w.g. \times 4-11/16"
*Front, left-hand (20)	8/10 s.w.g. \times 5 5/8"

WHEEL BEARINGS (4)

Type (left-hand and right-hand)	Hoffman LS.90R (front) — RS (rear)
Size, front and rear wheels (left-hand and right-hand)	7/8" \times 2" \times 9/16"
Spindle diameter, front nearside6855"—.6860" (17.418—17.424 mm.)
Spindle diameter, front offside8740"—.8745" (22.199—22.212 mm.)
Spindle diameter, rear685"—.686" (17.399—17.424 mm.)

REAR WHEEL SPROCKET

Number of teeth	47
Chain size (solo)	5/8" \times 3/8" \times 106L
Chain size (sidecar)	5/8" \times 3/8" \times 103L

BRAKES (Floating Shoes)

Diameter (front)	8"	(203.2 mm.)
Diameter (rear)	7"	(177.8 mm.)
Width (front)	1 5/8"	(41.275 mm.)
Width (rear)	1 1/8"	(28.575 mm.)
Lining thickness (front)	3/16"	(4.702 mm.)
Lining thickness (rear)	3/16"	(4.702 mm.)
Lining area sq. in. (sq. cm.):					
Front shoes	27.2	(175.44)
Rear shoes	16.5	(106.425)

*Figures for 1968 models onwards.

***FRONT BRAKE (Twin-leading Shoe 1968)**

Diameter	8"	(203.2 mm.)
Width	1 $\frac{5}{8}$ "	(41.275 mm.)
Lining thickness	$\frac{3}{16}$ "	(4.702 mm.)
Lining area, sq. in. (sq. cm.)	12.06	(000.000)

TYRES

Size, front	3.25" x 19"	(82.55 x 482.6 mm.)
Size, rear (East Coast)	3.50" x 19"	(88.9 x 482.6 mm.)
Size, rear (West Coast)	4.00" x 18"	(101.6 x 457.2 mm.)
Pressure, front	18 lbs. per sq. in.	(1.221 atm)
Pressures, rear	20 lbs. per sq. in.	(1.36 atm)

ELECTRICAL EQUIPMENT (12 volt)

Alternator, type	Lucas RM.19	
Zener Diode	Lucas ZD.715	
Rectifier	Lucas 2DS.506	
Coils (2)	Lucas MA.12	
Contact breaker	Lucas 4CA	*54041023
Battery (12 volt)	Lucas PUZ5A	
Battery, 6 volt (2), alternative	Lucas MKZ9E	
Battery capacity, 6 volt (2)	8 amp./hour each	
Horn	6H 12 volt	
Bulbs:						<i>Number</i>	<i>Type</i>
Headlight	Lucas 446	50 40 watt
Parking light	Lucas 989	6 watt
Stop/tail light	Lucas 380	21 6 watt
Speedometer light	Smiths	2.2 watt
*Headlight main beam indicator bulb	Lucas	2 watt

SPARK PLUGS

Type	Champion N.4	
Gap setting025"	(.635 mm.)
Thread size	14 mm. diameter	19 mm. reach

*Figures for 1968 models onwards.

CAPACITIES

Fuel tank	2 galls./2.4 U.S.	(9 litres)
Fuel tank (to order only)	4 galls./4.8 U.S.	(18 litres)
Oil tank	5 pints	(3 litres)
Gearbox	$\frac{7}{8}$ -pint	(490 c.c.)
Primary drive (approximate)	$\frac{1}{4}$ -pint	(140 c.c.)
Front forks (each leg)	$\frac{1}{3}$ -pint	(190 c.c.)

BASIC DIMENSIONS

Wheelbase	56"	(142.2 cm.)
Overall length	85 $\frac{1}{4}$ "	(216.5 cm.)
Overall width	30"	(76.2 cm.)
Overall height (Western handlebars)	44"	(111.8 cm.)
Overall height (standard handlebars)	40 $\frac{1}{2}$ "	(102.8 cm.)
Ground clearance (unladen)	8"	(20.3 cm.)

WEIGHTS

Machine unladen	391 lbs.
Engine/gearbox unit (less carburettors)	138 lbs.

MODEL A65 THUNDERBOLT (650 c.c.)

All general data is the same as data given for the A65 Lightning
(U.S.A.) model, except for the following:—

CARBURETTER

Type	Amal 389/234	
Main jet	310	
Pilot jet	25	
Needle jet size106"	(2.6924 mm.)
Needle position	3	
Throttle valve	389/3 1/2	
Nominal choke size	1 1/8"	(28.575 mm.)

CARBURETTER (Concentric) 1968 A65 THUNDERBOLT

Type	Amal R.928/2 (right-hand concentric)	
Main jet	230	
Pilot jet	20	
Needle jet size106"	(2.6924 mm.)
Needle position	1	
Throttle valve	3 1/2	
Nominal choke size	28 mm.	
Air cleaner type	Dry surgical gauze	

INLET MANIFOLD

Carburetter port size	1 1/8"	(28.575 mm.)
Cylinder head port size	1 1/16"	(26.987 mm.)

REAR WHEEL

.. .. .	As A65 Lightning (U.S.A.) model for the East Coast.
---------	--

MODEL A65 HORNET (650 c.c.) AND FIREBIRD SCRAMBLER (650 c.c.) 1968

All general data is the same as data given for the A65 Lightning
(U.S.A.) model, except for the following:—

*CARBURETTER (Concentric) 1968 FIREBIRD SCRAMBLER

Type	Amal R.930/24 (right-hand concentric) Amal L.930/25 (left-hand concentric)
Main jet	190
Pilot jet	25
Needle jet106" (2.6924 mm.)
Needle position	3
Throttle valve	2½
Nominal choke size	30 mm.
Air cleaner type	Dry surgical gauze

PISTON

Compression ratio	10.5 : 1	*10 : 1
Clearance, bottom of skirt0035"—.0038"	(.0889—.0965 mm.)
Clearance, top of skirt0065"—.0068"	(.1651—.1727 mm.)
<i>(both measured on major axis).</i>							

GEARBOX

<i>West Coast:</i>						<i>Top</i>	<i>3rd</i>	<i>2nd</i>	<i>1st</i>
Overall ratios (standard)	5.73—1	6.56—1	9.17—1	14.38—1
<i>(see page GD.28 for alternative ratios).</i>									
<i>East Coast</i>	As A65 Lightning (U.S.A.) model			

SPROCKETS

Final drive sprocket, East Coast	20 teeth
Final drive sprocket, West Coast	17 teeth

*Figures for 1968 models onwards

WHEELS

Rim size and type, front	WM3-19 (West Coast only)
Rim size and type, rear	WM3-18
Spoke sizes:				
Front, short (20)	10 s.w.g. \times 5-15/16"
Front, long (20)	10 s.w.g. \times 8 $\frac{7}{8}$ "
Rear, left-hand (20)	10 s.w.g. \times 7 $\frac{3}{8}$ "
Rear, right-hand (20)	10 s.w.g. \times 7 $\frac{1}{2}$ "
*Front, right-hand (20)	8/10 s.w.g. \times 4-11/16"
*Front left-hand (20)	8/10 s.w.g. \times 5 $\frac{5}{8}$ "

TYRES

Size:						
Front (East Coast)	3.50" \times 19"		(88.9 \times 482.6 mm.)
Front (West Coast)	4.00" \times 19"		(101.6 \times 482.6 mm.)
Rear	4.00" \times 18"		(101.6 \times 457.2 mm.)

REAR CHAIN

Chain size:						
East Coast	5/8" \times 3/8" \times 106L	
West Coast	5/8" \times 3/8" \times 105L	

ELECTRICAL EQUIPMENT (Energy Transfer Ignition)

Alternator type	Lucas RM.19ET
Coils	Lucas 3ET
Contact breaker	Lucas 4CA.ET
Condensers (capacitors)	Lucas 54441582

*ELECTRICAL EQUIPMENT (1968)

..	Same as 1968 Lightning (U.S.A.) model except provision is made for fitting a capacitor for competition purposes.
----	----	----	----	----	--

SPARK PLUGS

Type	Champion N.3
Gap setting025" (.635 mm.)
Thread size	14 mm. diameter \times 19 mm. reach

*Figures for 1968 models onwards.

**MODEL A65 SPITFIRE Mk. II SPECIAL (650 c.c.) 1966/7
AND MODEL A65 SPITFIRE Mk. IV SPECIAL (650 c.c.) 1968**

All general data is the same as data given for the A65 Lightning
(U.S.A.) model, except for the following:—

CARBURETTORS

Type	Amal 516/103GP (right-hand pilot air screw)
							Amal 516/120GP (left-hand pilot air screw)
Main jet	250
Pilot jet	25
Needle jet size109" (2.7686 mm.)
Needle position	3
Throttle valve	5
Nominal choke size	1-5/32" (29.36 mm.)
Air cleaner type	Not required

***CARBURETTORS (Concentric) 1968 A65 SPITFIRE Mk. IV**

Type	Amal R.932/1 (right-hand concentric)
							Amal L.932/2 (left-hand concentric)
Main jet	190
Pilot jet	20
Needle jet size	107
Needle position	2
Throttle valve	3
Nominal choke size	32 mm.
Air cleaner type	Dry surgical gauze

PISTON

Compression ratio	10.5 : 1	*9 : 1
-------------------	----	----	----	----	----	----	----------	--------

GEARBOX

							<i>Top</i>	<i>3rd</i>	<i>2nd</i>	<i>1st</i>
Overall ratio (standard)	4.63—1	5.29—1	7.41—1	11.62—1
(see page GD.28 for alternative ratios).							*4.87—1	*5.58—1	*7.8—1	*12.27—1

SPROCKETS

Final drive sprocket	21 teeth	*20 teeth
----------------------	----	----	----	----	----	----	----------	-----------

*Figures for 1968 models onwards.

WHEELS

Rim size and type, front	WM2-19 (knurled flanges)
Rim size and type, rear	WM3-18
Spoke sizes:				
Front (40)	10 s.w.g. $\times 5\frac{1}{8}$ "
Rear, left-hand (20)	10 s.w.g. $\times 7\frac{3}{8}$ "
Rear, right-hand (20)	10 s.w.g. $\times 7\frac{7}{16}$ "
*Front, right-hand (20)	8/10 s.w.g. $\times 4\text{-}11/16$ "
*Front, left-hand (20)	8/10 s.w.g. $\times 5\frac{5}{8}$ "

FRONT BRAKE (190 mm.)

Diameter	190 mm.	
Width	2"	(50.8 mm.)
Lining thickness	$\frac{3}{16}$ "	(4.702 mm.)
Lining area, sq. in. (sq. cm.)	32	(206.4)

*FRONT BRAKE (Twin-leading Shoe 1968)

Diameter	8"	(200.00 mm.)
Width	1 $\frac{5}{8}$ "	(41.275 mm.)
Lining thickness	$\frac{3}{16}$ "	(4.702 mm.)
Lining area, sq. in. (sq. cm.)	12.06	(305.00)

TYRES

Size:

Front	3.25" \times 19"	(82.55 \times 482.6 mm.)
Rear	4.00" \times 18"	(101.6 \times 457.2 mm.)

*Figures for 1968 models onwards.

MODEL A50 WASP (500 c.c.)

All general data is the same as data given for the A65 Lightning
(U.S.A.) model, except for the following:—

PISTON

Compression ratio	10.5 : 1	
Clearance, bottom of skirt0019"—.0024"	(.0473—.0610 mm.)
Clearance, top of skirt0045"—.0050"	(.1143—.1270 mm.)
<i>(both measured on major axis).</i>						
Gudgeon pin hole diameter7498"—.7500"	(19.0449—19.050 mm.)

PISTON RINGS

Compression ring, lower ring is tapered to
same dimensions:

Width0615"—.0625"	(1.5621—1.5875 mm.)
Thickness098"—.104"	(2.489—2.6416 mm.)
Clearance in groove002"	(.0508 mm.)
Fitted gap007"—.012"	(.178—.3048 mm.)
Oil control ring:						
Width124"—.125"	(3.1496—3.175 mm.)
Thickness098"—.104"	(2.489—2.6416 mm.)
Clearance in groove002"	(.0508 mm.)
Fitted gap007"—.012"	(.178—.3048 mm.)

GUDGEON PIN

Material	Nickel-chrome high tensile steel	
Fit in small-end (clearance)001"—.0006"	(.00254—.01525 mm.)
Diameter750"—.7502"	(19.05—.19.055 mm.)
Length	2.198"—2.208"	(55.73—56.083 mm.)

VALVES

Head diameter:						
Inlet	1.450"—1.455"	(36.83—36.957 mm.)
Exhaust	1.312"—1.317"	(33.325—33.452 mm.)

CYLINDER BARREL

Bore size (standard)	2.578"—2.579"	(65.481—65.506 mm.)
Maximum oversize	2.618"—2.619"	(66.497—66.522 mm.)

CYLINDER HEAD

Inlet port size	1 $\frac{5}{16}$ "	(33.337 mm.)
Exhaust port size	1-7/32"	(30.956 mm.)

CARBURETTORS

Type	Amal 389/230 (right-hand float chamber)
	Amal 689/230 (left-hand float chamber)
Main jet	190
Pilot jet	25
Needle jet size106" (2.6924 mm.)
Needle position	2
Throttle valve	389/3½ (right-hand); 689/3½ (left-hand)
Nominal choke size	1½" (28.575 mm.)

SPARK PLUGS

Type	Champion N.3
Gap setting025" (.635 mm.)
Thread size	14 mm. diameter × 19 mm. reach

SPROCKETS

Final drive sprocket, East Coast	18 teeth
Final drive sprocket, West Coast	17 teeth

GEARBOX

East Coast:	<i>Top</i>	<i>3rd</i>	<i>2nd</i>	<i>1st</i>
Overall ratios (standard)	5.41—1	6.19—1	8.65—1	13.58—1
<i>(see page GD.28 for alternative ratios).</i>				
West Coast	As A65 Hornet (U.S.A.) model for West Coast			

WHEELS

Rim size and type, front	WM3-19 (West Coast only)
Rim size and type, rear	WM3-18
Spoke sizes:	
Front, short (20)	10 s.w.g. × 5-15/16"
Front, long (20)	10 s.w.g. × 8⅞"
Rear, left-hand (20)	10 s.w.g. × 7⅝"
Rear, right-hand (20)	10 s.w.g. × 7⅞"

TYRES

Size:		
Front (East Coast)	3.50" × 19"	(88.9 × 482.6 mm.)
Front (West Coast)	4.00" × 19"	(101.6 × 482.6 mm.)
Rear	4.00" × 18"	(101.6 × 457.2 mm.)

REAR CHAIN

Chain size	⅝" × ⅜" × 105L
--------------------	----------------

ELECTRICAL EQUIPMENT (Energy Transfer Ignition)

Alternator type	Lucas RM.19ET
Coils	Lucas 3ET
Contact breaker	Lucas 4CA.ET
Condensers (capacitors)	Lucas 54441582

MODEL A50 ROYAL STAR (500 c.c.)

All General Data is the same as data given for the A50 Wasp (U.S.A.) model, except for the following:—

PISTON

Compression ratio	9.0 : 1
-------------------	----	----	----	----	---------

INLET BALANCE PIPE

..	Not required
----	----	----	--------------

INLET MANIFOLD

Carburettor port size	1" diameter	(25.4 mm.)
Cylinder head port size	15/16" diameter	(23.8125 mm.)

CARBURETTER

Type	Amal 376/319
Main jet	260
Pilot jet	25
Needle jet size106" (2.6924 mm.)
Needle position	3
Throttle valve	376/3 1/2
Nominal choke size	1" (25.4 mm.)

CARBURETTER (Concentric) 1968 A50 ROYAL STAR

Type	Amal R.626/7 (right-hand concentric)
Main jet	200
Pilot jet	25
Needle jet size106" (2.6924 mm.)
Needle position	2
Throttle valve	3 1/2
Nominal choke size	26 mm.
Air cleaner type	Dry surgical gauze

VALVE TIMING (Standard Camshaft)

Tappets set to .015" (.381 mm.) for checking purposes only:

Inlet opens	40° B.T.D.C.
Inlet closes	60° A.B.D.C.
Exhaust opens	65° B.B.D.C.
Exhaust closes	35° A.T.D.C.

GEARBOX

.. As A50 Wasp (U.S.A.) model for East Coast.

SPROCKETS

Final drive sprocket 18 teeth

WHEELS AND TYRES

.. Front wheel as for A65 Lightning (U.S.A.)
model.
Rear wheel as for A65 Lightning (East Coast
U.S.A.) model.

ELECTRICAL EQUIPMENT

.. As for A65 Lightning (U.S.A.) model

MODEL A65 LIGHTNING (650 c.c.)

All general data is the same as data given for A65 Lightning
(U.S.A.) model, except for the following:—

CARBURETTORS

Type	Amal 389/229 (right-hand float chamber)
	Amal 689/229 (left-hand float chamber)
Main jet	270
Pilot jet	25
Needle jet size106" (2.6924 mm.)
Needle position	3
Throttle valve	389/3
Nominal choke size	1-5/32" (29.36 mm.)

*CARBURETTORS

.. .. . Same as A65 Lightning (U.S.A.)

GEARBOX

Standard ratios as for A65 Lightning (U.S.A.)
model:

	<i>Top</i>	<i>3rd</i>	<i>2nd</i>	<i>1st</i>
Internal ratios (close ratio)	1—1	1.10—1	1.47—1	2.03—1
Overall ratios (close ratio)	4.87—1	5.36—1	7.16—1	9.89—1

(see page G.D.28 for alternative ratios).

WHEELS

.. .. . Rear wheel and tyre, as for A65 Lightning
(U.S.A.) East Coast.

ELECTRICAL EQUIPMENT

Bulbs:	<i>Number</i>	<i>Type</i>
Headlight (France)	As A65 Lightning (U.S.A.)	
Headlight (Continental)	Lucas 370	50/40 watt

CAPACITIES

Fuel tank 4 gallons (18 litres)

*Figures for 1968 models onwards.

MODEL A65 THUNDERBOLT (650 c.c.)

All general data is the same as data given for the A65 Thunderbolt (U.S.A.) model, except for the following:—

CARBURETTER

Type	Amal 389/233	
Main jet	300	
Pilot jet	25	
Needle jet size106"	(2.6924 mm.)
Needle position	3	
Throttle valve	389/3½	
Nominal choke size	1⅛"	(28.575 mm.)

***CARBURETTER**

..	Same as A65 Thunderbolt (1968) U.S.A.	
----	----	----	----	----	----	----	---------------------------------------	--

CAPACITIES

Fuel tank	4 gallons	(18 litres)
-----------	----	----	----	----	----	----	-----------	-------------

ELECTRICAL EQUIPMENT

..	As for A65 Lightning (Home and standard Export model).	
----	----	----	----	----	----	----	--	--

*Figures for 1968 models onwards.

MODEL A65 HORNET (650 c.c.) AND FIREBIRD SCRAMBLER (650 c.c.) 1968

All general data is the same as data given for the A65 Hornet
(U.S.A.) model, except for the following:—

CARBURETTERS

..	As A65 Lightning (Home and standard Export model).
----	----	----	----	--

*CARBURETTERS

..	Same as Firebird Scrambler (1968) U.S.A. model.
----	----	----	----	---

SPROCKETS

Final drive sprocket	20 teeth
----------------------	----	----	----	----	----------

GEARBOX

..	Ratios as for A65 Lightning (U.S.A.) standard model.
----	----	----	----	----	----	--

WHEELS

Front wheel and tyre	As for A65 Hornet (U.S.A.) model, East Coast
----------------------	----	----	----	----	--

CAPACITIES

Fuel tank	2 gallons	(9 litres)
Fuel tank (to order only)	4 gallons	(18 litres)

*Figures for 1968 models onwards.

**MODEL A65 SPITFIRE Mk. II SPECIAL (650 c.c.) AND
MODEL A65 SPITFIRE Mk. IV SPECIAL (650 c.c.) 1968**

All general data is the same as data given for the A65 Spitfire Mk. II Special (U.S.A.) model, except for the following:—

ELECTRICAL EQUIPMENT

.. .. . As A65 Lightning (Home and standard Export model).

CAPACITIES

Fuel tank (large capacity)	5 galls. U.S.	(22.5 litres)
Fuel tank (large capacity)	4 galls. Imperial	(18.2 litres)
Fuel tank (U.S.A.)	2¼ galls. U.S.	(10.0 litres)

MODEL A50 WASP (500 c.c.)

All general data is the same as data given for the A50 Wasp
(U.S.A.) model, except for the following:—

CARBURETTORS

Type	Amal 389/227 (right-hand float chamber)
							Amal 689/227 (left-hand float chamber)
Main jet	200
Pilot jet	25
Needle jet size106" (2.6924 mm.)
Needle position		2
Throttle valve	389/3½
Nominal choke size	1⅛" (28.575 mm.)

SPROCKETS

Final drive sprocket	18 teeth
----------------------	----	----	----	----	----	----------

GEARBOX

Standard ratios as for A50 Wasp (U.S.A.)
model, East Coast:

			<i>Top</i>	<i>3rd</i>	<i>2nd</i>	<i>1st</i>
Internal ratios (close ratio)	1—1	1.10—1	1.47—1	2.03—1
Overall ratios (close ratio)	5.41—1	5.95—1	7.95—1	10.98—1

(see page GD.28 for alternative ratios).

WHEELS

Front wheel	As A65 Lightning (U.S.A.) model
-------------	----	----	----	----	----	---------------------------------

TYRES

Size, front	3.50" × 19" (88.9 × 482.6 mm.)
-------------	----	----	----	----	----	--------------------------------

MODEL A50 ROYAL STAR (500 c.c.)

All general data is the same as data given for the A50 Royal Star
(U.S.A.) model, except for the following:—

CARBURETTER

Type	Amal 376/321	
Main jet	260	
Pilot jet	25	
Needle jet size106"	(2.6924 mm.)
Needle position	3	
Throttle valve	376/3 $\frac{1}{2}$	
Nominal choke size	1"	(25.4 mm.)

***CARBURETTER**

..	Same as A50 Royal Star (1968) U.S.A. model	
----	----	----	----	----	----	----	--	--

ELECTRICAL EQUIPMENT

..	As A65 Lightning (Home and standard Export model).	
----	----	----	----	----	----	----	--	--

CAPACITIES

Fuel tank	4 gallons	(18 litres)
-----------	----	----	----	----	----	----	-----------	-------------

*Figures for 1968 models onwards.

SPEEDOMETER GEARS

As fitted to all models with "Quick Release" Hubs and 47-tooth Rear Wheel Sprocket.


Speedometer Gearbox Ratio	Rear Tyre Size
21—10	3.50 × 19
2—1	4.00 × 18

GEARBOX RATIOS

Standard and Close Ratio Gears available for models with "Quick Release" Hubs, all with 28-tooth Engine, 58-tooth Clutch, and 47-tooth Rear Wheel Sprockets.

GEARBOX SPROCKET				17	18	20	21
INTERNAL RATIO	1.0	STANDARD GEARS	Top	5.73	5.41	4.87	4.63
	1.144		Third	6.56	6.19	5.57	5.29
	1.60		Second	9.17	8.65	7.79	7.41
	2.51		First	14.38	13.58	12.23	11.62
INTERNAL RATIO	1.0	CLOSE RATIO GEARS	Top	5.73	5.41	4.87	4.63
	1.10		Third	6.30	5.95	5.36	5.09
	1.47		Second	8.42	7.95	7.16	6.80
	2.03		First	11.63	10.98	9.89	9.39

FINDING THE RATIO



To find the gear ratios of a machine, calculate the top gear as follows:—

Divide the number of teeth on the clutch sprocket by the number of teeth on the engine sprocket and multiply the result by the number of teeth on the rear wheel sprocket, divided by the number of teeth on the gearbox sprocket, as example:—

$$\frac{\text{clutch sprocket (43)}}{\text{engine sprocket (17)}} \times \frac{\text{rear wheel sprocket (42)}}{\text{gearbox sprocket (19)}} = \frac{1806}{323} = 5.591$$

To find the intermediate gear ratio, multiply the overall top gear by the internal gear ratio concerned, as example:—

$$\text{top gear } 5.591 \text{ or } 5.6 \times \text{bottom gear internal ratio } 2.58 = 14.4 \text{ bottom gear overall ratio}$$

$$\text{Gearbox internal ratio} = \frac{\text{layshaft gear}}{\text{mainshaft gear}} \times \frac{\text{mainshaft top gear}}{\text{layshaft top gear}}$$

as example:—

$$\frac{(\text{layshaft 3rd}) 22\text{T}}{(\text{mainshaft 3rd}) 26\text{T}} \times \frac{(\text{mainshaft top}) 23\text{T}}{(\text{layshaft top}) 17\text{T}} = 1.144$$

(see FIG. B53 to identify gears)

MODEL A50 AND A65
PISTON DISPLACEMENT AND CRANKSHAFT DEGREES

DEGREES	PISTON DISPLACEMENT		DEGREES	PISTON DISPLACEMENT		DEGREES	PISTON DISPLACEMENT	
	INCHES	MM.		INCHES	MM.		INCHES	MM.
1	.0001	.00254	16	.0697	1.7703	31	.2559	6.499
2	.0010	.0254	17	.0793	2.01422	32	.2711	6.885
3	.0024	.06096	18	.0880	2.2352	33	.2876	7.305
4	.0043	.1092	19	.0980	2.4892	34	.3045	7.7343
5	.0067	.17018	20	.1084	2.7533	35	.3218	8.1737
6	.0098	.2489	21	.1194	3.0427	36	.3395	8.6233
7	.0134	.34036	22	.1307	3.3197	37	.3577	9.0855
8	.0175	.4445	23	.1427	3.6245	38	.3760	9.5504
9	.0224	.56896	24	.1551	3.9395	39	.3950	10.033
10	.0274	.69596	25	.1679	4.2646	40	.4143	10.5232
11	.0331	.84074	26	.1813	4.605	41	.4339	11.021
12	.0394	1.0007	27	.1952	4.918	42	.4538	11.5265
13	.0460	1.1684	28	.2094	5.3187	43	.4741	12.0421
14	.0535	1.3589	29	.2243	5.6972	44	.4947	12.5653
15	.0614	1.5595	30	.2393	6.0782	45	.5158	13.101

TORQUE WRENCH SETTINGS (DRY)

FLYWHEEL BOLTS	30 lb./ft.
CONNECTING ROD BOLTS	22 lb./ft.
CYLINDER HEAD BOLTS ($\frac{3}{8}$ ")	25 lb./ft.
CYLINDER HEAD BOLTS ($\frac{5}{16}$ ")	25 lb./ft.
CYLINDER HEAD NUTS ($\frac{3}{8}$ ")	26 lb./ft.
CYLINDER BARREL NUTS ($\frac{5}{16}$ ")	18 lb./ft.
OIL PUMP STUD NUTS	7 lb./ft.
CLUTCH CENTRE NUT	70-75 lb./ft.
KICKSTARTER RATCHET NUT	60 lb./ft.
ROTOR FIXING NUT	60 lb./ft.
STATOR FIXING NUTS	10-15 lb./ft.
CRANKSHAFT PINION NUT	60 lb./ft.
MANIFOLD STUD NUTS ($\frac{5}{16}$ ")	12½ lb./ft.
MANIFOLD STUD NUTS ($\frac{1}{4}$ ")	6 lb./ft.
CARBURETTOR FLANGE NUTS	10 lb./ft.
ZENER DIODE FIXING NUT	17 lb./in.

INDEX

	<i>Page</i>
ROUTINE MAINTENANCE	A.2
LUBRICATION POINTS	A.3
RECOMMENDED LUBRICANTS	A.4
ENGINE LUBRICATION SYSTEM	A.5-6
CHANGING OIL AND CLEANING THE FILTERS	A.6-8
OIL PRESSURE AND NON-RETURN VALVES	A.9
DISMANTLING AND REASSEMBLING THE OIL PUMP	A.9-10
REBUILDING THE PUMP	A.10
CONTACT BREAKER LUBRICATION	A.10-11
GEARBOX LUBRICATION	A.11-12
PRIMARY CHAINCASE LUBRICATION	A.12
REAR CHAIN LUBRICATION	A.12-13
STEERING HEAD RACE LUBRICATION	A.13
FRONT FORK LUBRICATION	A.13
WHEEL BEARINGS	A.13-14
LUBRICATION NIPPLES	A.14
LEFT-HAND REAR BRAKE	A.14
CONTROL CABLES	A.14-15
SPEEDOMETER AND TACHOMETER CABLES	A.15


RECOMMENDED LUBRICANTS

UNITED KINGDOM

ASSEMBLY	MOBIL	B.P.	CASTROL	ESSO	SHELL	REGENT
ENGINE: Summer and Winter	Mobiloil Super	S.A.E. 40	XXL	Extra 40/50	X100-40	Havoline S.A.E. 40 S.A.E. 30
		S.A.E. 30	XL	20/30	X100-30	
GEARBOX	D	S.A.E. 50	Grand Prix	Extra 40/50	X100-50	Havoline S.A.E. 50
PRIMARY CHAINCASE	Arctic	S.A.E. 20	Castrolite	Extra 20/30	X100-20	Havoline S.A.E. 20W
FRONT FORK	Arctic	S.A.E. 20	Castrolite	Extra 20/30	X100-20	Havoline S.A.E. 20W
WHEEL BEARINGS SWINGING ARM STEERING HEAD	Mobilgrease MP	Energrease L2	Castrolase LM	Multi- purpose H	Retinax A	Marfak 2

OTHER COUNTRIES

ASSEMBLY	MOBIL	B.P.	CASTROL	ESSO	SHELL	CALTEX
ENGINE: Above 32°C. 0° to 32°C. Below 0°C.	Mobiloil AF Mobiloil Super Mobiloil Arctic	Energol 40	XXL	S.A.E. 40/50	X100-40	S.A.E. 40
		Energol 30	XL	S.A.E. 20W/40	X100-30	S.A.E. 30
		Energol 20W	Castrolite	S.A.E. 10W/30	X100-20W	S.A.E. 20W
GEARBOX	Mobiloil Super	Energol 50	Grand Prix	S.A.E. 50	X100-50	S.A.E. 50
PRIMARY CHAINCASE	Mobiloil Arctic	Energol 20	Castrolite	S.A.E. 20W/40	X100-20W	S.A.E. 20W
WHEEL BEARINGS SWINGING ARM STEERING HEAD	Mobilgrease MP	Energrease L2	Castrolase LM	Multi- purpose H	Retinax A	Marfak 2
FRONT FORK: Above 32°C. 15°C. to 32°C. Below 15°C.	Mobiloil D Mobiloil Super Mobiloil Arctic	Energol 50 Energol 30 Energol 20W	Grand Prix XL Castrolite	S.A.E. 40 S.A.E. 20W/40 S.A.E. 10W/30	X100-50 X100-30 X100-20W	S.A.E. 50 S.A.E. 30 S.A.E. 20W



LUBRICATION DIAGRAM
SHOWING MODIFIED ROCKER
AND CAMSHAFT OIL FEED

FIG. A.2.

ENGINE LUBRICATION

The lubrication system is of the dry sump type, i.e., the oil is fed by gravity from a tank to the double gear type pump contained inside the crankcase on the gear-side. One set of gears in the pump draws oil from the tank through a gauze filter and delivers it under pressure past a non-return valve to the timing-side main bearing.

The oil then flows through drillings in the crankshaft past a sludge trap to the big-end bearings. Excess oil is thrown off by centrifugal force on to the cylinder walls, the underside of the piston (to lubricate the gudgeon pins), and is collected in various wells to lubricate the camshaft and gears.

If the pump pressure is above the intended maximum a release valve in the base of the timing cover opens to pass the excess oil direct to the bottom of the crankcase.

After lubricating the various internal parts of the engine the oil drains down into the sump, fastened to the underside of the crankcase. From here the second, and larger set of gears in the pump, draws oil through another non-return valve and pumps it back to the tank at a greater rate than the feed side thus ensuring that the sump is not flooded; hence the term "dry sump."

At the oil pipe connector on the crankcase, the return pipe is tapped to provide a supply of oil at low pressure to the valve rocker gear (1967/8 models). 1966 models have the pipe coming from the tank.

This pipe is connected by means of a union to the cylinder head immediately above the carburettor intake (single carburettor models).

The oil is then fed through drillings to the inlet rocker shaft thence via the shaft and a special oilway on the left-hand side of the rocker box to the exhaust rocker spindle. From the spindles the oil also lubricates the rocker ball




FIG. A.3. *Rocker lubrication.*

pins and adjuster screws, it then drains down into the crankcase, via the push rod tower, lubricating the tappets on its way down.

The feed to the rockers is metered by a split pin at the base of the centre pillar. Should this pin be replaced at any time one of exactly the same diameter must be used.

CHANGING THE OIL AND CLEANING THE FILTERS

The oil in new or reconditioned engines should be changed at 250, 500 and 1,000 mile (400, 800 and 1,500 km.) intervals during the running-in period and thereafter as stated on page A.2.

It is always advisable to drain when the oil is warm as it flows more readily.

To obtain access to the oil tank, turn the fasteners on the right-hand sidecover and withdraw the cover.

The oil tank filter is screwed into the lower right-hand corner of the tank. Obtain a suitable

receptacle with a piece of cardboard to use as a chute, unscrew the filter which has the normal right-hand thread, and allow the oil to drain.

Wash the filter thoroughly in petrol and allow to dry.

Lean the machine towards the right-hand side to drain off the remaining oil.

Again using a suitable receptacle to catch the oil, unscrew the four $\frac{1}{4}$ in. B.S.C. nuts holding the sump filter to the crankcase, take off the four shakeproof washers and remove the filter.

Allow the oil to drain, wash the filter thoroughly in petrol, and clean off the old jointing material from the filter and crankcase. If there is any sign of damage to the old gasket, replace it on assembly.




FIG. A.4. Oil tank and filter (pre-1967).




FIG. A.4A. Oil tank and filter (1968).

Non-Return Valves

With the sump filter off, check the scavenge pipe non-return valve, using a piece of wire, push the ball up off its seating and allow it to drop of its own weight, if it does not drop it indicates a build-up of sludge which can usually be removed by immersing the pipe in petrol for a short period.

If there has been a tendency for the crankcase to fill with oil after standing overnight so emitting clouds of smoke when the engine is started, it is quite possible that the feed line non-return valve is not seating properly thus allowing oil to run back from the tank, this is the valve behind the pump described on page A.9.

Oil Pipes

Unscrew the single $\frac{5}{16}$ B.S.F. bolt holding the oil feed and return pipes to the crankcase slightly to the right-hand of the sump filter.




FIG. A.5. Crankcase filter and ball valve.

On early models a plain paper gasket was used at this joint but later models use two rubber rings to provide an oil seal.

The later type can be fitted if desired but the metal pipes complete with rubber rings must be used, the rings alone cannot be used with the old pipes unless they are modified to suit.

Pull the pipes away and allow to drain.

NOTE:—Whenever the crankcase filter is removed for inspection and cleaning, it is important to replace approximately $\frac{1}{2}$ -pint of clean oil into the sump before the engine is restarted. This can be effected through the engine timing plug aperture in the crankcase.

Oil Tank

Usually it is sufficient to drain and refill the tank. If however the machine has been used for a long period and there is an accumulation of sludge in the tank, then it is good policy to flush it out with paraffin but, **all traces of paraffin must be removed before refilling.**

Reassembly

After thoroughly draining and cleaning the




FIG. A.6. Oil pipe connections (pre-1967).




FIG. A.6A. Oil pipe connections and rocker feed (1968).

system, replace the oil tank filter using a new fibre washer, reconnect the oil pipes to the crankcase using a new paper gasket and jointing cement sparingly, (cement is not used with the two rubber rings on later models). Replace the sump filter using a new paper gasket and cement. The four nuts must be tightened equally criss-crossing to avoid distortion.

NOTE:—The oil pipes are correctly fitted when crossed over, i.e., the outer pipe from the tank is attached to the inner connection on the crankcase.

Refill with correct grade oil.

OIL PRESSURE AND NON-RETURN VALVES

The oil pressure is controlled by the release valve situated on the right-hand side of the crankcase below the timing covers.

When the engine revolutions reach 3,000 revs per minute the oil pressure is around 50 lbs. per square inch therefore to prevent the pressure becoming excessive the valve opens and releases the excess oil direct into the crankcase whence it is returned to the tank.

The valve is pre-set at the works and there is no point in altering the setting. However after prolonged use the spring does tend to weaken and sometimes corrode and should be replaced. The length of the spring can be checked (see page GD.3) and if there is corrosion it is wise to replace the ball also after cleaning the valve body.

To remove the valve simply unscrew the large hexagon and to dismantle, unscrew the small hexagon. Do not attempt to remove the gauze filter and ensure that the fibre washers are fit for further use. Later models use O-rings in place of the fibre washers but, whilst the complete valve is interchangeable, the O-rings cannot be used with the old type valve.

There is a sludge trap built into the crankshaft and this may become blocked if oil changes are not carried out at the prescribed intervals.

Low Oil Pressure

Low oil pressure is dangerous since insufficient oil is likely to be delivered to the engine. The possible causes of low pressure being:—

1. Insufficient oil in the tank. Check the level and the return after replenishing. If the return is correct it will show as a mixture of oil and air issuing from the return stand pipe.
2. Tank and sump filters partly blocked preventing the free passage of oil.

3. Badly worn oil pump or badly worn big-end bearing shells.
4. Oil pipes incorrectly connected at the tank when the pump would be drawing air through the return pipe.

Syphoning

This, one of the commonest troubles, happens when one of the non-return ball valves is sticking off its seating. It can also be caused by a badly worn pump or one which is loose on its mounting.

Indications of syphoning are clouds of smoke from the exhaust when the engine is first started after standing overnight.

The non-return valves are located behind the oil pump body and in the scavenge pipe and consist of a ball and spring (see pages A.7 and B.30).

DISMANTLING AND REASSEMBLING THE PUMP

Having removed the pump from the engine take out the non-return valve ball and spring and store in a safe place.

Lever up the circlip at the spindle end and pull out with a pair of pliers. The thrust washer and spindle can now be removed.

Remove the four screws at the base of the pump, take off the base plate and spindle housing to uncover the four gears.

Wash all parts thoroughly in petrol and allow to dry before examining. Look for foreign matter jammed in the gear teeth and deep score marks in the pump body. These will be evident if the oil changing has been neglected. Figure A.7 shows slight score marks which could be ignored but the metal embedded in the gear tooth must be removed.




FIG. A.7.

The most likely point of wear will be on the spindle teeth, if these are worn to the extent that the sharp edge has gone then the spindle should be replaced.

On current model oil pumps there is an O-ring fitted to the feed driving gear to provide an oil seal between the gear and the spindle housing. This O-ring must be in good condition if it is to be used again otherwise it should be replaced.

The O-ring can be used on earlier models but a new spindle housing would be required also.


REBUILDING THE PUMP

Absolute cleanliness is essential when rebuilding the pump.

Insert the feed driving gear into its housing, this is the one on the rounded side of the body, place in position the driven feed gear then insert the return gears on the lower side of the pump. Slide the spindle through the two driven gears, **apply clean oil**, and refit the spindle housing and base plate.

Place the driving spindle in position and test the pump for freedom of movement; insert the spindle thrust washer and circlip.

Finally check the joint faces for parallelity; if the housing face is not in line it will be distorted


FIG. A.8. *Checking joint faces.*

when bolted to the crankcase and may prevent the pump from working (see Fig. A.8).

When refitting pump to crankcase secure nuts with a torque wrench set to figures quoted on page GD.31.

CONTACT BREAKER LUBRICATION

The contact breaker is situated in the inner timing cover and it is essential that no engine oil gets into the contact breaker housing. For this purpose there is an oil seal pressed into the inner timing cover at the back of the contact breaker unit,

FIG. A.9. *Contact breaker (1966/7).*

Lubrication of the contact breaker cam and the auto-advance unit pivot points is however necessary.

The cam is lubricated from an oil soaked felt wick which should have a few drops of engine oil (S.A.E. 20 or 30) applied every 5,000 miles (8,000 km.)—see Fig. A.9.

To lubricate the auto-advance unit it is necessary to remove the contact breaker plate. First place a mark across the plate and the housing so that it can be replaced in exactly the same position then take out the two contact breaker plate mounting screws and lift off the plate.

The pivot points of the auto-advance unit should be lightly oiled where indicated in Fig. A.10 again at 5,000 miles (8,000 km.) intervals.




FIG. A.10. Auto-advance unit.

After lubricating, replace the plate to the marks but, if the timing has been upset, follow the instructions on pages B.50-53.




FIG. A.9A. Contact breaker (1968).

GEARBOX LUBRICATION

The gearbox having its own oil bath is independent of the engine for lubrication but, for the same reason, the level of oil must be checked and any loss due to leakage made good.

The lower set of gears runs in the oil bath and oil being squeezed from or thrown off these gears by centrifugal force lubricates the rest of the gears, bearings, and bushes.

To drain the gearbox take out the filler plug on top of the gearbox then unscrew and take out the larger of the two plugs underneath, draining the oil into a suitable receptacle (see Fig. A.11, page A.12).

After draining, replace the drain plug making sure that the fibre washer (or O-ring) whichever is fitted, is in good condition but leave out the smaller plug.

Now replace the oil until it commences to overflow down the drain plug tube.

Replace the small plug.

Recommended grades are quoted on page A.4, capacities on page GD.12 and checking frequency on page A.2.




FIG. A.11. *The gearbox oil level screw and drain plug.*

On 1968 models the gearbox filler plug has been moved from the right-hand crankcase half to the inner timing cover and the plug itself has been replaced by a plastic dipstick. The drain plug as shown in Fig. A.11 is now solely used for draining and not as a level plug and drain plug combined.

Before refitting the drain plug after draining the gearbox, check that the rubber O-ring seal is in good condition, if not renew it.

PRIMARY CHAINCASE LUBRICATION

Like the gearbox, the primary chaincase, having its own oil bath, is independent of the engine but the level of oil must be checked periodically and the oil drained and replaced as indicated in the routine maintenance sheet, page A.2.

The oil bath in the primary chaincase does not lubricate the chain only, the clutch being contained in the same case is dependent on this oil supply for its efficient functioning and a drip feed is also provided for the rear chain through an oil well and nozzle at the back of the chaincase.

There are two of the chain case cover screws which have their heads painted red; they are situated midway along the lower rim of the case, the front one being the oil level screw and the rear is the drain screw.

To drain the oil, take out one of the inspection caps at the side of the case and the drain screw.

After draining, replace the drain screw, take out level screw and add oil through the inspection cap hole until it commences to run out of the level screw hole.

Oil containing molybdenum disulphide or graphite must NOT be used in the primary chaincase.

Drain the oil and use the grades as recommended on page A.4.

REAR CHAIN

Oil thrown off the primary chain is collected in a small well at the back of the primary case from which a drip feed is supplied to the rear chain.

This may not, however, be adequate in some circumstances and it may be advisable to supplement the drip feed by using an oil can occasionally on the rear chain, depending on

the state of the chain. The chain should be moist with oil but not dripping.

The best method of lubrication is to remove the chain every 2,000 miles, wash thoroughly in paraffin and allow to drain, then immerse it in melted tallow to which powdered graphite has been added.

Hang the chain over the grease tin to allow the surplus grease to drain off. If the tin is covered after use it can be used many times, but always use care when melting.

STEERING HEAD

The steering head bearings are packed with grease on assembly and only require repacking at the intervals quoted on page A.2.

Removal and replacement of the steering is dealt with on pages E.3-5 in the fork section.

When the balls are removed they should be cleaned by placing in clean rag then rolling the rag between the palms of the hands, changing the position on the rag as necessary.

After cleaning examine carefully for pitting and corrosion and examine the cups and cones for pocketing and cracks.

If there is evidence of damage, it is wise to replace all the bearings, cones and cups.

The fresh grease will hold the balls in position during assembly but make sure that there is the correct number as quoted on page GD.9 and that the grease is as quoted on page A.4.

FRONT FORKS

The oil contained in the forks not only lubricates the bearing bushes, but also acts as the damping medium. It is for this latter reason essential that the amount of oil in each fork leg is exactly the same.

Oil leakage midway up the forks usually indicates that the oil seal has failed and requires replacement; this is dealt with on page E.7.

Correct period for changing the oil as quoted on page A.2 is every 12,000 miles (19,200 km.) but some owners may not cover this mileage in a year, in which case it is suggested that the oil be changed every 12 months.

To drain the oil, unscrew and remove the two fork top nuts and take out the drain screws at the base of each fork leg (see Fig. A.12).

It is not necessary to remove the fork damper rods from the top nuts to drain or replace the oil.






FIG. A.12.

After allowing several minutes to drain, pump the forks up and down to expel any oil remaining, then replace the drain screws taking care not to omit the fibre washers.

Refill with one-third pint (190 c.c.) of the correct grade of oil (see page A.3).

WHEEL BEARINGS

The wheel bearings are packed with grease on assembly and only require repacking at the interval quoted on page A.2.

FIG. A.13. *Oiling a cable.*FIG. A.14. *Greasing speedometer cable.*

The bearings should be removed as quoted in Section F, dealing with wheels. After removal wash thoroughly in paraffin and, if possible, use an air line to blow any grit or paraffin remaining, out of the bearings.

Pack with the correct grade of grease as quoted on page A.4 after assembling the first bearing. Do not over-lubricate and do not handle brake shoes with greasy hands.

LUBRICATION NIPPLES

There are a number of points to be lubricated by means of a grease gun and nipples as indicated on page A.3. They comprise both front and rear brake cam spindles (5), rear brake pedal pivot (8) and centre stand (6). Give one stroke of the grease gun to each of these points at the period indicated on page A.2. No more than one stroke of the gun should be used at point (5) as excess

grease is liable to get on the brake linings.

LEFT-HAND REAR BRAKE

Models equipped with left-hand rear brake have no cross-shaft. On these models the brake pedal is provided with an oil hole to which a few drops of oil from a can should be applied every 2,000 miles or more frequently if the pivot point tends to dry up.

CABLES

1966 machines are fitted with cables, the inner wires of which, have been treated with a molybdenum based grease which forms a semi-permanent lubricant. They will give long service before needing attention.

Exposed sections of inner cables should be

lubricated periodically (see page A.2). This can be done either by greasing or applying the oil can.

The most satisfactory way, however, is to

induce a flow between the inner and outer casing by forming some sort of reservoir to hold the oil and leaving the cable for several hours (see Fig. A.13), for the oil to seep through.

SPEEDOMETER CABLES

It is necessary to lubricate speedometer cables particularly to prevent premature failure of the inner wire. Care is however necessary to avoid over-zealous greasing which may result in the lubricant getting into the instrument head. On models with exposed speedometer heads it is

only necessary to unscrew the cable nipple below the head and to pull out the inner wire for cleaning and greasing.

Apply grease sparingly to the inner wire, and none at all within 6 in. of the instrument head.

INDEX

	<i>Page</i>
ENGINE EXPLODED	B.3
ENGINE DESCRIPTION	B.4
DECARBONISING	B.4-15
Preparation	B.5
Removing the Petrol Tank	B.5
Removing the Carburetter(s)	B.5
Removing the G.P. Carburetters and Float Chamber (model A65 Spitfire Mk. II Special only)	B.6
Rocker Box and Exhaust Pipes	B.6
Exhaust Rocker Assembly	B.6-7
Cylinder Head Bolts and Studs	B.7
Cylinder Head Removal	B.8
Valve Springs	B.8
Push Rods	B.9
Valves and Guides	B.9
Valve Grinding	B.10
Cylinder Barrel	B.10-11
Removing the Barrel	B.11
Tappets	B.11
Cylinder Bores	B.12
Removing the Pistons	B.12
Piston Rings	B.12
Replacing the Rings	B.13
Small-end Bushes	B.13
Reassembly after Decarbonising	B.13
Replacing the Barrel	B.14
Replacing the Head	B.14
Tappet Adjustment	B.14-15
Replacing the Carburetter(s)	B.15
REPLACING THE G.P. CARBURETTERS AND FLOAT CHAMBER (model A65 Spitfire Mk. II Special only)	B.15
COMPRESSION PRESSURES	B.16
REMOVING THE ENGINE UNIT	B.16
Footrests	B.16
Chainguard	B.16-17
Rear Chain	B.17
Clutch Cable	B.17
Speedometer and Rev-counter Cables	B.17
Oil Draining	B.17-18
Mounting Bolts	B.18

INDEX

REPLACING THE ENGINE UNIT	Page B.18-20
DISMANTLING THE ENGINE UNIT	B.20-46
Transmission	B.20-21
Primary Drive Cover	B.21
Clutch Dismantling	B.21-22
Generator	B.22
Inspecting the Clutch	B.23
Shock Absorber	B.23
Clutch Chainwheel	B.23
Final Drive Sprocket	B.23-24
Clutch Operation	B.24
Reassembling the Primary Drive	B.24-26
The Contact Breaker	B.27
Removing the Contact Breaker	B.28
Timing Sidecover	B.28
Inner Timing Cover	B.29
Timing Gear and Oil Pump	B.29-30
Replacing the Pump	B.30
Timing Gears	B.30-31
Gearbox Dismantling	B.31-32
Gearbox Reassembly	B.32-34
Sequence of Gear Changing	B.35-40
Splitting the Crankcase	B.41
Camshaft	B.42
Crankshaft Assembly	B.40-42
Crankshaft Grinding	B.43
Gearside Journal	B.43
Big-End Journal	B.44
Crankshaft Sludge Trap	B.45
Flywheel Balancing (Static)	B.45-46
BEARINGS, BUSHES AND OIL SEALS	B.46-47
REASSEMBLING THE CONNECTING RODS	B.47-48
REASSEMBLING THE CRANKCASE	B.48-49
REPLACING THE INNER COVER	B.49-50
IGNITION TIMING	B.50-53




FIG. B.1. 500 and 650 c.c. engine exploded.

DESCRIPTION (500 and 650 c.c.)

Of unit construction the engine has a twin cylinder barrel of close grained cast-iron mounted on an aluminium crankcase made from two halves bolted and machined together. The gearbox is an integral part of the gear-side or right-hand half-case which also houses the oil pump and timing gears.

The primary drive case is an integral part of the left-hand or drive-side half-crankcase which, in addition to housing half the crankshaft, houses the alternator, clutch and primary chain.

The aluminium alloy cylinder head has high duty cast-iron valve seat inserts cast-in, and the rocker trunnions form an integral part of the head.

"Lo-Ex" aluminium pistons having two compression rings, one of which is tapered and one scraper ring are used on H-section connecting rods made from RR.56 biduminium alloy. The one-piece camshaft operates in three bushes, one in "Clevite 10" and the other two made from sintered bronze.

The alternator consists of a rotor mounted on the left-hand of the crankshaft and a six-coil stator mounted within a housing on three studs.

The one-piece, forged, two-throw crankshaft, has a detachable flywheel held in position by three high-tensile steel bolts secured by "Loctite" sealant. Incorporated in the crankshaft is a tubular centrifugal sludge trap.

The double gear oil pump is driven off a crankshaft mounted worm wheel and supplies oil to the crankshaft, cylinders, pistons and timing gears. When required the oil pump also drives a revolution counter.

Both the gearbox and primary chaincase have their own independent oil baths.

Power is transmitted from the engine through the engine sprocket and triple primary chain to the clutch, which has a built-in shock absorber, then to the four-speed gearbox and final drive sprocket.

An Amal monobloc carburetter is attached to an inlet manifold which in turn is bolted to the cylinder head on single carburetter models. When twin carburetters are used they are each attached direct to the cylinder head and an inlet balance pipe, joining the carburetters at their flanges, provides an even "tick-over."

DECARBONISING — DESCRIPTION

Decarbonising or "top overhaul" as it is sometimes called means the removal of carbon deposited on the top of the piston, on valve heads, around the combustion chamber and inlet and exhaust ports. It also means that while the upper portion of the engine is dismantled for this purpose the opportunity is taken to examine the various parts of the engine for general "wear and tear", hence the term "top overhaul."

Carbon, which is the result of the combustion taking place in the engine when running, is not harmful providing it is removed at the right time,

that is before the deposit is too heavy and therefore likely to cause pre-ignition and other symptoms which may impair performance.

The usual symptoms, indicating the need for decarbonising are, a tendency to "pink" (metallic knocking sound when under load), a general falling off of power noticeable mainly on hills, a tendency for the engine to run hotter than usual and an increase in petrol consumption.

Decarbonising should not be carried out unnecessarily, it should only be done when the engine really needs it.

PREPARING TO DECARBONISE

Before commencing the work it is advisable to have the following equipment available:—

Spanners from $\frac{3}{16}$ W.— $\frac{1}{4}$ in. B.S.F. to W. $\frac{5}{16}$ — $\frac{3}{8}$ in. B.S.F.

Set of scrapers.

Set of feeler gauges.

Supply of fine emery cloth.

Jointing compound or cement.

Grinding paste.

Clean engine oil.

Two pieces of hardwood, 9 in. long by $\frac{5}{8}$ in. square.

Top overhaul gasket set No. 00-3158 (A65) or No. 00-3157 (A50).

Gudgeon pin circlips No. 66-954 (4).

Valve springs (set) No. 40-169, 68-475.

Paraffin and rag for cleaning.

Perfect cleanliness is essential to ensure success in any service task, so, before starting the job, make sure that you have a clean bench or working area in which to operate and room to place parts as they are removed.

REMOVING THE PETROL TANK

The following instruction apply equally to machines fitted with twin or single carburetters, except that with twin carburetters there will also be two fuel feeds and two air cleaners to be removed.

Turn off the petrol supply at the taps and disconnect the fuel pipes at the carburetter(s) by unscrewing the banjo union bolt(s). Be careful not to lose the nylon filter or the fibre washers.

Take out the rubber plug in the centre of the tank and remove the nut and washer which will be exposed. On all steel tanks, both two or four gallon, there is an anti-roll bar fitted underneath the forward end, remove the two $\frac{1}{16}$ in. bolts and washers, take the bar away and lift the tank clear of the frame.

The fibre-glass tanks only use the single centre fixing bolt to secure them to the frame.

REMOVING THE CARBURETTER(S)

On twin carburetter models it will be necessary to first remove the sidecovers, each secured by two fasteners. Unscrew the air filters and remove the two nuts and washers securing each carburetter to the cylinder head.

Note position of gaskets and tufnol washer.

For the purpose of decarbonising it will be sufficient to pull each carburetter off its studs and tie back out of the way.

To remove the carburetters completely, disconnect the throttle cable at the handlebar by

removing the two screws securing the halves of the twist grip, part the body and pull out the cable nipple. Withdraw the cables from the grip.

Open the air control to its fullest extent, then close it, at the same time pull the outer casing and inner wire from the stop, remove the nipple from the lever and pull both throttle and air cables from the frame clips.

The same procedure can be used for the single carburetter models but note that the carburetter is fixed to an inlet manifold which itself is secured to the cylinder head by four nuts with washers.

REMOVING THE G.P.2 CARBURETTERS AND REMOTE FLOAT CHAMBER MODEL A65 SPITFIRE Mk. II SPECIAL ONLY

Take off each sidecover, turn off the petrol taps and disconnect petrol supply pipes. To avoid spilling petrol from the pipes, tie each pipe vertically to the body of its carburetter.

Remove petrol tank as described above.

Undo the locking rings with a suitable C-spanner and take off the bell mouths from each carburetter.

NOTE:—It is most important that the bell mouths are refitted to the same carburetters from which they were removed. Mark each tube, on removal, to indicate from which carburetter they were taken.

To provide access to the inner left-hand carburetter flange nut, disconnect the rocker oil feed pipe and tie back out of the way.

Take off carburetter flange nuts and two petrol pipe clips.

Remove the locknut from the recess in the float chamber mounting and release the fixing stud adaptor.

The carburetters and float chamber can now be withdrawn from the engine and tied back out of the way.

ROCKER BOX AND EXHAUST PIPES

Remove the engine steady stay at the front of the cylinder head by taking out the bolt securing it to the cylinder head, slacken off the bolt holding the steering head end and swing the stay to one side.

Remove the bolts securing the exhaust pipes and silencers to the frame brackets, tap the pipes out of the head using a raw-hide mallet and take away complete.

With siamese pipes the clip securing the left-hand pipe must be slackened off also.

Straight through and twin pipes have a tie rod in front of the engine which must be released before the pipes can be removed.

If this is not done the cylinder head may be seriously damaged.

To remove the rocker box cover take off the six $\frac{1}{4}$ in. nuts and plain washers, break the joint by a light tap with a mallet, and remove the cover.

There are two projections at the rear of the cover to assist in its removal. The paper gasket is cemented on one side only and should always be replaced.

Disconnect the oil feed pipe to the rocker box by unscrewing the union nut at the rear of the box. The other end pushes into a rubber sleeve adjacent to the oil tank.

EXHAUST ROCKER ASSEMBLY

The exhaust valve rocker assembly must be removed to obtain access to the two front cylinder head bolts. First slacken off the two front (exhaust) valve rocker adjusting screws until the two push rods can be removed, then unscrew the

nut holding the exhaust rocker shaft—at the front right-hand side—and tap the shaft through towards the left hand, leaving the rockers in position.

To avoid damaging the end of the shaft use a blunt centre punch. Take careful note of the position of the spring and thrust washers, and remove the rockers from between the shaft pillars.

From left to right, the assembly should be:—

THRUST WASHER
 SPRING WASHER
 LEFT-HAND ROCKER
 THRUST WASHER
 CENTRE POST
 THRUST WASHER
 RIGHT-HAND ROCKER
 SPRING WASHER
 THRUST WASHER

Spring washers are always fitted next to the rockers, they must never be fitted next to the shaft pillars.

There is no need to disturb the inlet rocker assembly, except for replacement purposes or, if there is doubt about the oil supply to the rockers. See page A.6 for details of the rocker lubrication.




FIG. B.2. Exhaust rocker spindle.




FIG. B.3. Exhaust rocker assembly.

CYLINDER HEAD BOLTS AND STUDS





FIG. B.4. Centre head bolt.

The cylinder head is secured by four $\frac{3}{8}$ in. B.S.C. nuts and washers on studs screwed into the barrel adjacent to the spark plug holes, two $\frac{3}{8}$ in. B.S.F. bolts at the front, two $\frac{3}{8}$ in. B.S.F. bolts at the rear, and one $\frac{3}{8}$ in. B.S.F. bolt in the centre at the bottom of the push rod tower. This latter bolt is short and the push rods must be removed to obtain access to it.

Lift out the exhaust push rods, slacken off the inlet rocker adjusting screws, and take out the inlet push rods.

Pull off the spark plug high-tension leads and remove the spark plugs.

CYLINDER HEAD REMOVAL

FIG. B.5. *Removing the head.*

Slacken off the nuts and bolts starting with the four long centre bolts then the short one in the push rod tunnel and finally the four nuts, unscrewing each a little at a time to avoid distorting the head. When all the nuts and bolts are removed, break the joint by tapping the exhaust ports gently with a hide mallet, and lift the head clear. Do not disturb the inlet manifold (if fitted), unless it is to be changed, or the gaskets are to be renewed. Twin carburettors are fitted direct to the head and do not require a manifold.

VALVE SPRINGS


Using service tool No. 61-3340, or any other good valve spring compressor, compress the springs until the split collets can be removed. If the tool is given a sharp blow with a hammer on the spring side after the spring has been compressed a little, it will release the collets from the tapered hole in the valve cap.

When the collets are out, the valve springs and top collars can be lifted from the valve stems, swilled in paraffin, then placed on a numbered board indicating their position in the head.

The springs may have settled through long use and they should therefore be checked in accordance with the dimensions quoted on page GD.4.

If the springs have settled more than $\frac{1}{16}$ in. (1.587 mm.), or there are signs of cracking, they should be replaced.

When refitting the valve springs it is important that the outer or larger valve spring should be fitted with the close wound coils placed downwards in the spring cup adjacent to the cylinder head.

FIG. B.6. *Checking the springs.*

Valve springs for a 1967/8 model will not fit a 1966 model owing to a change in the bottom spring cups, they can however be used if the latest type bottom cup is used.

PUSH RODS

Examine the push rod end cups to see if they are chipped, worn or loose, and check the rods by rolling on a flat surface, such as a piece of plate glass, to see if they are bent. If any of these faults are evident the rod should be replaced.




FIG. B.7. Driving out the guide.


VALVES AND GUIDES

Check the valves in the guides, there should be no excessive side play or evidence of carbon build-up on that portion of the stem which operates in the guide. Carbon deposits can be removed by careful scraping and very light use of fine emery cloth. If there are signs of scoring on the stems indicating seizure, both valve and guide should be replaced.

An old guide can be driven out with service tool No. 61-3382 but, the aluminium head should first be heated by immersing in hot water. The new guide can be driven in with the same punch while the head is still warm (see Fig. B.7).

Valve heads can be refaced on a valve refacer but if pitting is deep or the valve head is burnt, then a new valve must be fitted and ground-in.

When a new valve guide has been fitted, or if a new valve is necessary, the valve seat in the head must be re-cut at the correct angle of 45°.



BADLY BURNT VALVE

FIG. B.8. Burnt valve.

Sometimes, when the engine has been decarbonised many times, valves become "pocketed", that is the head and seat is below the surface of the combustion chamber so impairing the efficiency of the valve and affecting the gas flow. When this happens it is necessary to remove the pocket using a special 30° angle cutter before re-cutting the seat or grinding-in the valve.




FIG. B.9. Pocketed valve.

The valve seats can be re-cut with pilot No. 61-3293 and cutter No. 61-3301 which has a 45° angle one side and 30° angle on the other.

VALVE GRINDING

During decarbonisation, all valves must be ground-in, each to its own seat, whether new or old. This operation is carried out only after all the carbon deposit has been removed from the combustion chamber.

Removal of carbon from the head, inlet and exhaust ports, can be done with scrapers or rotary files but whichever method is used great care must be taken to avoid damage to the valve seats due to the tools slipping across the seats. For final "polishing" the careful use of fine emery cloth wetted by paraffin is recommended.

Having removed the carbon smear a small quantity of fine grinding paste over the face of the valve and return it to its seat.

Hold the head of the valve with tool No. 65-9240 and rotate the valve backwards and forwards maintaining steady pressure.

Every few strokes raise the valve and turn to a new position.

Take the valve out, clean off the paste and examine both face and seat, continuing the grinding until both show a uniform matt finish all round. After grinding remove all traces of grinding paste and smear the valve stem with clean engine oil before reassembling the valve to the head.

Prolonged grinding does not produce the same results as re-cutting and must be avoided at all costs.




FIG. B.10. Grinding-in valve.

CYLINDER BARREL

In the ordinary course of events it should rarely be necessary to remove the cylinder barrel, since top overhaul, already described, usually suffices to keep the engine in first-class working condition for thousands of miles, unless the condition of the engine indicates that the pistons, rings or cylinder bores require attention, the cylinder barrel should not be disturbed.

If the bores are worn this can sometimes be detected by placing the fingers on top of the piston and pushing **backwards** and forwards in the direction of rotation. Symptoms indicating faulty piston rings might include heavy oil consumption, and poor compression (but only if the

valves are in good order, otherwise they are much more likely to be the cause). Excessive piston slap when warm may indicate a worn bore or severe damage through seizure.

Worn bores can be measured with cylinder bore dial gauges, by moving the pistons to the bottom of the bores thus exposing them for examination (see page B.12).

If the barrel is not being removed bring the pistons to the top of the bores, plug the push rod tower with clean rag, and proceed to remove the carbon from the piston crowns using a suitable scraper such as a stick of tinsmiths solder flattened on the end to form a scraper.

Always leave a ring of carbon round the edge of the piston crown and do not remove the ring of carbon at the top of the cylinder bore.

After cleaning the pistons again rotate the engine to lower the pistons and wipe all loose carbon from the cylinder walls.

The cylinder barrel and head joint faces must also be cleaned and great care taken not to damage the faces by scoring with the scraper. Such score marks would result in gas leakage, loss of compression and even burning of the cylinder head faces.




FIG. B.11. Removing carbon.




FIG. B.12. Removing barrel.

REMOVING THE BARREL

To remove the barrel, unscrew and remove the eight cylinder base nuts, revolve the engine until the pistons are at bottom dead centre, then carefully lift the barrel until the pistons are clear of the bores. While this is being done get an assistant to steady the pistons as they emerge from the barrel.

After removal cover the mouth of the crank-case with clean rag to prevent grit and dust falling in.

TAPPETS

The tappets are retained in the barrel by circlips around their upper ends.

Examine both ends for signs of wear or chipping and make sure that they are quite free to move in the block. If there are signs of "scuffing" on the feet they should be replaced but, the camshaft should be examined too, as this also may be damaged.

To remove a tappet drive it out of the barrel

using a soft metal punch on the upper end, as soon as the circlip is free the tappet can be removed from the lower end.

To replace, insert the tappet into the barrel, preferably in the same place if it is being refitted, then fit the circlip from above using service tool No. 61-5702. Slip the circlip over the tool "pilot" shaft and press in the handle to transfer it to the tappet ring.




FIG. B.13. *Checking bore size.*

REMOVING THE PISTONS

To remove a piston from its connecting rod it is first necessary to remove one of the gudgeon pin circlips. This is best accomplished with a pointed instrument such as the tang end of a file suitably ground to enter the slot in the piston. If the gudgeon pin bush or piston are worn the pin will come out easily otherwise it may be necessary to heat the piston with rags dipped in hot water and wrung out.

Then, supporting the piston, tap out the gudgeon pin using a light hammer and punch.

When the piston is free, mark the inside of the piston skirt, so that it can be replaced the correct way round and on the same connecting rod.




FIG. B.15. *Checking ring groove.*

CYLINDER BORES

Examine the bores for signs of seizure or scoring and check for bore wear, the maximum usually being the top 1 in. in the direction of rotation. Bore wear anti-rotation and at the base of the cylinder is usually negligible. If the original bore size is unknown the amount of wear can therefore be considered as the difference between the base measurement and the point of maximum dimension shown by the dial.

If wear exceeds .005 in. (.127 mm.) at the top (rotation) then a rebore with new piston is indicated.




FIG. B.14. *Removing circlip.*

PISTON RINGS

If the rings are stuck in their grooves they will need to be carefully prised free and removed from the piston. All carbon should be carefully scraped from the grooves and the back of the rings. An old broken ring is useful for cleaning the grooves in the piston. If any rings show brown patches on the faces, replace them with new rings. Check the ring gaps by inserting each piston in its bore then slide the ring up to the piston to square it up and measure the gap with feeler gauges. Fit new rings if gaps greatly exceed figures quoted on page GD.2.

REPLACING THE RINGS

It is always advisable to check the gap of new rings before fitting, and if the gap is less than the minimum stated on page GD.2, the ends of the rings should be carefully filed to the correct limit.

When the ring gaps are measured the rings should be in the position of minimum bore wear which is usually at the bottom of the stroke.

Piston rings are very brittle and unless handled carefully are easily broken.

Reassembly is in the reverse order to that for dismantling, that is the scraper ring is replaced first. The middle ring on each piston is tapered this being indicated by the letter "T" marked on one face which must always be uppermost on the piston.

The ring gaps must always be equally spaced round the piston, that is, at 120° apart to restrict gas leakage through the gaps to the absolute minimum.

SMALL-END BUSHES

Small-end bush wear is normally very slight but when excessive it can cause an unpleasant high pitched tapping sound. The gudgeon pin should be a good sliding fit in the bush with no appreciable up and down movement, if there is considerable up and down movement then the bush should be changed.

To change a bush, push the old one out and at the same time press the new one in with service tool No. 61-3652. The new bush must be correctly lined up with the oil hole and reamed to .7503—.7506 in. (19.0576—19.0652 mm.) after pressing into the connecting rod.

REASSEMBLY AFTER DECARBONISING

Having ground-in and replaced the valves and springs in the cylinder head taking great care to correctly fit the tapered cotters, replace the pistons on the connecting rods so that they are the same way round as previously. Always use new gudgeon pin circlips and see that they are pressed well down into their grooves.

If the circlips come adrift or if one is omitted the cylinder barrel will soon be damaged and will require replacement.

Use a new cylinder base washer and support the pistons with two pieces of hardwood placed across the crankcase under the piston skirts (see page B.5 for measurements).





FIG. B.16. *Piston ring slippers.*

REPLACING THE BARREL

FIG. B.17. *Removing slippers*

Apply a coating of clean engine oil to the pistons and position the ring gaps at 120°. Using two piston ring slippers, service tool No. 61-3682 (A50) or 61-3707 (A65) compress the rings so that they are just free to move, then replace the barrel which will displace the slippers as the rings enter the bores. Remove the slippers after the rings have entered the barrel.

Take out the two pieces of wood to drop the barrel over the studs, replace the stud nuts and tighten down evenly to avoid distortion with torque wrench to figures quoted on page GD.31.

REPLACING THE HEAD

Place the cylinder head gasket in position. Slacken off the inlet valve rockers completely and place the head in position over the four studs. Screw in the five cylinder head bolts and replace the four nuts and washers on the studs, tighten down each a little at a time criss-crossing the head from the centre outwards.

Do not forget the short bolt inside the push rod tower, this bolt cannot be fitted with the push rods in position.

Using a torque wrench tighten the bolts and nuts to the figures quoted on page GD.31.

When the head is finally pulled down replace the two short push rods on the two outer tappets and under the inlet (rear) rocker arms.

Assemble the exhaust (front) rockers in the order detailed on page B.7 with the adjuster screws over the valves and fit the two long push rods on to the two inner tappets and under the exhaust rocker ball pins. Reconnect the rocker oil feed pipe.

TAPPET ADJUSTMENT

To set the tappets (or valve clearance) the valve must be in the correct position, that is with the cam follower (tappet) on the base circle of the cam as follows:—

Left-hand inlet valve spring fully compressed (valve fully open).
Set the right-hand inlet valve.

Right-hand inlet valve spring fully compressed (valve fully open).

Set the left-hand inlet valve.

Left-hand exhaust valve spring fully compressed (valve fully open).

Set the right-hand exhaust valve.

Right-hand exhaust valve spring fully compressed (valve fully open).

Set the left-hand exhaust valve.

With the valve in the correct position check the gap with the appropriate feeler gauge .008 in. (.2032 mm.) inlet; .010 in. (.254 mm.) exhaust.




FIG. B.18. *Measuring the valve clearance.*

If adjustment is required slacken off the locknut (A) and screw the adjuster (B) in or out as necessary. Re-check the setting after tightening the locknut.

Replace the rocker box cover using a new gasket.

REPLACING THE CARBURETTER(S)

The fitting of the carburetter(s) is the same whether there are single or twin carburetters.

Place the paper gasket next to the head (twin) or the inlet manifold (single) then position the tufnol block(s) ensure that the rubber (O-rings) in the carburetter flange is sound and in position, place the carburetter in position and secure with two spring washers and two $\frac{5}{16}$ in. B.S.C. nuts. Be very careful to tighten the nuts equally and avoid over-tightening, this only distorts the carburetter flange and results in an air leak and

unsatisfactory control operation. Carburetter flange nuts should be tightened with torque wrench to figures quoted on page GD.31.

When refitting inlet manifold the nuts should be tightened to figures quoted on page GD.31.

Thread the cables through the frame clips and reconnect to the twist grip and air controls.

To complete the work of decarbonising, replace the air cleaner(s) reconnect the petrol pipes and engine steady stay, and replace the petrol tank and sidecovers.

Note, when replacing the air cleaners see that the unperforated portion is so positioned that water cannot drip off the tank into the filter.

REPLACING THE G.P.2 CARBURETTERS AND REMOTE FLOAT CHAMBER MODEL A65 SPITFIRE Mk. II SPECIAL ONLY

Fit the carburetter washers to the flanges; one paper, one tufnol, one paper respectively for each flange.

Locate the carburetters on to the studs, replace the float chamber stud adaptor into its mounting and secure with locknut (with locking side of nut inwards). Replace the carburetter nuts, with the two petrol pipe clips, and tighten evenly.

Reconnect the rocker oil feed pipe.

Refit the bell mouths, but before tightening the lock rings, check that the pegs on each clip are correctly located in the carburetter slots.

Replace the tank making sure that the single fixing stud is central with the tank fixing hole. Fit the bush, large washer, rubber bush and second large washer on to the stud and secure with nut.

Refit the rubber plug into the tank fixing hole and reconnect petrol pipes to taps.

COMPRESSION PRESSURES

The table below gives compression pressures for engines in good condition taken at starter cranking speed with both plugs removed, throttle fully open and engine hot.

Taken with Crypton BX.35 gauge.

MODEL		COMP. RATIO	FIRST KICK	AVERAGE
650 c.c.	...	7.5 : 1	65-70	120/125
650 c.c.	...	9.0 : 1	65-70	140/145
500 c.c.	...	8.5 : 1	65-70	135/140
500 c.c.	...	9.0 : 1	65-70	150/155
650 c.c.	...	10.5 : 1	80-85	180/185

Figures quoted are in pounds per square inch. To obtain grammes per square centimetre, multiply by 70.3.

If readings obtained are substantially below those quoted the engine concerned is in need of attention to valves, rings or possibly a rebore.

REMOVING THE ENGINE UNIT

During the process of removing the engine unit keep careful watch for any nuts or bolts which have been loose and chafing, such parts are no longer safe and should be replaced. Examine the wiring for places where the insulation may have rubbed through and protect with a few turns of insulating tape.

Remember a bare wire can cause an electrical short-circuit which can set the machine on fire.

Proceed as for decarbonising described on pages B.5 to B.6, but do not remove the rocker box cover at this stage.

FOOTRESTS

The left-hand footrest is secured by a washer and nut which has a left-hand thread. Unscrew the nut, turning clockwise, remove the washer and give the footrest a sharp blow with a mallet to release it from its taper.

The right-hand footrest is secured to the frame in a similar manner but in this case the nut has the conventional right-hand thread.




FIG. B.19 Removing footrest nut.

CHAINGUARD

With quick-release hubs the lower rear bolt is extended to secure the rear brake anchor strap in addition to the chainguard.




FIG. B.20. Removing chainguard.

Take off the self-locking nut, washer and distance piece then the two Philips head screws to remove the chainguard. Replacement is the reversal of the above, but, if the self-locking nut can be screwed up with the fingers it should be replaced.

REAR CHAIN

After removing the chainguard, disconnect the rear chain by removing the spring link and run the chain off the gearbox sprocket. Disconnect the generator leads at the couplings and remove the low-tension wires from the terminals on the coils. Battery ignition, single and twin carburetter models will require the left-hand coil to be removed.

Models with "energy transfer" ignition system, where both coils are immediately above the gearbox will require both coils removed, as they are attached to the top engine mounting plate bolt, they can be removed at the same time as this bolt.




FIG. B.21. *Generator couplings.*

CLUTCH CABLE

To remove the clutch cable at the lower end, pull back the rubber cover to expose the cable connections. Pull back the cable and take out the

short slotted abutment, this will allow the long abutment to be pulled back exposing the cable nipple which can then be removed from the connector.

To disconnect the cable at the handlebar lever, screw the adjuster right home, take off the lever fulcrum pin nut and remove the pin, slip the lever off the bracket and prise out the cable nipple.

The cable and adjuster can then be removed from the bracket.

Replacement of the cable is imply the reverse of the above procedure but, when replacing the lever fulcrum pin, be careful to adjust the pin so that the lever is free to move yet not so loose as to cause a rattle.

REV-COUNTER CABLE

To disconnect the rev-counter cable (when fitted) from the front of the timing case, simply unscrew the outer casing nipple and pull out the inner cable.

OIL DRAINING

Unscrew the oil filter from the oil tank and drain into a suitable receptacle. Replace the filter when the tank is empty.




FIG. B.22. *Oil pipe connection.*

Remove the single $\frac{1}{8}$ in. bolt which holds the oil feed and return pipes to the underside of the crankcase. On this joint there are two rubber seals which must be sound and unbroken. Seals which have softened and swollen should be replaced. Do not use jointing cement.

MOUNTING BOLTS

The engine/gearbox unit is now held solely by its mounting bolts.

Unscrew and remove the two nuts and washers securing the rear engine plates to the frame. Drive the bolts out towards the right-hand side leaving the plates attached to the engine but, slacken off the engine plate crankcase bolts.

Remove the front mounting bolt and the long bolt underneath the crankcase. This latter bolt usually has a packing washer inserted between the crankcase and the frame, take note of its position.

The unit will now be free and ready to be lifted out. To do this tilt the engine forward so lifting the rear upwards and the front downwards, then twist the unit and lift out on the left-hand side complete with the rear engine plates.




FIG. B.23. *Engine loose.*

REPLACING THE ENGINE UNIT

Having completed the overhaul of the engine/gearbox unit, it should be complete with kick-start and footchange levers and rear engine plates loosely fitted.





FIG. B.24. *Positioning the engine.*

Lift the unit into the frame from the left-hand side and position the front mounting lug below the frame lug and the rear mounting above the frame lug, then lever the mountings into position. Insert the mounting studs with washers and nuts through the front lug then the rear lug (refit energy transfer coils if applicable) and finally the bottom lug. Do not omit the packing piece which is usually on the lower engine bolt between the frame and the crankcase. Replace the nuts and washers and make absolutely tight. Replace the engine steady-stay to the front of the cylinder head.

Connect the rocker box oil feed pipe to its union at the rear of the cylinder head and then the oil feed and return pipes to the crankcase and oil tank. To ensure that the crankcase connection is oil-tight see that the two rubber seals are in good condition, they do not require jointing cement. "Loctite" cement should however


FIG. B.25. *Engine steady bolt.*

be used on the threads of the centre bolt to ensure that the bolt does not work loose.

Feed the clutch cable through the frame clips (or replace it) pass the nipple and adjuster through the handlebar bracket, then insert the nipple into the lever and secure the lever with the fulcrum pin and nut. Adjust the cable as necessary.

On battery ignition models the coils can now be replaced.

Reconnect the generator leads ensuring that the colours are correctly matched and replace the low-tension wires on to the coils. The black/


FIG. B.26. *Coil connections.*

yellow wire to the (+) positive terminal on the right-hand coil and the black/white wire to the (+) positive terminal on the left-hand coil.

Replace the rear chain with the closed end of the connector link spring facing the direction of chain travel and refit the chainguard.

See that the self-locking nut on the brake anchor strap bolt, which also secures the chain-guard is absolutely tight.

See that the O-ring(s) is/are in position in the carburetter(s) and that the insulating block or blocks are undamaged.

FIG. B.27. *Chain link.*

Note that O-rings are not used on model A65 Spitfire Mk. II Special.

Replace the carburetter(s) using a new gasket for each side of the "tufnol" washer.

Do not over-tighten the carburetter flange nuts, such action can result in a buckled flange and subsequently an air leak.

For details on remote float chamber fixing for model A65 Spitfire Mk. II Special, see page C.20.




FIG. B.28. Carburetter joint.

Press the exhaust pipes well down into the exhaust ports, replace the silencers and secure to the brackets at the front and rear of the frame.

On models fitted with twin or straight through pipes on each side of the machine the front tie rod is fitted last. At the rear fastening the longest distance piece is on the left-hand side.

Replace the left-hand footrest which is secured by a washer and nut having a left-hand thread.




FIG. B.29. Exhaust pipe bolt.

If the right-hand footrest has been lowered this can be replaced, but this time the nut has the normal right-hand thread.

Replace the petrol tank, position the holding-down bolt in the centre tube, then press the tank down on to the mounting rubbers and secure with the large diameter washer and nut. If a steel tank is fitted, replace the anti-roll bar underneath the tank, ensuring that it is correctly fitted and not being strained.

Replace the carburetter air filter or filters, reconnect the fuel pipes, and after completing the assembly of the sidecovers etc., refill the oil tank, primary drive case and gearbox.




FIG. B.30. Stop light switch.

Before starting the motor or turning on the fuel supply, turn the engine over several times by means of the kickstart, to prime the oil pump and start the oil circulating.

TRANSMISSION

Power from the engine is transmitted through the engine sprocket and primary drive chain to the clutch chainwheel, thence via the clutch driving and driven plates to the shock absorber unit and

the gearbox mainshaft, through the gearbox to the final drive sprocket, the rear chain and rear wheel.

The shock absorber unit, as its name implies, is necessary to smooth out the drive as the power impulses fluctuate.

The clutch not only provides a means of stopping and starting the machine without stopping the engine, but also provides a means of changing from one gear ratio to another smoothly.

Thus it will be evident that the satisfactory functioning of one part of the system is very often dependent on another part. In other words if one part is worn or faulty it can very often prevent other parts from working properly.

The dismantling and reassembly of the primary drive can be carried out if necessary without removing the engine unit, but will be treated in this case as though the unit were on the bench.

PRIMARY DRIVE COVER

Take out the twelve screws securing the primary chaincase outer cover, two of these, which have aluminium washers under the heads are the oil level and drain screws. If the joint has not already been broken to release the oil, break it by tapping the cover gently with a hide-mallet and remove the outer cover, but have a receptacle underneath to catch the oil.




FIG. B.31. Primary cover.

CLUTCH DISMANTLING




FIG. B.32. Clutch exploded.

Unscrew the three spring nuts which have the normal right-hand thread. Some of these may be difficult because there is a projection on each nut to prevent it working loose and it may be necessary to destroy the spring in the process of removal.

Take out the nuts, springs, pressure plate, driving and driven plates and pull out the clutch push rod.

To unscrew the clutch centre nut it will be necessary to lock the chainwheel and centre

together with service tool No. 61-3768 and to support the connecting rods with a bar through the small-end bushes, resting on hardwood pads on the crankcase to avoid damage.

Unscrew the nut which has a right-hand thread, take off the self-locking nut, and distance piece but do not attempt to remove the chainwheel at this stage.

Slacken off the chain tensioner adjusting screw until the tensioner blade is completely free from the chain.

GENERATOR

The generator comprises the rotor which is the circular component fitted to the engine mainshaft and the stator which is mounted on three studs around the rotor, both being dealt with in the electrical section.

To remove the clutch chainwheel, chain or engine sprocket, however, the generator must first be removed.

Flatten the tab washer under the crankshaft nut and using the bar through the connecting rods, unscrew the nut which has a right-hand thread.

Do not omit to use the hardwood pads on the crankcase face to avoid damaging the joint face.

Take off the three stator plate self-locking nuts being careful not to damage the windings of the




FIG. B.33. *Removing clutch.*




FIG. B.34. *Crankshaft key.*

coils, and pull the stator plate off the studs. Later models have a housing fitted over the stator studs secured by locknuts. On 1968 models the housing is part of the crankcase.

Pull off the rotor to expose the engine sprocket and take out the engine shaft key (if fitted). Machines fitted with energy transfer ignition equipment have a timing disc between the rotor and the engine sprocket, the disc can be removed with the rotor. There is no key on these models.

The engine sprocket, primary chain and clutch chainwheel must be removed together. Free the clutch sleeve with service tool No. 61-3766 then withdraw all the components together. If the engine sprocket is tight, it can be drawn off the shaft with service tool No. 61-3676, and two bolts $\frac{1}{4}$ in. by 26 t.p.i. by 3 in. long.

INSPECTING THE CLUTCH

The clutch on the 1966/7/8 models is completely new, the clutch sleeve key being the only interchangeable part with earlier models.

The driving plates have segments of special friction material bonded to the metal, these segments should all be complete, unbroken and not displaced.

The tags on the outer edge should be a reasonable fit in the chainwheel slots and not hammered up. If there are burrs on the tags, or the segments are displaced, the plates should be replaced. Even if there is no apparent wear or damage the overall thickness of the plate and segments should be measured and if the extent of the wear is more than .030 in. (.75 mm.) the plate should be replaced.

Standard thickness is .140—.145 in. (3.556—3.683 mm.).

The plain driven plates should be free from score marks and perfectly flat. To check the latter lay the plate on a piece of plate glass. If it can be rocked from side to side it is buckled and should be replaced.

SHOCK ABSORBER

To inspect the shock absorber rubbers which are inside the clutch centre, take out the three countersunk head screws adjacent to the clutch spring housings and prise off the retaining plate.

The rubbers should be quite firm and sound, if there is any tendency for the rubbers to disintegrate they should be replaced. To remove prise out the smaller rebound rubbers first. When refitting do not use oil or grease, if lubricant is required it is better to use a liquid soap.

CLUTCH CHAINWHEEL

Examine the slots for wear, if they are corrugated or the teeth are hooked and thin, the chainwheel should be replaced. Check the chainwheel bearing for up and down play, slight play is permissible otherwise the bearings should be renewed.




FIG. B.35. *Primary case back plate.*

GEARBOX OR FINAL DRIVE SPROCKET

Access to the gearbox sprocket can only be obtained when the clutch is removed. Take out the six screws holding the circular plate at the back of the primary case, break the joint and remove the plate which also carries an oil seal. Look for signs of leakage down the back of the cover, if leakage is evident change the oil seal taking care to see that it is fitted the correct way round with the lip of the seal to the inside of the chaincase.

To change or renew the sprocket, flatten the tab washer, place a length of chain round the sprocket and lock in a vice or with a suitable bolt and unscrew the sprocket nut which has a right-hand thread.

When the nut and tab washer are removed the sprocket can be pulled off its splines. If there has been oil leakage from the back of the sprocket it indicates that the gearbox oil seal requires renewal. This can be done but great care is necessary when fitting the replacement.

If the sprocket boss is worn this also will require replacement.

Fitting a new seal on its own would be useless as the old sprocket would ruin the new seal.

If the sprocket boss is smooth and not scored it can of course, be refitted but it must be lightly oiled to avoid damaging the seal as the sprocket is pressed home. Reassembly is in the reverse order but do not omit to turn the tab washer over the nut after tightening.

CLUTCH OPERATION

As already indicated, the clutch being part of the transmission system transmits power to the rear wheel, and by separating the driving and driven plates this connection is broken. This is done by pulling the left-hand handlebar lever towards the rider, the force imposed is transmitted via the clutch cable to the clutch lever in the timing-side case, thence by means of the push rod in the hollow gearbox mainshaft to the clutch pressure

plate, so compressing the clutch springs and freeing the plates.

To ensure the smooth operation of the clutch it is essential that the spring pressure is equal and the pressure plate runs true. Adjustment for the cable is provided at the handlebar lever and at the clutch pressure plate.

REASSEMBLING THE PRIMARY DRIVE

Replace the circular cover at the back of the primary case using jointing cement on one side only of the paper gasket.

If the clutch chainwheel has been removed from the sleeve, grease the roller track, assemble the 20 rollers and slide the chainwheel over the rollers.




FIG. B.36. Cush drive.

Of the six cush drive rubbers the three thick driving rubbers are fitted on the right-hand side of the centre vanes and the three thin rebound rubbers are on the left-hand side, the outer plate being secured by three countersunk head screws.

Insert the spring bolts from the rear and slide the assembly into the chainwheel.

Pass the stator leads through the back of the primary chaincase and press in the cable guide, if it has been removed. Secure with "Loctite" or jointing cement.

NOTE:—It is easier to do this operation at this stage rather than after the chain and sprockets are fitted.




FIG. B.37. Clutch chainwheel.

Make sure that the crankshaft distance piece is in position behind engine sprocket. This distance piece is of a standard size, therefore if chain alignment should need adjustment there are shims available of .010 in. and .020 in. thicknesses. These should be fitted as required.

With both the clutch chainwheel and the engine sprocket lying on the bench, place the chain round both, pick up engine sprocket, chainwheel and chain, pass the stator plate through the chain and slide both sprockets and chain over the shafts at the same time.




FIG. B.38. Fitting primary drive.

Secure the clutch by replacing the distance piece, recessed side outwards, then secure the self-locking nut tightened to torque wrench settings quoted on page GD.31.

On models fitted with "energy transfer" ignition equipment the timing disc is fitted next to the engine sprocket with the peg facing outwards at approximately 9 o'clock and the piston at top dead centre.

The rotor for these models has two holes at the rear, the one marked "S" is used for both A50 and A65 models. Locate the peg in the appropriate hole and secure the rotor with its nut and washer turning the washer on to the nut after tightening.





FIG. B.39. Fitting the rotor.


On models with battery ignition equipment, replace the woodruff key in the crankshaft, replace the rotor and secure with nut and washer tightened to torque wrench settings quoted on page GD.31.

Slide one segmented driving plate into the clutch chainwheel then one plain plate and so on, until all the plates are assembled, there being six of each.

Insert the clutch push rod into the hollow gearbox mainshaft (if it has been removed) and replace the pressure plate, spring cups, springs and nuts. It is essential that the spring nuts are tightened evenly to keep the plates parallel. Normal setting is for the outer face of the nut to be flush with the end of the stud.


FIG. B.40. *Adjustment of the primary chain.*

Check the accuracy of the spring setting by pulling the clutch lever and rotating the pressure plate by means of the kickstarter. Any unevenness should be taken out by re-adjustment of the appropriate springs.

FIG. B.41. *The primary chaincase oil level.*

Place the stator over the three studs so that the leads are on the outside at approximately 2 o'clock and replace the three self-locking nuts, tighten with torque wrench to figures on page GD.31.

It is important that the air gap between the rotor and stator is equal so, if there is any variation due to the studs having been displaced, the studs should be very carefully set over. The gap can be checked with feeler gauges between the stator pole pieces and the rotor. The gap should be no less than .015 in.

FIG. B.42. *Adjusting clutch springs.*

Replace the chain tensioner and adjust the chain so that there is slight up and down movement on the top run of the chain, no more than $\frac{1}{8}$ in.

Apply jointing cement to both faces of the chaincase and, using a new gasket, replace the cover tightening the screws evenly to avoid distortion.

See that the oil level and drain screws are correctly positioned on the lower run with aluminium washers under the heads of the screws.

THE CONTACT BREAKER

The contact breaker assembly is contained in a circular compartment in the inner timing cover on the right-hand side of the machine, its circular cover forming part of the outer timing cover.

The assembly comprises the contact breaker plate on which are mounted the two sets of contacts and two condensers (capacitors).




FIG. B.43. Contact breaker unit (1966/7).




FIG. B.43A. Contact breaker unit (1968).

Underneath the contact plate is the automatic-advance and retard assembly comprising two bob-weights and springs and the contact breaker cam. This assembly is locked into the tapered hole in the idler pinion by its central bolt.

Oil is prevented from reaching the assembly by an oil seal set in the back of the housing.




FIG. B.44. Auto-advance mechanism.

When the engine is first started the ignition is in the retarded position because of the two springs which are holding the two bob-weights and the cam. This makes starting easier and prevents "kick-back" on the kickstart lever.

As the engine revolutions increase, centrifugal force carries the bob-weights outwards and this in turn progressively turns the cam and advances the ignition.

The elongated holes in the contact plate enable the plate to be moved to right or left, so providing a means of fine adjustment for ignition timing.

To obtain access to the contact breaker take out the two screws holding the circular cover to the outer timing cover.

REMOVING THE CONTACT BREAKER

Before removing the two screws holding the contact plate, scribe a mark on the plate and housing to assist in reassembly, otherwise it will be necessary to re-time the ignition. The plate can be removed, complete with contacts and condensers after the two bolts are removed.

To remove the auto-advance unit and cam it is necessary to take out the centre bolt, the unit can then be freed from its taper with service tool No. 61-5005.

This tool is screwed in until resistance is felt, further screwing will then release the assembly.

Do not however, remove the auto-advance unit unnecessarily as the timing will have to be reset, this is detailed on pages B.50-53.

To change a set of points unscrew and remove the barrel nut inside the C-shaped spring and remove the nut holding the spring and lead to the condenser, lift off the movable contact, fibre washer, then the fixed contact (see Fig. B.43).

Replacement is in the reverse order but do not omit the fibre washer between the contacts on the pillar or the insulating strip from the condenser, this is fitted over the terminal and before the spring or the lead (see Fig. B.43).

After changing a set of points revolve the engine until the fibre heel is on the peak of the cam, slacken off the contact plate screw and move the fixed contact point in or out to obtain the correct gap of .015 in. (.381 mm.).

Re-check the timing.

TIMING-SIDE COVER

To obtain access to the timing gears or the gear-box internals, it is necessary to remove the covers on what is known as the timing or gear-side, that is the right-hand side of the machine.

Take off the kickstart and footchange pedals, take out the three screws retaining the outer cover and remove the cover complete with the contact breaker cover.

This now reveals the contact breaker unit, kickstart return spring, clutch lever and foot-change return spring.

The clutch cable connector can remain on the lever unless it is to be renewed.

Take out the clutch lever ball and pull off the kickstart return spring and anchor plate.




FIG. B.45. Gear-side cover.

There is a grub or set-screw securing the foot-change return spring stop plate, this screw must be slackened off before the plate can be pulled off the gearchange quadrant spindle.

INNER TIMING COVER

Revolution Counter

If the machine is equipped with a revolution counter (or tachometer) remove the two bolts holding the cable connection to the front of the timing cover, remove the connector and pull out the revolution counter drive spindle.

The inner timing cover can now be removed. Take out the eight screws round the outer edge, two in the centre and one under the clutch lever, but do not remove the slotted screw at the rear, this is the kickstart spring anchorage.




FIG. B.46. Removing inner cover.

Tap the cover gently with a hide-mallet round the edges to break the joint and pull off the cover complete with the clutch lever leaving the kickstart and footchange spindles in position.

The clutch lever pivot post is retained by a single nut and washer on the inside and need not be disturbed.

The gearchange selector quadrant and kickstart quadrant are simply push-fits into the gearbox cover and can be withdrawn quite easily although it may be necessary to depress the quadrant plungers first.




FIG. B.47. Inner cover screws.

TIMING GEAR AND OIL PUMP

Oil Pump Removal

Removal of the inner timing cover exposes the oil pump, timing gears, kickstart ratchet assembly and gearbox outer cover.

Flatten the tab washer under the crankshaft nut, unscrew the nut which has a left-hand thread, then unscrew the oil pump worm-drive which also has a left-hand thread and is therefore turned in a clockwise direction to unscrew.

To remove the oil pump, unscrew the two nuts and remove the washers from the main body of the pump. Flatten the tab washer under the other nut and unscrew the nut.




FIG. B.48. Crankshaft nut.

As the pump is removed it will release the oil feed non-return valve ball and spring which are fitted into the crankcase behind the pump.

It is not advisable to dismantle the oil pump unless it is suspected that there is some fault or possible damage. Internal damage can occur if the periodical oil changes have been neglected.

Dismantling and reassembly is described on pages A.9-10.

REPLACING THE PUMP

Take out the oil pump studs, and ensure the faces are clean, apply a smear of grease to a new gasket and place the gasket in position on the crankcase face. Insert the non-return valve spring, apply a dab of grease to the countersunk hole in the joint face of the pump and press the ball into the grease, position the pump carefully and screw in the studs securing the nuts equally to avoid tilting the pump.

If the engine is being completely dismantled the pump will of course be left off until the engine is rebuilt.




FIG. B.49. Oil pump non-return valve.

TIMING GEARS

Careful examination of the timing gears will show that there are marks on the faces of the gears adjacent to the gear teeth.

These marks are to assist in the correct re-assembly and it is good practice to familiarise oneself with them before removing the gears (see Fig. B.50).




FIG. B.50. Timing marks.




FIG. B.51. Removing pinion.

Take off the crankshaft distance piece then pull off the pinion using extractor No. 61-3676.

The idler pinion is simply a push-fit in the case and can be withdrawn without a tool.

To unscrew the camshaft nut it is necessary to leave the gears in position and lock the assembly with a bar through the connecting rods. Great care must be taken to avoid damaging the crankcase.

Having locked the assembly, flatten the tab washer, unscrew the nut, and withdraw the cam-

shaft pinion with extractor No. 61-3676.

Take out the woodruff key.

Replacement of the timing gear is simply the reversal of the above procedure except that care must be taken to match the timing marks as the idler pinion is inserted last into the case.

GEARBOX DISMANTLING

If the purpose of dismantling is to obtain access to the connecting rods or flywheel assembly there is no need to remove the gear cluster unless the assembly is suspect.

The gearbox internal cluster can be removed without interfering with the timing gears but the clutch must be removed first (see pages B.21—26).

Take off the five $\frac{1}{16}$ in. B.S.C. nuts and spring washers holding the gearbox end cover, break the joint with a hide-mallet, and remove the cover complete with the gear cluster, cam-plate and selector forks.

Take out the fulcrum pin then remove the cam-plate, selector forks and shaft.

Pull out the layshaft and remove the sliding pinion (layshaft third gear), first gear and kick-start quadrant.

To remove the mainshaft, grip the shaft in a vice using soft metal clamps, flatten the tab washer under the kickstart ratchet nut, unscrew and remove the nut and take off the ratchet, ratchet pinion, spring, bush and thrust washer.

The mainshaft complete with its gears can now be driven out of the cover bearing.

After taking off the sliding pinions both shafts are left with two gears, the mainshaft first and third gears and the shorter layshaft with its top and second gears.




FIG. B.52. Removing cluster.

In both cases the smaller gear is a press-fit on to the shaft so retaining the larger gear which has a thrust washer between it and the end of the splines.

If it is necessary to change either of these gears the shaft must be pressed out of both gears at the same time, an operation which requires a good press properly mounted on bench or floor.

When examining the various bearings and bushes for wear do not overlook the phosphor-bronze bushes in the layshaft first gear and the mainshaft top gear, this gear is at this point still in the gearbox.

The layshaft has needle roller bearings at each end, one in the back of the box and one in the end cover. Both can be driven out with a suitable size drift.




FIG. B.53. Gear cluster exploded.

The mainshaft has ball journal bearings at each end. To remove the left-hand bearing the gearbox sprocket must be removed (see page B.23) then the top gear pinion is driven through, into the gearbox, the oil seal prised out from the outside and the circlip removed. The bearing can then be pressed out from inside the gearbox, but before any bearing or bush is removed from an aluminium case, the case should be heated, the bearing pressed out and the replacement pressed in while the case is still hot.

The right-hand mainshaft bearing can be removed from the cover, pressing from the inside, after the circlip is removed.

When examining the gears look for cracked, chipped or scuffed teeth, the latter will show (if present) on the thrust faces of the teeth and in severe cases might even have broken through the case hardening.

Check the cam-plate for wear in the cam-track by offering up the selector forks and check the gear notches at both ends. At the large end look for burrs and at the small end for wear on the edges of the slots.

The plunger at the back of the box must be quite free in its housing and the gearchange quadrant plungers must not be chipped or worn on the toothed end and again must be quite free in their housings. Any damage to these parts will make good gearchanges impossible.





FIG. B.54.

GEARBOX REASSEMBLY

It will be assumed that all bearings, bushes or oil seals have been replaced as necessary.


Press the mainshaft through its bearing in the outer cover ensuring that the distance piece is in position between the bearing and the small gear. Grip the shaft in a vice using soft metal clamps and replace the kickstart ratchet gear washer, bronze bush, spring, ratchet pinion, ratchet, tab washer and nut in that order. Turn the washer over the nut after tightening with torque wrench to figures quoted on page GD.31.

FIG. B.55. *Kickstart ratchet.*

The mainshaft being locked to the cover bearing does not need checking for end float but the layshaft has thrust washers at each end, it must therefore be assembled into the case with the low gear pinion and standard thrust washer (.113—.115 in.) at each end when there should be just perceptible end float. If the end float is excessive there are two thicker washers available (.120—.122 in. and .127—.129 in.) which should be used at the sprocket end.

Having checked the layshaft end float the cluster can be assembled on to the end cover.


Clean all jointing compound off the joint faces in readiness for the assembly.

FIG. B.56. *Selector forks.*

Note that whilst the mainshaft (second) and layshaft (third) sliding gears are interchangeable (with standard ratios) the selector forks are not. The latter can be identified thus: with forks on the shaft and both rollers below the shaft as in Fig. B.56, the layshaft fork is on the left and the mainshaft fork on the right.

Place one of the standard thrust washers in position on the inside face of the cover, position the layshaft first gear with the dogs facing inwards and insert the layshaft complete with its sliding gear second and top gears.

Position the layshaft selector fork, slide the mainshaft sliding gear on to the shaft and position the mainshaft selector fork.

FIG. B.57. *Assembling the gears.*

Insert the cam-plate through the slot in the cover with the long end of the outer track at the bottom. Fit the cam-plate fulcrum pin and insert the selector fork spindle.

If the mainshaft top gear has not already been fitted, press the gear through its bearing, replace the gearbox sprocket and secure with the lock-nut and tab washer.

See that the cam-plate plunger and spring are in position at the back of the gearbox.

Pick up the gearbox outer cover complete with the gear cluster, place the other thrust washer over the end of the layshaft and slide the whole assembly into the box.




FIG. B.58. *Inside the box.*

To facilitate the meshing of the top gear pionsins revolve the shafts gently. Secure the cover with the nuts and washers when the cover is right home.

Do not attempt to force the cover home.

Position the cam-plate midway in the slot and insert the small end of the gear selector quadrant into the small hole in the cover at the same time engaging the quadrant plunger in the cam-plate.




FIG. B.59. *Cluster assembled.*

Place the small end of the kickstart quadrant into the steel bush on the left-hand side of the cover before replacing the inner timing cover.




FIG. B.60. *Fitting the selector.*

SEQUENCE OF GEAR CHANGING

To understand this description of the gear changing sequence, it is necessary to refer to the various drawings and to understand some of the terms used.

- (1) CAM-PLATE---this is the large fan-shaped part with notches at one end and windows at the other end.
- (2) LARGE PLUNGER---this operates at the large end of the cam-plate to locate the gear positions.
- (3) SELECTOR PLUNGERS---these operate at the small end of the cam-plate in the "windows."
- (4) SELECTOR FORKS---these only show as small spots in the wavy cam-tracks at the large end of the cam-plate. They are the rollers which move the selector forks up and down the tracks.
- (5) SLIDING GEARS---there are two gears in the box which move along the splined shafts. These are operated by the selector forks, there being one on each shaft.

The gears must always be in the neutral position for starting the engine, this is the position shown in Fig. B.60A.

The large plunger is holding the cam-plate by the second notch. At the other end of the cam-plate the selector quadrant plungers are compressed ready to operate either way the pedal is moved.

When the pedal is moved down, to engage first gear, the plunger will enter the cam-plate and move it to first gear position, this in turn will operate the layshaft selector fork and will mesh the layshaft sliding gear with the layshaft first gear.

Reference to Fig. B.60B will now show the quadrant plunger in the second window ready to move the cam-plate from first to second gear.


This time the cam-plate moves in the opposite direction and again operates the layshaft selector fork moving the layshaft sliding gear in the opposite direction to mesh with the second gear.

Reference to Fig. B.60C will show two quadrant plungers in the cam-plate windows ready to move the gears from second to first or neutral or back again.

When the cam-plate is moved to third gear position as will be seen by reference to Fig. B.60D, the action moves both selector forks, drawing the layshaft sliding gear to a neutral position and moving the mainshaft sliding gear into mesh with the mainshaft third gear. Again the quadrant plungers are ready to move the gears either way.

Finally, the move into fourth or top gear (Fig. B.60E) operates the mainshaft selector fork only, again sliding the gear the opposite way to mesh with the sleeve pinion. After each movement of the gearchange pedal the quadrant returns to a static position so that the plungers are ready to operate the cam-plate. The large plunger at the large end of the cam-plate is the positive gear location and it also serves to steady the cam-plate whilst the quadrant plungers are returning to their static position.

SEQUENCE OF GEAR POSITIONS

SELECTOR AND CAMPLATE
IN NEUTRAL POSITION

NEUTRAL POSITION




FIG. B.60A.

SEQUENCE OF GEAR POSITIONS




FIG. B.60B.

SEQUENCE OF GEAR POSITIONS



SELECTOR AND CAMPLATE
IN SECOND GEAR POSITION2ND GEAR

FIG. B.60c.

SEQUENCE OF GEAR POSITIONS





FIG. B.60D.

SEQUENCE OF GEAR POSITIONS




FIG. B.60E.

SPLITTING THE CRANKCASE

Before attempting to part the two halves of the crankcase all the timing gear must have been removed as detailed on pages B.28-30 and the primary drive gear as detailed on pages B.21-24.

It is not absolutely necessary to remove the gear cluster but, since the work already involved constitutes a major operation it is sometimes good policy to examine the gears at the same time. Removal and replacement of the gear cluster is detailed on pages B.31-35.




FIG. B.61. Crankcase bolts (1966/7).




FIG. B.61A. Crankcase showing new stator fixing (1968).

Remove the nuts and washers from the two bolts (A) at the lower front of the case, the two bolts (B) at the upper front and the three studs (C). Fig. B.61.

There is also one nut and washer on the bridge piece across the mouth of the crankcase.

Take off the four nuts holding the sump filter and remove the filter.

There is no need to disturb the oil pump scavenge valve which is now exposed, unless it is known to be defective but, care must be taken during subsequent handling to avoid damage.




FIG. B.62. Scavenge valve.

Remove any woodruff keys which may still be in the shafts noting their particular locations, break the joint by tapping gently with a hide-mallet and take away the gear-side half-case. Do not attempt to prise the two halves of the case apart using a screwdriver or other tool between the joint, this will only damage the joint faces and result in oil leakage.

CAMSHAFT

The camshaft can now be removed, it may come away with the breather valve and spring or these parts may remain behind the camshaft bearing in the drive-side half-case.

The breather is of the rotary disc valve type, the rotating half being driven off the end of the camshaft and the static half being secured by a peg at the base of the drive-side camshaft bearing. The bearing must be removed to gain access to the static half.

Examine the peaks of the cams for wear or scuffing. If the peaks are worn the valves will not open completely and the camshaft should be replaced.




FIG. B.63. *Camshaft and breather.*

The crankshaft assembly can now be removed and placed to one side.

CRANKSHAFT ASSEMBLY




FIG. B.64. *Removing connecting rod.*

Removal of the connecting rods from the crankshaft is quite straight forward but, the rods, bolts and caps must be marked so that they can be replaced in the same positions if they are being used again.

If the crankshaft is to be reground it is essential that the correct regrind sizes are used to suit the undersize big-end bearing shells and gear-side bush.

There are three undersize bearing shells available but only two gear-side bushes.




FIG. B.64A. *Connecting rod assembly.*

CRANKSHAFT GRINDING


It will be necessary to regrind the bearing surfaces if the overall wear of the crankpins or gear-side journal exceeds .002 in. or if the surfaces have been damaged by seizure. Worn bearings will develop a distinct "knock" and the engine will become generally very rough.

GEAR-SIDE JOURNAL.

Shaft No. 68-734

Grind journal to: 1.4885—1.489 in. with .050—.060 in. radius and use .010 in. undersize bush No. 68-647 or grind to 1.4785—1.479 in. with .050—.060 in. radius and use .020 in. undersize bush No. 68-648.


FIRST REGRIND



MARK CRANKSHAFT WEB FACE AS SHOWN

FIG. B.65.

SECOND REGRIND



MARK CRANKSHAFT WEB FACE AS SHOWN


FIG. B.66.

Reground crankshafts complete with big-end bearing shells and gear-side bush are available from the Service Department.

This service, only available to owners in the British Isles, is operated through the dealer network.


BIG-END JOURNALS

FIRST REGRIND




Grind the crankpins to 1.677—1.6765 in. dia. with .085—.090 in. face radius. Fit bearing shell No. 67-1431 (4 off) marked .010 in. undersize.

SECOND REGRIND



Grind the crankpins to 1.667—1.6665 in. dia. with .085—.090 in. face radius. Fit bearing shell No. 67-1432 (4 off) marked .020 in. undersize.

THIRD REGRIND



Grind the crankpins to 1.657—1.6565 in. dia. with .085—.090 in. face radius. Fit bearing shell No. 67-1433 (4 off) marked .030 in. undersize.

CRANKSHAFT SLUDGE TRAP

The opportunity should be taken while the crankshaft is out of the case (assuming it is being re-fitted) to clean the sludge trap.

To remove the trap, take out the end plug and the flywheel bolt on the crankpin side and tap the sludge trap out. The oilways should be thoroughly cleaned with paraffin and if possible blown out with a high pressure air line.




FIG. B.70. Removing the flywheel.

Flywheel bolts should be secured with a torque wrench set to the value quoted on page GD.31.




FIG. B.71. Sludge trap.

When replacing the sludge trap locate with the flywheel bolt first then screw in the end plug, all should be secured with "Loctite" seal or if this is not available the plug should be centre-punched into the thread to secure.

Should it be necessary the crankshaft balance can be checked using service tool No. 61-3710 for the 650 c.c. or tool No. 61-3711 for the 500 c.c. machines. Crankshaft balancing does however, call for the services of a skilled mechanic and should not be undertaken without access to precision workshop equipment.

FLYWHEEL BALANCING (STATIC)

For all general purposes the crankshafts and flywheel assemblies are sufficiently balanced when they leave the works.

There should be no need to re-balance when fitting new connecting rods or oversize pistons.

Flywheel balancing should not be undertaken except by an expert mechanic who has access to the equipment necessary.

The equipment required is a drilling machine with depth stop and knife-edge rollers as illustrated, the latter must be set up perfectly horizontal.

For balancing purposes a weight equivalent to 70% of the reciprocating weight is attached to each crankpin journal (see Fig. B.73), the crankshaft is then placed on the rollers and allowed to revolve until it stops, when a chalk mark is made at the lowest point.




FIG. B.72. Knife-edge rollers.

This procedure is repeated several times to ensure accuracy.

The next step is to find the amount of out-of-balance so, plasticine is applied to the rim of the flywheel diametrically opposite the heaviest point until the shaft remains stationary when placed in any position on the rollers.

The wheels must now be drilled at the heaviest spot to remove metal equal to the weight of plasticine.

Drilling must be carried out on the periphery of the flywheel and must be central and not deeper than $\frac{3}{16}$ in.

It is better to start with a small diameter hole, which can be opened out if necessary, rather than a large hole to then find that too much metal has been removed.




FIG. B.73.

BALANCE WEIGHTS

MODEL	TOOL NO.	NO. REQD.	WEIGHT
A65	61-3710	2	22 ozs. 14 drms.
A50	61-3711	2	21 ozs.

BEARINGS, BUSHES AND OIL SEALS

With the crankcase split the opportunity should be taken to examine and replace all bushes and bearings which may be worn or damaged.

Journal bearings should be checked for roughness indicating damaged balls, rollers or tracks.

Most bearings and bushes can be pressed out, and in, quite normally but the crankcase must always be heated first and well supported.

The blind camshaft bush in the drive-side half-case can be removed with service tool No. 61-3776 but the replacement bushes must be reamed in line to the sizes quoted on page GD.5. To do this the two half-cases must be bolted together after the bushes have been changed, they are then carefully reamed to the required size, unbolted

and the swarf very carefully removed by high pressure air line.




FIG. B.74. Gear-side bush.

When replacing oil seals they must be handled very carefully to avoid damaging the knife-edge of the seal and they must be pressed into the housing squarely, with the open side always towards that part which is to be sealed.




FIG. B.75. *Sleeve pinion bush worn by oil seal.*

Never reassemble a component which is deeply scored by the seal, to a new seal, it will be useless, the component should be replaced as well as the seal.

Figure B.75 shows sleeve pinion bush with groove worn by the primary drive case oil seal. This is a case where both components must be replaced.

Check all oilways to see that they are clear and see that the oil scavenging non-return valve in the base of the crankcase is quite free. If there is any possibility of sludge in the return pipe obstructing the ball, immerse the pipe in a container of petrol and allow to soak for a time.

REASSEMBLING THE CONNECTING RODS

Before refitting the rods to the crankshaft check for ovality in the big-end eye. Bolt the caps and connecting rods together without the shells to the torque wrench setting on page GD.31. If the ovality in the bore is in excess of .0004 in. the rod and cap should be replaced.

The need for cleanliness cannot be over emphasized, all parts should be clean and free from grit or rust. As the various parts are assembled all bearing surfaces should be coated with clean engine oil.

Place the bearing shells in both the caps and connecting rods. If the old shells are being refitted see that they go into their original positions. No scraping is necessary with these bearing shells and must not be attempted or damage will result.

Connect each rod in turn to its crank journal making sure that the marks on rod and cap correspond and that the rods are the right way round, insert the bolts and secure the new self-locking nuts with a torque wrench set to the value quoted on page GD.31.





FIG. B.76. *Using torque wrench.*

Maximum crankshaft end float must not exceed .003 in. (.0762 mm.). This is controlled by shims fitted between the inner race of the drive-side bearing and the crankshaft web. If the original shaft is being replaced it is only necessary to see that the shims are fitted.


FIG. B.77. *Crankshaft shim.*

When a new or reground crankshaft is being used, it must first be assembled into the case and the two halves bolted tightly together to enable the end float to be checked. If the float amounts to say .010 in. then two shims of .003 in. and .005 in. should be used leaving .002 in. end float.

At this point it is of great help to obtain a block or box measuring approximately 8 in. by 8 in. by 6 in. with a hole in the centre large enough to accept the drive-side end of the crankshaft.

REASSEMBLING THE CRANKCASE

Place the crankshaft assembly on the block or box with gear-side end in the block, see that the shims are in position on the drive-side end and place the drive-side half-case in position being careful to enter the bearing squarely and to ensure that it goes right home.

FIG. B.78. *Assembling drive-side.*

Reverse the assembly on the block and enter the rotary breather disc with the driving pegs uppermost, enter the spring and finally the camshaft carefully engaging the driving dogs in the end of the camshaft.

See that the thrust washer is in position on the gear-side shaft with the oil grooves next to the crank web.


Having previously cleaned off the joint faces, smear both faces with a thin coating of jointing cement, place the gear-side half-case in position and bolt the two halves together. There are four bolts at the front (two with nuts and washers) and four nuts with plain washers on studs, three inside the primary case and one on the bridge piece across the mouth of the case.

Check that both the crankshaft and camshaft rotate quite freely, if they do not, then the alignment is incorrect and the cause of the trouble must be found and rectified.

Camshaft end float does not matter at this stage, it will be eliminated when the pinion is fitted.

Replace the sump plate and filter using a new gasket cemented both sides.

Replace the woodruff key in the crankshaft and refit the crankshaft pinion with the timing mark on the outside.

FIG. B.79. *Testing for freeness.*


Replace the crankshaft distance piece then screw on the oil pump worm gear, this has a left-hand thread and is therefore replaced screwing anti-clockwise. Place the tab washer in position and secure with the nut which also has a left-hand thread, tighten with torque wrench to figures quoted on page GD.31.

Replace the oil pump as detailed on page B.30.

Replace the woodruff key in the camshaft and refit the camshaft pinion with the timing mark outside (flat face inside). Do not omit to turn the tab washer over the nut after tightening.

The idler pinion is now replaced so that the timing marks match with both the camshaft and the crankshaft pinions (see Fig. B.50, page B.30).

If the gear cluster has not yet been replaced it can now be assembled as detailed on pages B.33-35.

FIG. B.80. *Camshaft pinion.*


REPLACING THE INNER COVER

Fit the kickstart and footchange spindles and replace the inner timing cover using a new paper gasket cemented both sides. Secure with the eleven inner cover screws.

Check that the ball is in position in the clutch lever cup and that the cable connector is in position on the lever.

Press the gear selector return spring and stop-plate over the spindle together so that the plate engages fully on the two spindle flats and one end of the spring is lying each side the anchor pin.

Secure the stop-plate on the spindle with the small grub or set-screw.

FIG. B.81. *Auto-advance unit.*

NOTE:—The current type footchange quadrant and inner timing cover cannot be used on earlier models.

Replace the kickstart return spring and stop-plate winding the plate round to engage the flats on the spindle and so place the spring under tension.

If a rev-counter is fitted, replace the driving pin so that it engages with the oil pump spindle and

replace the cable nipple on the front edge of the case.

Replace the automatic-advance unit loosely, together with the contact breaker plate, and leave the retiming of the engine until later.

Replace the primary drive as detailed on pages B.24–26.

Replace the upper part of the engine as detailed for decarbonising on pages B.13–14.

IGNITION TIMING — WITH FLYWHEEL LOCATING PEG

INITIAL PREPARATION

Continue from the point reached during rebuilding of the engine unit (see page B.49) where the auto-advance and the contact breaker were left loosely assembled.

Remove both spark plugs if not already out

The simplest way to set the ignition timing, that is the point at which the compressed charge in the combustion chamber is ignited, is to set it statically.

Unfortunately, due to manufacturing tolerances this is not ideal because, whilst it will set the timing of the engine for tick-over speeds, the firing at wide throttle openings can be varied due to differences in the amount of automatic-advance.

The automatic-advance functions by centrifugal force acting on spring-loaded bob-weights and advances the ignition timing as the engine revolutions rise. Since exact timing accuracy is required at operating speeds it is better to time the engine in the fully advanced position so transferring any variations in the firing to the tick-over or low engine speeds when it can least affect the performance.

There is a plug included in the toolkit for setting the piston position to time the ignition in the fully advanced position.

This plug is used through the aperture on the right-hand front of the crankcase and it has two positions one for 500 c.c. models and the other for 650 c.c. models. All models however, now use the 500 c.c. setting marked "A50."

Remove the crankcase cover (A) Fig. B.82, and insert the peg with the A50 model number uppermost and using light finger pressure on the plug, turn the crankshaft slowly until the plug drops into the groove in the flywheel.

The engine can be turned by means of the kickstart lever but it can be done easier with both spark plugs out and in top gear by turning the rear wheel, if the engine is still in the frame.

Do not attempt to revolve the crankshaft whilst the timing plug is in position.

Having located the flywheel by means of the plug, check which cylinder is on compression stroke by examining the valves, if both valves are closed on the right-hand cylinder then the upper set of contacts should be used. For the left-hand cylinder use the lower set of contacts.




FIG. B.82.

Secure the contact breaker back-plate with the two screws midway in the slots.

Without moving the pistons and lightly pressing the auto-advance cam inwards, turn the cam until the upper set of contact breaker points are just about to open and secure the auto-advance unit by securely tightening the centre bolt.

After tightening revolve the cam to the limits of the auto-advance and check the fully open gap

which should be .015 in. (.381 mm.). If the gap has to be adjusted repeat the timing procedure to obtain the static timing. To adjust the gap slacken off the circular slotted nut inside the C-shaped spring adjacent to the points being adjusted.

Do not, at this stage, alter the back-plate screws.

Check the fully open gap of the lower set of points (left-hand cylinder).

PISTON POSITION BEFORE TOP DEAD CENTRE — FULL ADVANCE

ALL MODELS

.304 in. (7.216 mm.) = 34° crankshaft angle.

IGNITION TIMING — FULLY ADVANCED

Timing should always be set in the advanced position.

To check the opening of the contacts more accurately connect a battery and bulb in circuit with the points.

Attach one lead from the C-spring to the battery terminal, take another lead from the other battery terminal to a bulb then from the other side of the bulb to a good earth on the machine.

When the points open the light will go out. The leads must of course be changed to whichever set of points is being used.

(1) Having positioned the right-hand piston on the compression stroke (both valves closed).

(2) Slacken off the contact breaker back-plate screws. By holding the cam and turning anti-clockwise open the bob-weights to the fully advanced position, then still holding the cam turn the contact breaker plate so that the upper set of points are just opening. Lock the plate in this position and re-check the setting. There should be no change in the fully open gap setting.

(3) Position the left-hand piston the required distance before top dead centre on the compression stroke by turning the flywheel one complete revolution and re-inserting the timing plug.

(4) Now holding the cam in the fully advanced position check the opening of the lower set of points. This time do not move the back-plate but adjust the points gap to obtain the setting.




FIG. B.83. Battery and bulb in circuit.

To advance the spark open the points approximately .001 in. for each engine degree required and to retard close the gap. If the setting on the left-hand cylinder (or lower set of points) is say now .013 in. this figure should be recorded and always used when retiming.

It should not be necessary to alter the gap by more than .003 in. + or - to obtain correct timing.

The right-hand gap setting must, of course, remain at .015 in. (.381 mm.).




FIG. B.84. *Points just opening on left-hand cylinder (lower set).*




FIG. B.85. *Points just opening on right-hand cylinder (upper set).*

NOTE:—When checking the ignition timing with the engine in position in the frame the ammeter on the machine can be used in place of the battery and bulb, if the ignition switch is turned to ON, the needle will flick to zero when the points open, unfortunately the help of an assistant will be required to observe this. Also the piston position can be obtained more easily if top gear is engaged and the rear wheel is rocked backwards or forwards.

STROBELIGHT TIMING

Using the Stroboscope

If for some reason the ignition setting has been completely lost a basic static check and preliminary setting as detailed in preceding pages, must be made in order to facilitate engine starting for the strobe check.

To proceed, remove the large inspection cover in the primary chaincase cover to expose the

generator rotor, at the bottom of the aperture a pointer is pressed into a boss (on 1967/8 models only). Connect the strobelight to the battery or any suitable 6 volt or 12 volt battery and attach the high-tension lead to the right-hand spark plug. Start the machine and direct the light on to the generator rotor. If the ignition timing is correct, the pointer and the mark on the rotor will line-up when the engine is revved up to 2,400 r.p.m.

INDEX

	<i>Page</i>
CARBURETTER (EXPLODED DRAWING)	C 2
DESCRIPTION	C.3
DISMANTLING AND REASSEMBLING	C.3-4
INSPECTING THE COMPONENTS	C.4-5
HINTS AND TIPS	C.5-6
REASSEMBLING	C.6
TRACING FAULTS	C.6
VARIABLE SETTINGS AND PARTS	C.7
HOW TO TUNE (SINGLE CARBURETTER)	C.8-9
TUNING TWIN CARBURETTERS	C.9-11
CONCENTRIC CARBURETTER (EXPLODED DRAWING)	C.10
DISMANTLING AND REASSEMBLING	C.11
VARIABLE SETTINGS AND PARTS	C.12
G.P.2 GENERAL OPERATION	C.12-17
G.P.2 MIXING CHAMBER (EXPLODED)	C.13
SECTIONED G.P.2 MIXING CHAMBER AND FLOAT CHAMBER	C.17
G.P.2 TUNING SEQUENCE	C.71 18
ALCOHOL FUELS	C.18-19
G.P.2 REMOTE FLOAT CHAMBER (AND MOUNTING)	C.20
FLOAT CHAMBER SETTING	C.21




FIG. C.1. Carburetter exploded.

DESCRIPTION

All but one of the 500 c.c. (A50) and 650 c.c. (A65) models are fitted with the Amal monobloc, the only variation being on the A65 Spitfire Mk. II Special models which have twin G.P.2 carburetters. This only applies to 1966/7 models, all 1968 models are fitted with Amal concentric carburetters.

The monobloc carburetters both single and twin are as Fig. C.1 except that the twin carburetters now have the float chambers left or right-hand providing access to the throttle stops and pilot air screws.

The model A65 Spitfire Mk. II Special is fitted with two T10G.P.2 carburetters using a single remote float chamber.

The carburetter, because of its jets and choke bore, proportions and atomises just the right amount of petrol with the air that is drawn into the engine and provides a highly inflammable mixture which is ultimately burnt inside the cylinder head, hence the term "combustion chamber."

The float chamber maintains a constant level of fuel at the jets and incorporates a valve which cuts off the supply when the engine stops.

The throttle, being operated from the handlebar twist grip, controls the volume of mixture and therefore the power.

At tick-over the mixture supply is from the pilot jet system, then as the throttle is opened via the pilot by-pass, the mixture is augmented from the main jet, the earlier stages of which action is controlled by the needle in the needle jet.

The pilot system is supplied by a jet which is detachable for cleaning purposes and which, when assembled in the carburetter body, is sealed by a cover nut.

The carburetter also has a separately operated mixture control known as an air valve, for use when starting from cold, and until the engine is thoroughly warm. This control partially blocks the passage of air through the main choke and is operated from the handlebar.

The design of the carburetter is such that it provides quite simple and effective tuning facilities.

The main jet does not spray directly into the mixing chamber, but discharges through the needle jet into the primary air chamber, and goes from there as a rich petrol/air mixture through the primary air choke, into the main air choke. This primary air choke has a compensating action in conjunction with bleed holes in the needle jet, which serve the double purpose of compensating the mixture from the needle jet and allowing the fuel to provide a well outside and around the needle jet, which is available for snap acceleration.

DISMANTLING AND REASSEMBLING
THE MONOBLOC CARBURETTER

After removing the carburetter from the cylinder as described on page B.5 the procedure for dismantling is the same whether for single or twin except that twin carburetter air cables are connected to a junction box. Removal of the cable nipples from the junction box is quite simple and straight forward after the single cables have been disconnected from the lever.

First remove the throttle and air slides from the body by unscrewing the mixing chamber top cap, then withdraw the slides and throttle needle.

Remove the needle retaining spring clip, compress the slide return spring, then push the cable nipple down and out of the slide.

To release the air slide, compress the spring and slip the nipple out of the bottom of the slide.

Unscrew three slotted screws and withdraw the float chamber cover and remove the float spindle bush, the float, then withdraw the triangular section float needle.

Unscrew the banjo bolt which secures the fuel pipe banjo connector to the float needle seating block and withdraw the banjo, filter and junction washers. Unscrew the needle seating block. Unscrew the tickler body then withdraw the tickler and spring.

Remove the air screw and throttle stop screw, then the main jet cover nut from the bottom of the body. Unscrew the main jet, main jet holder and needle jet. To release the jet block re-insert the main jet holder, until a few threads are engaged then tap it with a hide-mallet. This will release the jet block through the carburetter body.

Unscrew the pilot jet cover, and unscrew the pilot jet. All that remains to be removed then is the hexagonal locating peg, the end of which can be seen protruding within the mixing chamber.

Thoroughly clean all parts in petrol (gasoline). Deposits on the carburetter body are best removed by a light grade wire brush. It is advisable to wash the parts several times each in a clean quantity of petrol, to avoid particles of dirt remaining. Allow the parts to drain, preferably using a jet of compressed air from such as a hand pump to ensure that all holes and drillings are free from blockage.

Inspect the component parts for wear and check that the jets are in accordance with the recommended sizes given in General Data.

Apart from one or two points that are mentioned below, reassembly is a reversal of the above instructions, referring to Fig. C.1 for guidance.

Do not replace any fibre washer that looks unserviceable. It is advisable to purchase replacement washers before removing the carburetter.

When replacing the jet block, ensure that the fibre washer is in position; align the location slot in the jet block with the locating peg in the carburetter housing and drive the block home.

Finally, note that the float spindle bush fits on the outside end of the spindle, and that the float pressure pad is uppermost so that the float needle rests on it.

INSPECTING THE CARBURETTER COMPONENTS

The parts liable to show wear after considerable mileage are the throttle valve slide, mixing chamber and the air slide.

- (1) Inspect the throttle valve slide for excessive scoring to the front area and check the extent of wear on the rear slide face. If wear is apparent the slide should be renewed. In this case, be sure to replace the slide with the correct degree of cut-away (see General Data).
- (2) Examine the air valve for excessive wear and check that it is not actually worn through at any part. Check the fit of the air valve in the jet block. Ensure that the air valve spring is serviceable by inspecting the coils for wear (see page GD.6).
- (3) Inspect the throttle return spring for efficiency and check that it has not lost compressive strength by measuring its length and comparing it to the figure given in page G.D.6.
- (4) Check the needle jet for wear or possible scoring and carefully examine the tapered end of the needle for similar signs.
- (5) Examine the float needle for efficiency by inserting it into the inverted float needle seat-

ing block, pouring a small amount of petrol (gasoline) into the aperture surrounding the needle and checking it for leakage.

- (6) Ensure that the float does not leak by shaking it to see it contains any fuel. Do not attempt to repair a damaged float. A new one can be purchased for a small cost.
- (7) Check the petrol filter, which fits over the needle seating block, for any possible damage to the mesh. Ensure that the filter has not parted from its supporting structure, thus enabling the petrol (gasoline) to by-pass it unfiltered.

HINTS AND TIPS

Cable Controls

See that there is a minimum of backlash when the controls are set back and that any movement of the handlebar does not cause the throttle to open; this is done by the adjusters on the top of the carburetter. See that the throttle shuts down freely.

Petrol Feed

All models are fitted with a filter gauze at the inlet to the float chamber. To remove the filter gauze unscrew the banjo bolt, the banjo can then be removed and the filter gauze withdrawn from the needle seating.

Ensure that the filter gauze is undamaged and free from all foreign matter. To check fuel flow, before replacing the banjo, turn on petrol tap momentarily and see that fuel gushes out.

Flooding

May be due to a worn needle or a leaky float, but is more likely due to impurities (grit, fluff, etc.) in the tank, so clean out the float chamber periodically till the trouble ceases. If the trouble persists, the tank must be drained and swilled out.

On model A65 Spitfire Mk. II Special, fitted with a single remote float chamber, flooding may also be caused by incorrect setting of the float

chamber height in relation to the carburetters (see page C.21 for details of adjustment).

Fixing Carburetter and Air Leaks

Erratic slow running is often caused by air leaks, so verify there are none at the point of attachment to the cylinder or inlet pipe, check by means of an oilcan and eliminate by new washers and the equal tightening up of flange nuts. On later models a sealing ring is fitted into the attachment flange of the carburetter. In old machines look out for air leaks caused by a worn throttle or worn inlet valve guides.

Banging in Exhaust

May be caused by too weak a pilot mixture when the throttle is closed or nearly closed, also it may be caused by too rich a pilot mixture and an air leak in the exhaust system; the reason in either case is that the mixture has not fired in the cylinder and has fired in the hot silencer. If the banging happens when the throttle is fairly wide open the trouble will be ignition, not carburation.

Bad Petrol Consumption

Which cannot be corrected by normal adjustment, may be due to flooding, caused by impurities from the petrol tank lodging on the float needle seat so preventing its valve from closing.

It may also be caused by a worn float needle valve. High consumption will be apparent if the needle jet has worn; it may be remedied or improved by lowering the needle in the throttle, but if it cannot be—then the only remedy is to get a new needle jet.

There are many other causes of high fuel consumption not connected with the carburetter.

Air Filters

These may affect the jet setting. If a carburetter is set with an air filter and the engine is run without, take care not to overheat the engine due to too weak a mixture; testing with the air valve will indicate if a larger main jet and higher needle position are required.

Effect of Altitude on Carburetter

Increased altitude tends to produce a rich mixture. The greater the altitude, the smaller the main jet required. Carburetters ex-works are set suitable for altitudes up to 3,000 feet approximately. Carburetters used constantly at altitudes 3,000 to 6,000 feet should have a reduction in main jet size of 5%, and thereafter for every 3,000 feet in excess of 6,000 feet altitude further reductions of 4% should be made.

No adjustment can compensate for lost power due to rarified air.

REASSEMBLING THE CARBURETTER
(see page C.4.)**TRACING FAULTS**

There are two possible faults in carburation, either richness or weakness of mixture.

Indications of Richness

Black smoke in exhaust.
Petrol spraying out of carburetter.
Four-strokes, eight-stroking.
Two-strokes, four-stroking.
Heavy, lumpy running.
Sparking plug sooty.

Indications of Weakness

Spitting back in carburetter.
Erratic slow-running.
Overheating.

Engine goes better if: throttle is not wide open or air valve is partially closed.

If richness or weakness is present check if caused by:—

- (1) Petrol feed—check that jets and passages are clear, that filter gauze in float chamber banjo connection is not choked with foreign matter, and that there is ample flow of fuel. Check there is no flooding.

- (2) Air leaks—at the connection to the engine or due to leaky inlet valve stems.
- (3) Defective or worn parts—such as a loose fitting throttle valve, worn needle jet, loose jets.
- (4) Air cleaner choked up.
- (5) An air cleaner having been removed.
- (6) Incorrect setting of float chamber height in relation to carburetters—see page C.24. (model A65 Spitfire Mk. II Special only).
- (7) Removal of the silencer or running with a straight-through pipe, this requires a richer setting.

Having verified the correctness of fuel feed and that there are no air leaks, check over ignition, valve operation and timing. Now test to see if mixtures are rich or weak. This is done by partially closing the air valve, and if engine runs better weakness is indicated, but if engine runs worse richness is indicated.

To remedy, proceed as follows:—

To Cure Richness

- Position 1. Fit smaller main jet.
- Position 2. Screw out pilot air adjusting screw.
- Position 3. Fit a throttle with larger cut-away (paragraph E, page C.7).
- Position 4. Lower needle one or two grooves (paragraph D, page C.7).

To Cure Weakness

- Position 1. Fit larger main jet.
- Position 2. Screw pilot air adjusting screw in.
- Position 3. Fit a throttle with smaller cut-away (paragraph E, page C.7).
- Position 4. Raise needle one or two grooves (paragraph D, page C.7).

NOTE:—It is not correct to cure a rich mixture at half-throttle by fitting a smaller jet because the main jet may be correct for power at full throttle: the proper thing to do is to lower the needle.

VARIABLE SETTINGS AND PARTS

Figure C.2 is a three-section diagram of the carburettor showing the throttle adjusting screw (A), and the pilot air adjusting screw (B).

(A) Throttle Adjusting Screw

Set this screw to hold the throttle open sufficiently to keep the engine running when the twist grip is shut off.

(B) Pilot Air Adjusting Screw

This screw regulates the strength of the mixture for "idling" and for the initial opening of the throttle. The screw controls the depression on the pilot jet by metering the amount of air that mixes with the petrol.




FIG. C.2.

(C) Main Jet

The main jet controls the petrol supply when the throttle is more than three-quarters open, but at smaller throttle openings although the supply of fuel goes through the main jet, the amount is diminished by the metering effect of the needle in the needle jet.

Each jet is calibrated and numbered so that its exact discharge is known and two jets of the same number are alike. **Never ream out a jet, get another of the right size.** The bigger the number the bigger the jet.

To remove the main jet unscrew the main jet cover, the exposed main jet can then be unscrewed from the jet holder.

(D) Needle and Needle Jet (FIG. C.1)

The needle is attached to the throttle valve and being taper—either allows more or less petrol to pass through the needle jet as the throttle is opened or closed throughout the range, except when idling or nearly full throttle. The taper needle position in relation to the throttle opening can be set according to the mixture required by fixing it to the throttle valve with the jet needle clip in a certain groove, thus either raising or lowering it. Raising the needle richens the mixture and lowering it weakens the mixture at throttle openings from quarter- to three-quarters open.

(E) Throttle Valve Cut-away

The atmospheric side of the throttle is cut away to influence the depression on the main fuel supply and thus gives a means of tuning between the pilot and needle jet range of throttle opening. The amount of cut-away is recorded by a number marked on the throttle valve, viz. 376/3 means throttle valve type 376 with No. 3 cut-away; larger cut-aways, say 4 and 5, give weaker mixtures and 2 a richer mixture.


(F) Air Valve

Is used only for starting and running when cold, and for experimenting with, otherwise run with it wide open.

(G) Tickler

A small plunger spring-loaded, in the float chamber wall. When pressed down on the float, the needle valve is allowed to open and so "flooding" is achieved. Flooding temporarily enriches the mixture until the level of the petrol subsides to normal. This valve is operated on some models through a metal strip immediately in front of the left sidecover.

HOW TO TUNE THE CARBURETTER



SEQUENCE OF TUNING

FIG. C.3.

TUNE UP IN THE FOLLOWING ORDER

NOTE:—The carburettor is automatic throughout the throttle range—the air valve should always be wide open except when used for starting or until the engine has warmed up. We assume normal petrols are used.

Read remarks on pages C.6-7 for each tuning device and get the motor going perfectly on a quiet road with a slight up gradient so that on test the engine is pulling.

1st Main jet with throttle in position 1, Fig. C.3. If at full throttle the engine runs "heavily" the main jet is too large. If at full throttle by slightly closing the throttle or air valve the engine seems to have better power, the main jet is too small.

With a correct sized main jet the engine at full throttle should run evenly and regularly with maximum power.

If testing for speed work ensure that the main jet size is sufficient for the mixture to be rich enough to keep the engine cool, and to verify this examine the sparking plug after taking a fast run, declutching and stopping the engine quickly. If the plug body at its end has a cool appearance the mixture is correct; if sooty, the mixture is rich; if, however there are signs of intense heat, the plug being very white in appearance, the mixture is too weak and a larger main jet is necessary.

2nd Pilot jet (Fig. C.3) with throttle in positions 2 and 5. With engine idling too fast with the twist grip shut off and the throttle shut down on to the throttle adjusting screw, and ignition set for best slow-running: (1) screw out throttle adjusting screw until the engine runs slower and begins to falter, then screw pilot air adjusting screw in or out, to make engine run regularly and faster. (2) now gently lower the throttle ad-

justing screw until the engine runs slower and just begins to falter, adjust the pilot air adjusting screw to get best slow-running, if this second adjustment leaves the engine running too fast, go over the job again a third time.

3rd Throttle cut-away with throttle in position 3 (Fig. C.3). If, as you take off from the idling position, there is objectionable spitting from the carburetter, slightly richen the pilot mixture by screwing in the air screw. If this is not effective, screw it back again, and fit a throttle with a smaller cut-away. If the engine jerks under load at this throttle position and there is no spitting, either the jet needle is much too high or a larger throttle cut-away is required to cure richness.

4th Needle with throttle in position 4 (Fig. C.3). The needle controls a wide range of throttle opening and also the acceleration. Try the needle in as low a position as possible, viz. with the clip in a groove as near the top as possible; if acceleration is poor and with air valve partially closed the results are better, raise the needle by two grooves; if very much better try lowering the needle by one groove and leave it where it is best. If mixture is still too rich with clip in groove No. 1 nearest the top, the needle jet probably wants replacement because of wear. If the needle itself has had several years' use replace it also.

5th Finally, go over the idling again for final touches.

TUNING TWIN CARBURETTERS

First of all, slacken the throttle stop screws and put the twist grip into the shut off position to allow the throttles to shut off. There should be a slight back-lash in the cables which can be obtained, if necessary, by screwing in the cable adjusting screws on the top of the carburetter. Then with the handlebars in the normal position and with the throttles closed, adjust the cable adjusting screws so that on the slightest opening of the twist grip, both throttles begin to open simultaneously.

To set the carburetters, follow the procedure as given on previous pages and bear in mind these "hints", which may be useful: main jet sizes are of course selected by checking the effect of the mixture on the sparking plugs after taking a run at full throttle over a straight piece of road; the smallest pair of jets that give the best maximum speed are usually correct provided that the plugs do not show any signs of excessive heat. It might be that for really critical tuning, one carburetter might require a slightly different jet size from the other. For slow-running, set the twist grip to make the engine run slowly but just faster than a "tick-over"; then gently screw in the throttle stops to just hold the throttles in that position, and return the twist grip into the shut position, leaving the engine running on the throttle stops. Set each carburetter according to operation 2, on previous page.

Regarding the setting of the pilot a fairly satisfactory method is to detach one sparking plug lead, and set the pilot air adjusting screw on the other cylinder, as a single unit, and then reverse the process to the other cylinder. It may be found that when both leads are connected to the sparking plugs, the engine runs slightly quicker than desirable, in which case, a slight re-adjustment of the throttle stop screws will put this right. It is essential that the speed of idling on both cylinders is approximately the same, as this will either make or mar the smoothness of the get-away on the initial opening of the throttle.

It is essential with twin carburetters that the throttle slides are a good fit in the bodies and also that there is no suspicion of air leaks at either of the flange attachments to the cylinder.

The lower end of the throttle range, is always more difficult to set and one can only take extra care to make quite sure that the control cables are perfectly adjusted, without any excessive back-lash or difference in the amount of back-lash between one carburetter and another; otherwise one throttle slide will be out of phase with the other, and so resulting in lumpy running.

AMAL CONCENTRIC CARBURETTER




FIG. C.4. Carburetter exploded.

To check the opening of the throttles simultaneously, shut the twist grip back so that the throttles are resting on the throttle stop screws in their final position of adjustment; then insert the fingers into the air intakes and press them on the throttles and ask a friend to gently open the twist grip and feel that the throttles lift off their stops at the same time.

DISMANTLING AND REBUILDING THE CONCENTRIC CARBURETTER

Unscrew the air filter, release the two fixing nuts and withdraw the carburettor from its mounting studs; it will not be necessary to detach the cable from the twist grip.

Take out the two Phillips-head fixing screws and remove the carburettor top cover complete with throttle valve assembly. Compress the throttle spring and remove the needle clip to release the needle. Whilst still compressing the spring, push the cable downwards to release the nipple from its location in the valve. Take care not to lose the needle clip when taking off the spring and top cover.

Unscrew the "banjo" bolt which secures the fuel pipe "banjo" connector to the float needle seating block and withdraw the nylon filter.

The float chamber is secured to the base of the mixing chamber by two screws with spring washers. On removal, it will be noted that the float spindle is a press-fit into the chamber body and that the needle is retained in position by the rear forked end of the float.

The pilot jet, needle jet and main jet (with holder) can now be unscrewed from the mixing chamber base.

Take out the throttle stop adjusting and pilot air adjusting screws and ensure that the small rubber O-ring on each screw is in good condition before replacing.

The float chamber tickler (or primer) consists of a spring and plunger, splayed at one end to retain it in the mixing chamber. This item should not be subjected to a great deal of wear and is therefore unlikely to require replacement.

Having dismantled the carburettor, carefully clean all parts in petrol (gasoline). Hard deposits on the carburettor body are best removed with a light grade wire brush. After washing the parts in clean petrol, allow to dry and ensure that all holes or small drillings are free from dirt. A hand pump is ideal for "blowing through" any blockages in the drillings. Inspect the component parts for wear and check that the jets are in accordance with the recommended sizes given in General Data.

Reassembly is simply a reversal of the above instructions but remember to replace any gaskets or O-rings that appear unserviceable. Refer to Fig. C.4 for guidance.




FIG. C.5.

VARIABLE SETTINGS AND PARTS

The following paragraphs have reference letters for guidance and should be read in conjunction with the sectioned diagram (Fig. C.5) indicating the variable parts.

(A) Throttle Adjusting Screw

Set this screw to hold the throttle open sufficiently to keep the engine running when the twist grip is shut off.

(B) Pilot Air Adjusting Screw

This screw regulates the strength of the pilot mixture for "idling" and for the initial opening of the throttle. The screw controls the depression on the pilot jet by metering the amount of air that mixes with the petrol.

(C) Main Jet

The main jet controls the petrol supply when the throttle is more than three-quarters open, but at smaller throttle openings although the supply of fuel goes through the main jet, the amount is diminished by the metering effect of the needle in the needle jet.

Each jet is calibrated and numbered so that its exact discharge is known and two jets of the same number are alike. Never ream out a jet, get another of the right size. The bigger the number the bigger the jet.

To gain access to the main jet the float chamber must first be removed (two screws). The main jet can now be unscrewed from its holder in the mixing chamber base.

(D) Needle and Needle Jet

The needle is attached to the throttle valve and being taper—either allows more or less petrol to pass through the needle jet as the throttle is opened or closed throughout the range, except when idling or nearly full throttle. The taper needle position in relation to the throttle opening can be set according to the mixture required by fixing it to the throttle valve with the jet needle clip in a certain groove, thus either raising or lowering it. Raising the needle richens the mix-

ture and lowering it weakens the mixture at throttle openings from quarter- to three quarters open.

GENERAL OPERATION (G.P.2.)

Design Features

The G.P.2 carburetter has been designed with a view to obtaining the maximum possible power from the engine, at the same time maintaining a progressive and consistent acceleration throughout the throttle range.

This has been achieved by embracing the metering needle (11) within the confines of the throttle valve itself (23) which, although leaving an unrestricted bore at full throttle, also leaves a very short tract for the mixture to traverse from the needle jet (1) to the choke.

The G.P.2 carburetter, as distinct from the G.P. carburetter, now carries an additional feature, inasmuch as the pilot adjuster screw (27) now controls the volume of air and the petrol is metered through a detachable pilot jet (24), giving much more flexible tuning over the pilot range and at the same time this arrangement has been so designed that the carburetter can be used at an increased downdraught angle and if necessary, completely downdraught.

Resulting from these points of design it will be found that in conjunction with the maximum power obtainable, a much smoother throttle control is possible at the lower r.p.m. which has the result where megaphone exhausts are used, of allowing a cleaner entry on to the megaphone than was previously possible.

Choke Bore Diameters

Except in the maximum choke sizes of the four types of G.P.2 instruments, it will be found that the effective choke diameter of the mixing chamber is on the engine side of the throttle slide (23), between it and the outlet of the carburetter, and not in the centre of the choke adaptor (22) as might be expected. Therefore, in referring to the choke size of a G.P.2 carburetter, it is this

G.P.2 MIXING CHAMBER




FIG. C.6.


T.10 G.P.2 MODELS WITH
REMOTE FLOAT CHAMBER

FIG. C.7.

smallest diameter in the mixing chamber which is of moment.

Naturally, when deciding on the choke size of a racing carburetter, the peak r.p.m. of the engine is the main controlling factor in conjunction, of course, with the inlet port diameter on the engine in question.

Fitting

Regarding fitting the carburetter, although we are often asked what is the correct distance between the inlet valve centre line and the centre of the carburetter mixing chamber, this is not a figure which can be laid down in hard and fast manner, as it varies enormously from one engine to another. Broadly speaking, a distance of between 7 in. to 9 in. probably represents a fair mean dimension.

Flange fitting is standardised with the G.P. carburetter to eliminate as much as possible the worry of air leaks which may persist with clip fitting instruments.

Float Chambers

The float chamber recommended and normally fitted to the current G.P.2 carburetter is a remotely mounted type 510 and is of bottom feed design incorporating a lever type operated float.

Petrol Level

The petrol level in the type 510 float chamber is .640 in. below the cover joint and is marked with a raised line on the outside of the body. In positioning the float chamber this line should be on a level with the lowest point of the circular scribe mark on the air jet plug (3).

Locking Devices

A spring blade locking device (18) held in place by the air tube lock ring (19) engages with serrations on the mixing chamber cap (16), which positively prevents unscrewing due to vibration. The jet plug (20), banjo bolt (43), plug screw (42), jet block holding screws (13), float chamber cover screws (46), and the float/hinge spindle head (not illustrated) are drilled to enable them to be lock-

wired up.

Tuning (General)

The tuning sequence of the G.P.2 carburetter follows the well established Amal principles. Inasmuch as there is a main jet (15) controlling the fuel supply at full throttle, a needle jet (1), the emission from which is controlled by the position of a taper needle (11), and at the lower throttle openings by the cut-away of the throttle valve (23), a detachable pilot jet (24) and a pilot air adjusting screw (27) controlling the mixture strength for idling; an air jet (2) controls the amount of air which primarily atomises the fuel as it comes out of the needle jet (1) before going into the spray tube (12) and thence to the heart of the choke.

This latter air jet (2) is a form of depression control for the main jet and from normal experiences would appear to require a .1 in. dia. air jet for chokes of up to $1\frac{1}{16}$ in. and .125 in. dia. for choke sizes in excess of this figure.

Normally speaking, this air jet would be fitted by the factory when the carburetter was supplied and would not be considered a likely component to change, but remembering that the main jet depression can be increased by fitting a smaller air jet, it may sometimes, for special purpose tuning, be found an asset to try a larger or smaller air jet.

The needle control covers a range of the throttle opening from about one-third throttle up to seven-eighths throttle opening. The needle grooves in the G.P. needle will be found to number five instead of seven as previously on the T.T. instruments, due to the fact that the needle control of the G.P. carburetter is rather more sensitive than on other types. Two types of needle (11) are available, a standard taper needle and a much weaker taper needle.

The standard taper needle is known as the G.P. needle; the weaker taper needle is known as the G.P.6 needle.

The weaker needle is usually fitted except where alcohol fuel is concerned.

Main Jet

Always bear in mind, that whatever the type of needle used, or the position in which it is fitted, there will be no affectation of the main jet (15). This should be arrived at by fitting the jet which gives the best possible power on the bench or, on the other hand, the highest possible r.p.m. on the road, and once this has been obtained, under no circumstances should it be altered.

The main jet (15) can be very readily removed by taking off the hexagon cap (20) at the base of the carburetter mixing chamber. The jet size is marked on the side of these jets, and represents the flow in c.c. per minute on Amal calibrating machines. These jets are made in 10 c.c. increments, that is, for instance—250, 260, 270, etc.—up to and including 600, when, after this, 20 c.c. increments become standard up to 1,000. Over 1,000 increments are of 100 c.c.

For rough guidance, therefore, the following jet sizes should be approximately correct for the choke sizes in question:—

using 80 octane or petrol benzol fuel

10 G.P., $1\frac{1}{16}$ in. choke—jet 210

10 G.P., $1\frac{3}{32}$ in. choke—jet 260

with of course, the intermediary choke sizes, using a proportionate sized jet.

The rest of the throttle range should then be dealt with absolutely individually in steps by means of the needle adjustment, throttle valve cut-away alteration and pilot adjustment, with a possible check on the air jet fitted.

The throttle valve (23) which surrounds the choke adaptor (22) in the carburetter, controls

with its leading edge the velocity of air entering the throttle bore and consequently the depression on the spray tube at lower throttle openings with a diminishing effect up to point where the cut-away disappears from the cross bore.

The trailing edge of the throttle valve, of course, controls the volume of mixture passing to the engine.

These throttle valves can be supplied with various cut-aways from No. 3 up to No. 8, each number varying in its cut-away on the air intake side by $\frac{1}{16}$ in. Low numbers provide richer mixture than high numbers.

The needle jet (1), which is of stainless steel to prevent wear, has been found for best all-round usage on petrol or petrol benzol to require a diameter of .107 in. for choke sizes in the type T.15.G.P.2 range, over this a needle jet of .109 in. diameter is necessary. For alcohol fuel, of course, larger needle jets are necessary.

Pilot System

This gives a supply of metered fuel through a detachable pilot jet (24), which mixes with air regulated by the pilot air adjusting screw (27) and passes into the mixing chamber through a small hole on the engine side of the throttle slide.

Compensation on this G.P.2 carburetter is obtained through the medium of the primary air which passes through a slot (4) in the mixing chamber and then, via the air jet (2) previously mentioned, atomises the liquid fuel passing from the needle jet (1).

As the engine supply increases or decreases at a given throttle opening with a varying load, so compensation will take place.

KEY TO SECTIONED ILLUSTRATION

Mixing Chamber

1. Needle jet.
2. Air jet.
3. Air jet plug.
4. Primary air slot.
5. Air valve cable adjuster locknut.
6. Air valve cable adjuster.
7. Throttle cable adjuster.
8. Throttle cable adjuster locknut.
9. Needle clip.
10. Needle clip retaining screw.
11. Metering needle.
12. Spray tube.
13. Choke adaptor retaining screws.
14. Petrol inlet banjo.
15. Main jet.
16. Mixing chamber cap.
17. Throttle valve return spring.
18. Mixing chamber cap lock-spring.
19. Air tube lock ring.

20. Jet plug.
21. Jet holder.
22. Choke adaptor.
23. Throttle valve.
24. Pilot jet.
25. Pilot jet cover nut.
26. Pilot jet cover nut washer.
27. Pilot air adjusting screw.
28. Pilot air adjuster locknut.

Float Chamber

40. Petrol outlet connection.
41. Float and hinge.
42. Plug screw.
43. Petrol inlet banjo bolt.
44. Petrol inlet banjo.
45. Float needle.
46. Float chamber cover screws.
47. Tickler.

TUNING SEQUENCE

To get carburation for any stated fuel when the choke bore is correct for the peak revs of the engine and the correct needle jet for the fuel to be used, the procedure is simple. Start off with an assumed setting, and then tune as follows. There are four phases:—

- (1) Main jet for power at full throttle;
- (2) Pilot air adjuster for idling;
- (3) Throttle cut-away for "take off" from the pilot jet;
- (4) Needle position for snappy mixture at quarter to three-quarter throttle; then final idling adjustment of the pilot jet.

Always tune in this order, then any alteration will not upset a correct phase.

Sequence of Tuning

- (1) Main jet size.
- (2) Pilot adjustment.
- (3) Throttle valve cut-aw.

- (4) Needle position.

(1) Main Jet Size

This should be determined first: the smallest jet which gives the greatest maximum speed should be selected, keeping in mind the safety factor for cooling. (The air lever should be fully open during these tests.)

(2) Pilot Adjustment

Before attempting to set the pilot air adjuster the engine should be at its normal running temperature, otherwise a faulty adjustment is possible, which will upset the correct selection of the throttle valve. The pilot air adjuster is rotated clockwise to richen the mixture and anti-clockwise to weaken it. Adjust this very gradually until a satisfactory tick-over is obtained, then reset locknut but take care that the achievement of too slow a tick-over—that is, slower than is actually necessary—does not lead to a "spot" which may cause stalling when the throttle is very slightly open.

(3) Throttle Cut-away

Having set the pilot air adjuster, open up the throttle progressively and note positions where, if at all, the exhaust note becomes irregular. If this is noticed, leave the throttle open at this position and close the air lever slightly; this will indicate whether the spot is rich or weak. If it is a rich spot, fit a throttle valve with more cut-away on the air intake side (or vice versa if weak).

(4) Jet Needle Position

Tuning sequence 2 and 3 will affect carburation up to somewhere over one-quarter throttle, after which the jet needle, which is suspended from the throttle valve, comes into action and when the throttle is opened further and tests are again made for rich or weak spots, as previously outlined, the needle can be raised to richen or lowered to weaken the mixture, whichever may be found necessary. With these adjustments correctly made, and the main jet size settled, a perfectly progressive mixture will be obtainable from tick-over to full throttle. The jet needles are interchangeable in 10G.P.2 carburetters.

ALCOHOL FUELS

Concerning alcohol fuels, the G.P.2 range of carburetters function perfectly satisfactorily on any alcohol blend up to and including straight methanol. It will be necessary to fit a .125 in. diameter needle jet (1) for any alcohol content over 50%. With this larger needle jet a standard taper needle (11) should be used, which means for the type 10G.P.2 a needle marked G.P. is required. An approximately correct needle position will be No. 4 that is: the fourth groove from the top of the needle.

Regarding main jet sizes, these have to be increased in the following proportions, taking the basic size as that used for 80 octane fuel or petrol benzol.

STRAIGHT METHANOL—increase the basic jet size by 150%.

J.A.P. RACING FUEL—increase the basic jet size by 150%.

ESSO No. 1 FUEL—increase the basic jet size by 150%.

ESSO No. 2 FUEL—increase the basic jet size by 120%.

ESSO No. 3 FUEL—increase the basic jet size by 130%.

SHELL A.M.M. FUEL—increase the basic jet size by 150%.

SHELL A.M.1 FUEL—increase the basic jet size by 140%.

SHELL A.M.8 FUEL—increase the basic jet size by 120%.

SHELL A.M.9 FUEL—increase the basic jet size by 100%.

SHELL A.M.12 FUEL—increase the basic jet size by 50%.

NOTE:—When calculating the jet size on the basis of the jet size used for petrol/benzol mixtures—the per cent increase must be added to the original jet size and the total is the new size to be used for the particular fuel. Example: if a jet No. 300 was used for petrol/benzol and it was decided to change over to **methanol**, which requires an increase of 150% adding to the original jet size 300.

Calculate this way: $\left(\frac{\% \text{ increase} \times \text{original jet size}}{100} \right) + \text{original jet size}$

$$\text{namely } \left(\frac{150 \times 300}{100} \right) \div 300 = 450 \div 300 = 750$$

The answer is, use main jet 750 and the appropriate needle-jet for alcohol fuels as given in a paragraph above.


When using alcohol mixtures, the alcohol content of which is not exactly known, "trial and error" will be necessary in finding the correct jet size, in which case it should be remembered that although quite an excessively over-rich mixture can be used on alcohol, the slightest weakness will result in trouble. Therefore, always err on the rich side for the start of the "trial and error" tests. On the other hand, if the exact composi-

tion of the fuel should be known and you get in touch with the Technical Department, Amal Ltd., Holdford Road, Witton, Birmingham 6, they will be able to give you a fairly close approximation of the jet size required for the alcohol mixture in question.

Normally, when changing over from petrol to alcohol on the G.P. range of instruments, no alteration will be necessary to the air jets fitted.

**ALCOHOL FUELS MUST NOT BE USED
IN FIBRE-GLASS FUEL TANKS.**

G.P.2 REMOTE FLOAT CHAMBER AND MOUNTING

**Removing Remote Float Chamber**

Turn off the petrol supply at both taps and protect the crankcase from petrol with a suitable piece of rag.

Take out the jet holders from below each carburettor by unscrewing the larger of the two nuts below the "banjo" unions.

Disconnect the "banjo" union at front base of float chamber and move supply pipes clear.

Remove the locknut from the recess in the float chamber mounting and release the fixing stud adaptor.

The float chamber is now free and can be withdrawn complete with small petrol pipes, "banjo" unions and fixing stud with adaptor.

Reassembly is simply a reversal of the above procedure.


It will be noted that the setting of the float chamber height is not disturbed when using this method for removal. If, however, the float chamber fixing stud nuts were loosened or removed, the correct setting must be obtained as follows.

Adjust the fixing stud top nut so that the float chamber level line is brought horizontal with the base of the circular groove on the carburettor air jet plug (see Fig. C.9, page C.21).

Hold this setting and tighten the locknut on to base of adaptor.

FIG. C.8.

FLOAT CHAMBER SETTING (see page C.20)



LINE TO BE LEVEL
WITH BASE OF CIRCLE

FIG. C.9.

INDEX

	<i>Page</i>
A50, A65 FRAME (1966)	D.2
FRAME ALIGNMENT	D.3-5
CHAINGUARD	D.6
SWINGING ARM	D.6-8
REAR SHOCK ABSORBERS	D.8-9
SWINGING ARM BUSHES	D.9
DUAL SEAT	D.9
SIDECOVERS	D.9
SIDECOVER FASTENERS	D.9-10
REAR MUDGUARD	D.10
BATTERY CARRIER	D.10-11
OIL TANK	D.11
TOOLBOX	D.12
CENTRE STAND	D.12
PETROL TANK REMOVAL	B.5
THROTTLE CONTROL CABLE REPLACEMENT	D.13
AIR CONTROL CABLE REPLACEMENT	D.14
CLUTCH CONTROL CABLE REPLACEMENT	B.17
TWIN CARBURETTOR CABLES	D.14
FRONT BRAKE CABLE REPLACEMENT	D.15





FIG. D.1.

FRAME ALIGNMENT

FIG. D.2. *Steering head mandrel.*

ONE OFF MILD STEEL BAR.

24 IN. X 1 IN. TO SUIT BLOCKS.

TWO OFF MILD STEEL BLOCKS.

The only satisfactory way of checking the A50/65 frame for alignment is on an engineers setting-out table. The drawing on page D.2 will help in checking the basic dimensions.

In addition to the table which should be approximately 5 feet by 3 feet the following equipment will also be necessary.

One mandrel and two blocks as in Fig. D.2.
 One mandrel or bar for swinging arm pivot $13/16$ in. diameter by 12 in.
 One large set-square.
 One 18 in. vernier height gauge or large scribing block.
 One pair of large "V" blocks and several adjustable height jacks.





FIG. D.3. Setting up the frame.

FRAME ALIGNMENT

FIG. D.4. *Showing bent top tube.*

If a scribing block is used then an 18 in. steel rule will also be required. The mandrels must be straight and round, otherwise measurements will be affected. The basic set-up for checking is shown in Fig. D.3, variations can of course be used according to the facilities available.

Place the mandrel and blocks in the steering head and "V" blocks and position the blocks at one end of the setting-out table.

Check the mandrel at each end to ensure that it is parallel with the surface of the table.

Insert the 13/16 in. diameter mandrel through swinging arm pivot holes.

Using jacks or packing pieces set the frame horizontal to the table so that checks taken at points (A) are the same.

If the frame has suffered damage in an accident, it may not be possible to set points (A) parallel in which case points (B) can be used.

Sometimes if the machine has suffered a frontal impact, the main tube will be parallel at points (A) but will be bent as shown in Fig. D.4. The straight edge can be made quite easily from say a piece of good quality hardboard but, the checking edge must be quite straight.

When set parallel to the surface table the mandrel through the swinging arm pivot holes should be vertical in all directions, this can be checked using the set-square and internal calipers or a slip gauge between the mandrel and the square.

The set-square should touch the upper and lower tubes together at points (C) and (D) if the frame is true and correctly set-up on the table.

To find the frame centre line take the height of the main tube and subtract half the diameter of the tube, checks can then be taken of the engine mounting lugs and other points of the frame.

Errors at any point should not exceed $\frac{1}{32}$ in. (.75 mm.).

CHAINGUARD

The chainguard used with quick-release type hubs with the brake rod on the left-hand side, has only the two upper screws in captive nuts and one bolt in the rear lower position.

This bolt also retains the rear brake anchor strap, with a distance piece between the strap and the rear portion of the guard, and a self-locking nut at the back of the guard.

To remove, take off the nut, bolt and distance piece, and take out the two upper screws.

Replacement is simply the reversal of the removal procedure.

SWINGING ARM REMOVAL

The swinging arm fork fits between two plates welded to the frame and is retained in position

by the pivot spindle.

With the quick-release hubs which are fitted, the brake rod is on the left-hand side of the frame and the pedal is fitted to a separate spindle.

Remove the chainguard as described opposite.

Remove the rear chain from the chainwheel after disconnecting the spring link.

Remove the rear wheel and chainwheel as detailed on pages F.8-10.

Remove the rear shock absorbers (page D.8).

Unscrew and remove the large 13/16 in. B.S.C. nut fitted to the right-hand end of the hollow pivot spindle.

Remove the single $\frac{5}{16}$ in. bolt and washer holding the pivot spindle anchor plate on the left-hand side of the machine and pull out the spindle.




FIG. D.5. *Swinging arm dimensions.*

It may be necessary to move the small stop light lever on the brake pedal to allow free passage for the anchor plate.

If the spindle has corroded use a drift not more than .805 in. diameter to drive the spindle out.

The swinging arm fork is now ready to be removed, using a raw-hide mallet, tap the left-hand side downwards and the right-hand side upwards to release it from the plates.

Replacement is simply the reversal of removal procedure but, do not lock the large 13/16 in. B.S.C. nut until the shock absorbers have been refitted otherwise difficulty may be experienced in connecting both ends of the units.

To check the fork, the silent block bushes must

be in good condition or, be renewed.

Using the same mandrel that was used for the swinging arm pivot on the frame, and the rear wheel spindle, set the swinging arm in "V" blocks as shown in Fig. D.6. In this position both the spindle and mandrel should be parallel to the surface table.

Should there be less than $\frac{1}{4}$ in. malalignment of the swinging arm fork it is permissible to correct it by means of a suitable lever but, great care is necessary if further damage is to be avoided.

To check that the forks are square to the pivot they must be set-up at 90° to the position illustrated, that is the pivot must be vertical.




FIG. D.6. *Checking the swinging arm fork.*

Next find the centre of the pivot and check the fork ends etc., in accordance with the drawing dimensions (see Fig. D.5, page D.6 for dimensions of the swinging arm fork).

There may also be variation in the rear dampers and a careful examination should be made of the overall length between the mounting eyes. It is possible that one damper may be weaker

than the other, this may be due to "settling" of one spring in which case it is advisable to renew both springs.

When there is considerable malalignment in either frame or swinging arm, owners in the British Isles can obtain works reconditioned units through the dealer network.

REAR SHOCK ABSORBERS

The rear shock absorbers are the coil spring type, hydraulically damped, with bonded rubber mounting bushes at each end. The only dismantling possible is for the removal and replacement of the springs.

To remove the dampers take out the upper and lower mounting bolts after placing a suitable block of wood between the rear tyre and the mudguard.

Take careful note of the various distance pieces and washers used with the top mounting.

If the springs are to be changed the spring must





FIG. D.7. Using tool 61-3503



LIGHT - MEDIUM - HEAVY

FIG. D.8. Cam ring positions.

first be compressed with service tool No. 61-3503 and the split collets removed, the tool is then removed, the spring changed and the new spring compressed to replace the split collets.

Solo springs are graded at 90 lbs./in. rate and have green/white marking. Sidecar springs are graded at 110 lbs./in. and are marked with red/white paint for identification.

The dampers have three load positions, light, medium and heavy and they must be in the "light load" position before dismantling.

The mounting bushes at each end can be driven out quite easily, and new ones fitted if a little liquid soap is used to assist.

Squeaking is usually due to the spring rubbing

on the lower dust shield and can be eliminated by smearing high-melting point grease on the spring and inside the shield.

Do not lubricate the plunger rod.

SWINGING ARM BUSHES

The bushes fitted to the swinging arm fork take the form of two steel bushes bonded together with rubber, the inner bush being slightly more in length than half the width of the fork pivot.

When the swinging arm is assembled in the frame the two inner bushes are locked together on the end faces and the rubber is then under tension as soon as the fork moves.

Under normal circumstances the bushes will last the life of the machine but, if they do require renewal, then the rubber should first be removed by burning it out. This can be done by heating thin rods or strips of metal and then progressively burning out the rubber. When sufficient rubber has been removed, drive out the inner bushes after which the outer bushes can be removed with a suitable drift which should not be more than 1.245 in. (31.623 mm.) in diameter.

DUALSEAT

The dual seat is retained in position by two bolts with washers and distance pieces, underneath the seat at each side of the guard. To remove, take out the bolts and washers noting position of each

distance piece, and unhook the seat from the front.

Replacement is the reversal of this procedure.

SIDECOVERS

The glass-fibre sidecovers, which are now used with all models are each secured by two special fasteners.

Removal and replacement of the covers is quite straight forward. It is only necessary to give each fastener a half-turn to release it or to lock it.

SIDECOVER FASTENERS

The fastener bolt in the cover is known as an "Oddie" stud and is retained in the cover by the rubber bush. If at any time it is necessary to

replace a stud, simply press the old one out, place a new bush in the hole and press the new stud into position using a little liquid soap as a

lubricant.

The fasteners, one on the toolbox and three on the frame brackets, are known as "Oddie"

clips and are retained in position by $\frac{1}{8}$ in. Whitworth bolts and nuts ("pop" rivets on later models).

REAR MUDGUARD

Two types of rear mudguard are used the valanced, and the blade type, which has no valance.

The mountings are basically the same except at the shock absorber. All valanced guards have the top shock absorber bolt passing through the valance with the nuts inside the guard, whereas the blade type uses a bridge piece, the guard then being bolted to the bridge piece separately.

Removal

Remove the dual seat as described on page D.9 and disconnect the rear lamp at the connectors under the seat.

Take out the rear wheel as described on page F.8 but, do not disturb the chainwheel.

Valanced Type

Remove all the bolts and nuts attaching the guard to the frame taking particular note of the disposition of any distance pieces or washers.

The damper bolts should only be drawn out sufficiently to release the mudguard which can be removed complete with the number plate.

Blade Type

Proceed as for valanced guard but do not disturb the damper bolts, release the mudguard by taking out the two bolts and nuts attaching the guard to the bridge piece. In some cases it may be necessary to move the rectifier to avoid damaging it.

Replacement of both types is simply the reversal of dismantling procedure.

BATTERY CARRIER

The battery carrier is suspended by two special bolts and nuts with rubber distance pieces between so insulating the carrier and battery from road shocks and vibration.

Removal and replacement is quite straight forward after the left-hand sidecover has been removed. The battery strap and battery can be removed without disturbing the rubber mountings.

Always see that the rubber mats and the rubber buffer at the base of the carrier are in position.

If the carrier is removed for any reason it is essential that the reassembly is carried out in the order shown in Fig. D.9. The plain washer (A) fits into slot (B) with rubber bushes (D) on each side.




FIG. D.9. Battery carrier (1966/7).

On 1968 models the battery carrier has been modified to simplify removal of the battery.

Instead of the steel strap on top of the carrier there is a bonded rubber strap which pulls over the battery and hooks under the bracket at the front, this strap is fully adjustable.

Normally, the carrier need not be disturbed, but if for some reason it is taken off care must be taken when replacing it. The fitting instructions are the same as for the 1966/7 carrier (Fig. D.9), but to avoid undue pressure on the sides of the battery case, it is essential that the carrier when mounted measures $5\frac{1}{4}$ in. between the two sides internally, excluding the rubber pads. Should there be any tendency for this dimension to be less than $5\frac{1}{4}$ in. at the top, it can be ad-

justed by means of an elongated hole on the front upright of the carrier.




FIG. D.9A. Battery carrier (1968).

OIL TANK

The oil tank rests on three buffers and is retained in position by a single rubber-mounted bolt at the top of the tank, thus insulating the tank from vibration.

To remove the tank, first drain the oil as described on pages A.6-8.

Remove the dual seat and disconnect the oil feed and return pipes from underneath the tank and the rocker box oil feed pipe, this latter connection is at the top of the tank.

Take out the rear wheel, as described on page F.8 and remove the rear mudguard as described on page D.10.

Remove the oil tank mounting bolt noting the position of the rubbers etc., and lift the tank out.

NOTE:—It may be necessary in some cases to move the rectifier to avoid damage.

The rubber buffers below the tank are simply a press-fit into the frame brackets and need not be disturbed unless they have become saturated with oil, in which case, they should be replaced.

Replacement of the oil tank is simply the reversal of dismantling but, it is advisable to replace all the pipes and check for leakage before replacing the mudguard and wheel.

Do not forget that the oil feed and return pipes cross over on the way to the engine (see Fig. A.6, page A.8).




FIG. D.10. Tank mounting.

TOOLBOX

The toolbox is retained by two $\frac{1}{4}$ in. B.S.C. bolts and nuts which pass through both the box and the bag with the nuts inside the bag. To remove or replace the bag, it is only necessary to remove the two nuts and washers, after taking off the right-hand sidecover.

If the toolbox is to be removed the rear wheel must be taken out, as described on page F.8, and the mudguard removed as detailed previously. The box can only be positioned from inside the frame.

CENTRE STAND

The centre stand is held in position with a plain steel bar drilled at both ends for split pins, centre distance piece, two spring washers and two plain washers.

To remove the stand it is only necessary to remove the split pin from one side and draw the pivot pin out from the opposite side.

When replacing the stand, note that the spring washers are fitted outside the stand, then the plain washer and finally the split pin.

Grease nipples are provided in each stand lug to lubricate the pivot.

Stand Spring

The simplest way to replace the stand spring is to use a Phillips type screwdriver. Place the eye of the spring over the frame anchorage, insert the screwdriver in the other eye, place the screwdriver slot under the hook on the stand and lever downwards to press the spring over the hook (see Fig. D.11).




FIG. D.11. *Fitting the spring.*

THROTTLE CABLE REPLACEMENT

Throttle cable replacement is an operation which the private owner should practice once or twice so that in the event of a cable failure on the road, the replacement can be quickly carried out.

It is also good practice to carry spare throttle and air cables taped to the existing cables.

Single Carburettor Models

First turn the twist grip to open the throttle then release it and at the same time pull the cable out of the grip to release the slotted cable stop.

Now remove the two slotted screws from the twist grip control and take off the top half to expose the cable nipple.

Ease the nipple out of the grip and remove the cable.

Fit the replacement cable to the grip by passing it up through the lower half to insert the nipple in its slot.

Replace the top half of the grip tightening the screws equally and ensuring that the grip turns freely.




FIG. D.12. *Removing throttle cable from slide.*

Do not replace the cable stop at this stage.

Remove the petrol tank and carburettor as described on page B.5.

Pull the cable from the frame clips and unscrew the knurled ring holding the mixing chamber top cap on the carburettor (see Fig. C.1).

Very carefully draw out the slide assembly.

Take careful note of the position of the throttle needle clip and remove the clip and needle. Compress the throttle slide return spring then push the cable nipple down and out of the slide (see Fig. D.12).

To fit the replacement cable, pass the nipple through the top cap and the spring, compress the spring and slip the cable through the slot so that the nipple is seated to one side of the centre hole.

Replace the throttle needle and secure with the spring clip in the correct groove (see page GD.6).

Carefully pass the needle down through the carburettor body so that the needle goes into the needle jet.

Locate the slides so that they slip freely down into the body and replace the top cap and ring. Make absolutely sure the ring goes completely down on its seat and that threads are in good condition.

Check the action of the controls before replacing the carburettor on the engine.

Secure the cable to the frame, replace the cable stop at the twist grip, and adjust the cable as necessary by means of the adjuster in the top cap or on the cable.

AIR CONTROL CABLE

To replace an air control cable first open the control to its fullest extent then close it pulling the cable out of the body at the same time. Release the cable nipple.

Remove the petrol tank and carburetter as described on page B.5 and remove the slide assembly as described for changing the throttle cable.

Slip the air slide up and out of the throttle slide and compress the spring to release the cable nipple.

To fit the replacement pass the nipple through the top cap, spring guide tube, and spring, compress the spring and slip the nipple into the slide.

Replace the air slide in the throttle slide and proceed as for the replacement of the throttle cable.




FIG. D.13. *Air slide and cable.*

TWIN CARBURETTERS

The procedure for replacement of cables is similar to the single carburetter models except that there is no need to remove the carburetters from the engine, and the twin air cables from the carburetters enter a junction box to emerge as a single cable.

Remember that the adjustment of the cables for twin carburetters is very critical otherwise the tune will be upset.

There are two adjusters for the throttle cables but only one on the top cap for the air cable.

If the long air cable is to be replaced remove the petrol tank as described on page B.5.

This will expose the junction box underneath the tank, it is then only necessary to unscrew the one cap off the junction box to expose the cable nipple.




FIG. D.14. *Junction box.*

If either of the short cables require replacement, unscrew the carburetter top caps and draw out the slides, unscrew the junction box caps at that end to expose the nipples and proceed as for single carburetters.

After reassembly synchronise the carburetters as detailed on page C.9.

FRONT BRAKE CABLE

To remove a front brake cable first unscrew and remove the handlebar lever fulcrum pin and nut.

Swing the lever out from the bracket and slip the cable nipple out of the lever, the adjuster can then be removed from the bracket with the cable.

Remove the screw and nut holding the toggle to the lever on the brake cover plate and remove the outer casing from the stop on the cover plate.

Replacement is simply the reversal of the above procedure but, do not omit to re-adjust the brake cable, and test brake deliberately before using the machine as usual.

INDEX

	<i>Page</i>
DESCRIPTION	E.2
ADJUSTING STEERING HEAD RACES	E.2-3
RENEWING STEERING HEAD RACES	E.3-5
REMOVING AND REFITTING THE HEADLAMP	E.5
REMOVING FORK LEGS	E.5-6
CHANGING FORK SPRINGS	E.6
DISMANTLING FORK LEGS	E.6-7
OIL SEALS	E.7
REBUILDING FORK LEGS	E.8
REPLACING FORK LEGS	E.8-9
FORK ALIGNMENT	E.9-10
HYDRAULIC DAMPING	E.11

DESCRIPTION

The front forks fitted to all A50 and A65 models are basically the same in that they are telescopic, hydraulically damped and the oil used for damping also lubricates. The quantity of oil required is the same for all the forks the only variations being in the fittings, such as spring covers and headlamps.

1966 models which have quick-release type hubs have rubber fork gaiters and the wheel spindles screw into the fork end.

The forks are of robust design and only require the minimum of maintenance amounting to oil

changing at the periods quoted on page A.2.

There is, built into the main tube of each leg, a new damper valve attached to a rod screwed into each top cap.

This valve operates in a special damper tube attached to each lower sliding member by a socket screw passing through the fork end.

Whereas earlier models had little fork rebound damping the 1966 valve, together with the well-tried compression damping, gives full damper control at all times.

ADJUSTING STEERING HEAD RACES

It is most important that the steering head races are correctly adjusted.

There should be no play evident between the races but great care must be taken not to over-tighten, the latter can indent the balls into the races and make steering extremely difficult and dangerous.

Place a strong support underneath the engine so that the front wheel is lifted clear of the ground, then standing in front of the wheel, push and pull alternately on the lower fork legs to determine if there is play in the steering head (Fig. E.2).

Care is necessary to distinguish between play in the head races and play in the fork bushes. In some cases there may be both.

If possible get a friend to place the fingers of one hand lightly round the top head races whilst the forks are being pushed and pulled, if play is there, it will be felt quite easily by the fingers.




FIG. E.1. *Steering head adjustment.*

It should also be possible to move the forks from side to side quite smoothly and without any jerky movement. If the movement is jerky the balls are indented into the races, or broken, in either case they and the cups and cones should be renewed. The steering damper must of course be completely free while testing.

To adjust the steering, remove the damper rod then the top cap (B) Fig. E.1, to expose the adjuster sleeve (E).

Slacken off the pinch bolts (C) and (D) and using service tool No. 61-3008 screw the sleeve (E) in (clockwise) to reduce steering play or, out (anti-clockwise) to increase steering play.

Having adjusted the steering tighten the pinch bolts (C) and (D), replace the top cap (B), and the steering damper rod.




FIG. E.2. Testing the steering head for play.

RENEWING HEAD RACES

The steering can be dismantled to change the head races without stripping the forks but the lighting cables must be removed by pulling them from the socket at the back of the switch and the reflector in the headlamp (see page E.6). Disconnect the front brake cable at the handlebar lever.

Remove the damper rod and disconnect both speedometer and rev-counter cables (when fitted) by unscrewing the cable nipples at the instrument heads and pulling out the inner wire.

Place a piece of cloth over the fuel tank, remove the four bolts (B) securing the handlebar clips, and place the handlebars to one side on the tank.

Slacken the pinch bolt (D), remove the cap (C), and unscrew and remove the adjusting sleeve which is underneath cap (C) Fig. E.3. Unscrew

caps (A) lift up and unscrew the fork damper rods which are screwed into the underside of the caps. Allow the rods to drop down into the fork legs, they can be retrieved later.




FIG. E.3.

Using a raw-hide mallet strike the sides of the top yoke alternately to release it from the tapered legs. Lift the top yoke to one side and draw the steering column down and out of the head, but be careful to catch the bearings which will be released as the column is withdrawn.




FIG. E.4.

There should be twenty $\frac{1}{4}$ in. diameter steel balls in each race. See page A.13 regarding lubrication.

The two cones differ slightly in size but the two cups are identical.

The lower cone can be prised off the column but care is required when fitting the replacement.

For this purpose a piece of steel tubing 10 in. to 12 in. long, $1\frac{1}{4}$ in. inside diameter, of heavy gauge, is most useful for driving the cone on to its seat squarely and firmly (see Fig. E.4).

The two cups can be removed with service tool No. 61-3063.

Slacken off the nut on the tool sufficient to allow the tool to be screwed into the cup then tighten the nut until the tool is expanded tightly into the cup threads.




FIG. E.5. Removing the top cup.

Drive out the cup with a suitable bar from inside the head tube.

Remove the tool by slackening off the nut and repeat the procedure on the other cup.




FIG. E.6. Cup drift.

When fitting the replacement cups see that they enter the housing squarely and be very careful to avoid cracking the cup. If possible use a piece of steel bar or tube slightly less than the outside diameter of the cup. Do not drive the cup in with a drift resting on the radius of the ballrace, this will impose undue strain and is liable to fracture the cup. A suitable drift would be as Fig. E.6.

Reassembling the Steering Head

After replacing the cups and bottom cone grease the cups, assemble 20 balls in each cup then slide the column back into the head. Replace the top cone and dust cover then the top yoke and screw in the adjusting sleeve. Adjust as quoted on pages E.2-3 and complete the reassembly in the reverse order to that used for dismantling. The damper rods can be retrieved with service tool No. 61-3765.

REMOVING THE FORK LEGS

Before commencing work on the forks it is advisable to have the following tools and replacements available:—

65-5451	Oil seal (2)
65-5424	Top bush (2)
29-5347	Lower bush (2)
61-3350	Service tool
61-3005	Service tool
61-3006	Service tool
61-3007	Service tool
61-3765	Service tool

and a length of No. 5 twine approximately 15 in. long.

Remove the front wheel as described on pages F.2 or F.5 according to the type of wheel fitted, then remove the front mudguard by taking out the bolts from the fork ends and midway up each leg.

Remove the two caps (A) Fig. E.3, and release the damper rods allowing them to drop down into the main tubes.

REMOVING THE HEADLAMP

Slacken off the slotted screw at the top of the headlamp rim and pull off the rim complete with glass and reflector. Remove the bulb connections.

Disconnect the leads to the ammeter and speedometer and pull out the harness plug from the lighting switch. Disconnect the dipper switch leads.

To remove the headlamp shell take out the two bolts securing the shell to the fork covers.

The harness complete with the socket plug can be pulled through the base of the lamp after the large grommet is removed.

Replacement of the lamp is simply a reversal of the removal procedure.




FIG. E.7. Fork tools.

On those models fitted with twin speedometer and rev-counter heads on a bracket above the forks, pull out the light bulbs and disconnect the drive cables after unscrewing the cable nipples.

Take out the two fixing screws with washers and remove the instrument heads and the bracket.




FIG. E.8. *Removing twin instruments.*

Drain the oil from the forks as described on page A.13. Screw service tool No. 61-3350 (minus the large nut and washer) into the top of the fork leg and slacken off the pinch bolt in the bottom fork yoke (D) Fig. E.1, page E.3.

On those models fitted with rubber gaiters remove the top clip, and push the top of the gaiter off the fork cover.

Now take a firm grasp of the lower sliding member with one hand and strike the top of the

tool sharply with a hammer or mallet, this will release the leg from its taper in the top yoke and the complete leg can be drawn down and removed from the machine. Repeat the operation on the other leg.

Spring Changing

At this stage—if not other work is required—the springs can be changed. All that is necessary is to pull out the old springs, apply a liberal coat of grease to the new springs and to replace.

Replacing the fork leg is described on page E.8.




FIG. E.9. *Removing fork leg.*

DISMANTLING THE LEG

To dismantle the lower section of the fork hold the sliding tube by gripping the wheel spindle lug in a soft-jawed vice. If rubber gaiters are fitted slacken off the clip and pull off the gaiter.

To remove the oil seal holder slide service tool No. 61-3005 over the main tube and enter the dogs in the slots at the bottom of the oil seal holder.

Pressing down firmly on the tool and turning anti-clockwise at the same time, unscrew the oil seal holder complete with the extension tube.

Remove the tool and slide the holder up the shaft until it becomes tight on the tapered section of the shaft, but do not use force or the oil seal may be damaged.

The spacer which retains the top bush in the sliding member, is now exposed and can be prised out with a sharp tool such as the tang end of a file.

After the spacer is removed the main tube complete with bushes can be withdrawn from the sliding member. There are no shims as in earlier models.

Grip the tube in a vice using soft clamps on the unground portion of the shaft and unscrew the nut at the lower end of the shaft.




FIG. E.10. *Removing oil seal holder.*

This nut secures the lower bush and after its removal the oil seal holder, spacer and bushes can be slid off the shaft.

The damper tube and rod are at this stage still attached to the lower sliding member by a $\frac{1}{8}$ in. socket screw in each fork.

To remove the screw an "Allen" key $\frac{7}{32}$ in. across the flats is required.




FIG. E.11. *Removing lower nut.*

The damper rod is retained by its top bush which is in turn retained by two circlips, one—which is obvious—in the slots and an inner one fitted above the bush. Both circlips must be removed before the rod and bush can be withdrawn from the tube.

Before removing the nut at the end of the rod, take careful note of the way the damper valve is assembled.

OIL SEALS

If it is necessary to change the oil seal, place the lower edge of the holder on a wooden block and enter service tool No. 61-3006 into the top of the holder, give the tool a sharp blow with the hammer and the seal will be driven out.

To fit a replacement seal, coat the outside with a good jointing compound and whilst still wet enter the seal squarely into the holder with the open side upwards and drive home with service tool No. 61-3007.

Great care is required to avoid damaging the feather-edge of the oil seal and this should be greased before reassembly.




FIG. E.12. *Removing oil seal.*

REBUILDING THE FORK LEG




FIG. E.13.

Reassembly is carried out in the reverse order to dismantling.

Cleanliness is essential and before attempting to reassemble, clean all parts thoroughly and the work bench on which the forks have been dismantled.

If the damper rod has been dismantled it must be reassembled in the order shown in Fig. E.13.

On some early models the top nut is brazed therefore the bush must be assembled first.

When assembled the valve seat (1) is locked against the collar (2) so that the valve (3) moves freely.

The valve must **not** be fitted the wrong way round.


Lower the damper tube into the sliding member and locate the slotted end over the drain screw, press the tube well down on to its seating and secure with the socket screw and washer. The damper rod assembly can now be fitted and the bush secured with circlips (4) and (5).

Slide the oil seal holder over the shaft until it is on the tapered section but do not use force or the seal may be damaged.

Place the spacer over the shaft followed by the top bush, then the bottom bush and finally the bottom nut.

Tighten the nut securely, grip the lower sliding tube in the vice and enter the mainshaft, with the assembled parts, into the sliding tube.

Screw down the oil seal holder on to one turn of twine round the groove at the end of the thread. This will provide an additional seal.

FIG. E.14. *Using the twine.*

Repeat the operations on the other leg. Before refitting the leg to the steering head, apply a liberal coating of grease to the spring and place the spring in position in the oil seal holder.

Replacing the Fork Leg

Now screw service tool No. 61-3350 minus the nut and collar—into the top of the tube and pass the tube up through the two yokes, fit the collar and nut and draw the tube firmly home into its taper.

Tighten the pinch bolt in the bottom yoke before removing the tool.

Using service tool No. 61-3765 locate the upper end of the damper rod and screw it back into the top cap. The rod and cap can be lifted sufficiently high to allow the oil to be added.

Repeat the operation on the other leg then refill with the correct amount of oil ($\frac{1}{3}$ pint to each leg), see page A.4 for grades, and replace the top caps.

Final assembly is simply the reversal of dismantling.




FIG. E.15. Using tool No. 61-3350.

FORK ALIGNMENT

It is possible, during reassembly of the forks, for them to be incorrectly aligned.

For this reason, after the mudguard has been replaced, replace the wheel so that the front spindle is screwed up tight into the right-hand leg but the pinch bolt in the left-hand leg is slack and the rest of the bolts, in the bottom yoke, top caps, and the pinch bolt in the top yoke are slackened off.

The forks should now be pumped up and down several times to line them up and then tightened up from bottom to top, that is, wheel spindle, bottom yoke pinch bolts, top caps, and finally the steering stem pinch bolt in the top yoke.

If the forks do not function satisfactorily after this treatment, either the fork tubes are bent or one of the yokes is twisted.




FIG. E.16. Testing for straightness.

The tubes can only be accurately checked for straightness with special equipment such as knife-edged rollers and dial gauges and special gauges are required to check the yokes.





FIG. E.17. Straightening.

It is possible however to take a reasonable check of the tubes by rolling them on a good flat surface such as a piece of plate-glass, but it is not a simple operation to straighten a bent tube, it is far better to obtain a factory-service unit if the owner is resident in the British Isles.

FIG. E.18. *Bottom yoke twisted.*

If the tube is obviously bent but not kinked, then it may be possible to effect a reasonable repair with patience and care.

Find the highest point on the bend then with the two ends resting on wood blocks and with a wood block to protect the tube from the hammer give the tube a hard blow and re-check. The measure of success will of course depend on the extent of the damage and the skill of the operator.

This job is vastly improved and simplified if a press is available to the repairer.

Having checked the tubes for straightness and reset as necessary, the top and bottom yokes can be checked.

First assemble the two tubes into the bottom yoke so that a straight edge across the lower ends is touching all four edges of the tubes, tighten the pinch bolts.

Now view them from the side, when the two tubes should be quite parallel, or, place the lower 12 in. of the tubes on a surface plate when there should be no rocking.

If the tubes are not parallel as in Fig. E.18, then the yoke can be set providing the error is not excessive.

To reset hold the one tube in a vice, on the unground portion, using soft clamps and set the

other tube using a longer and larger diameter piece of tube for leverage.


Having set the tubes one way, check the gap between them on the ground portion.

The next step is to place the top yoke in position when the steering column should be quite central, Fig. E.19 shows a bent steering column.

Final step is to check with the two tubes assembled into the top yoke only, in this case use the bottom yoke loosely assembled on the tubes simply as a pilot.

It is permissible to rectify slight errors in alignment by resetting, but when there is excessive malalignment it is safer to replace the part affected.

Works reconditioned forks are available to owners in the United Kingdom through the dealer network.

FIG. E.19. *Bent steering column.*

HYDRAULIC DAMPING

Figure E.20 shows a sectional view of the front forks extended. Note the four $\frac{3}{8}$ in. diameter bleed holes in the main tube and the transfer holes at the base of the damper tube.

When the forks are compressed, a double damping action takes place within each fork leg. As the fork leg rises, oil in the damper tube is compressed by the valve and is forced through the transfer holes, into the main tube. At the same time, the oil in the main tube is also being compressed and is forced upwards between the outside of the damper tube and the top tube bush. The pressure of the oil increases as the gap narrows around the tapered damper tube, progressively slowing the fork spring action.

When the top tube begins to fill with oil which can no longer be compressed, the oil passes through the bleed holes and into the area between the fork leg and top tube bushes. Eventually the point of maximum compression is reached and is cushioned by the remaining oil in the main reservoir.

As the fork leg begins to extend again, the oil in the area between the two fork bushes is compressed and forced through the four bleed holes, back into the main tube.

The damper valve, as it rises, causes a vacuum and draws oil into the damper tube, via the transfer holes, thus providing a smooth cushioned motion.

Exactly the same amount of oil should be in each leg otherwise damping will not be uniform. The correct quantity is $\frac{1}{3}$ of a pint to each leg.

If a sidecar is fitted stronger fork springs should be used; these are available through the dealer network.




FIG. E.20.

INDEX

	<i>Page</i>
FRONT WHEEL (QUICK-RELEASE HUB)	F.2-4
FRONT WHEEL (190 M.M. HUB)	F.5-6
FRONT WHEEL (TWIN-LEADING SHOE)	F.6-7
REAR WHEEL (QUICK-RELEASE HUB)	F.8-10
WHEEL BUILDING	F.11
WHEEL BALANCING	F.11-12
SECURITY BOLTS	F.12
WHEEL ALIGNMENT	F.13
RENEWING BRAKE LININGS	F.13-14
REMOVING AND REFITTING TYRES	F.14-17
TYRE MAINTENANCE	F.18
SIDECAR ALIGNMENT	F.19

FRONT WHEEL REMOVAL AND REPLACEMENT (QUICK-RELEASE HUB)

To remove the front wheel, first disconnect the cable from the lever on the cover plate. This can be done by removing the screw and nut attaching the cable toggle to the lever. Having released the toggle unscrew and remove the cable adjuster and cable (see Fig. F.1).




FIG. F.1. *Removing cable adjuster.*

Remove the brake anchor strap nut from the cover plate and slacken off the nuts at the other end to enable the removal of the strap from the plate.

Slacken off the pinch bolt in the left-hand fork end and using a bar through the head of the spindle unscrew the spindle in a clockwise direction (left-hand thread).

Support the wheel as the spindle is withdrawn and when it is clear the wheel can be pulled away from the right-hand leg and clear of the machine.

Try not to let the wheel fall on the brake side as this may displace the bush through the cover plate, if it does happen the bush can be retrieved and replaced with the wheel spindle.

Front Wheel Replacement

Lift the wheel between the fork legs and position the bush in the right-hand fork leg. Screw the spindle in anti-clockwise (left-hand thread) until it is nearly tight, position the brake plate and replace the anchor strap. Tighten the spindle then pump the forks up and down to position the left-hand leg and tighten the pinch bolt in the left-hand fork end.

Finally replace the brake cable and adjust as necessary using the adjuster on the cover plate.

The cable adjuster on the handlebar is for cable adjustment when riding.




FIG. F.2. *Replacing the spindle.*

FRONT BRAKE SHOES (QUICK-RELEASE HUB)

The brake plate (A) is a push-fit on the bush (B) (see Fig. F.3).

To remove the brake shoes lever them upwards and outwards off the cam and fulcrum pin.

The shoes are of the conventional type (not floating) but are not interchangeable. Since one shoe is leading and the other trailing they must be fitted with the narrow side (relative to centre web) next to the brake plate.

1965 and earlier shoes will fit 1966 drums but being narrower will not be so efficient.

1966 shoes will not fit earlier drums.

Replacement brake shoes are available through the Exchange Service in the British Isles, but for those who cannot use this service the notes on relining on page F.13 may be of some assistance.

A grease nipple is provided for lubricating the cam spindle and it is advisable to check that the hole is not blocked by dirt. Be careful not to over-lubricate, grease must not get on to the linings.




FIG. F.3. Section of front hub.

FRONT HUB DISMANTLING (QUICK-RELEASE HUB)

Pull off the brake plate and remove the split-pins at each side of the hub. Unscrew the bearing retainers which have normal right-hand threads.




FIG. F.4. *Removing split-pin.*




FIG. F.5. *Fitting new bearing.*

Replace the spindle and drive out the brake side bearing together with the bush (B) by striking

the head of the spindle with a hide-mallet. If a mallet is not available use a piece of hardwood to protect the spindle.

Only the left-hand bearing remains and this can be driven out with a suitable drift or with the spindle and bush reversed.

Both bearings are the same size and therefore interchangeable.

Replacement bearings are simply fitted in the reverse manner but, pressure must only be applied to the outer ring of the bearing.




FIG. F.6.

See that the rubber grease retainers are in good condition and that the retainers are screwed down quite tight. If necessary drill new holes for the split-pin.

Note that the retainer with the large hole is fitted on the brake side.

**FRONT WHEEL
(190 mm. BRAKE)**

The 190 millimetre diameter front brake is fitted as standard to the 1966 Spitfire Mk. II Special model, but, it can be used on any of the 1966 range of models.

The advantage of the brake is that there is a greater braking area—32 square inches—and the shoes operate centrally in the hub, thus providing a very efficient brake for high speed work.

Wheel Removal and Replacement

Removal and replacement of the 190 mm. brake front wheel is exactly the same as for the standard quick-release type front wheel described in detail on page F.2.

After replacing the wheel always check that the anchor strap nuts and bolts are absolutely secure.




FIG. F.7. Section of 190 mm. hub.

BRAKE SHOES (190 mm.)

The brake plate (A) is a push-fit over the bush (B) Fig. F.7.

To remove the shoes lever them upwards and outwards off the cam and fulcrum pins, or, the shoes can be removed complete with the cam and fulcrum pins after the nuts have been removed from the outside of the plate.

The shoes are of cast aluminium and are interchangeable. Replacement brake shoes can be obtained through the Exchange Service but for those who cannot use the service, the notes on relining on page F.13 may be of some assistance.

There is a grease nipple in the cover plate, for lubricating the cam spindle, and it is advisable to

check that the hole in the spindle is not blocked by dirt.

Always be careful not to over-lubricate, grease must not get on to the linings.

Dismantling

Dismantling and renewal of bearings and retainers is exactly the same as for the quick-release hubs detailed on page F.4, indeed the bearings and retainers are the same.

The only difference is that the brake drum is secured to the left-hand spoke flange by five $\frac{1}{4}$ in. B.S.F. socket screws.

The drum and flange should not be separated and the screws must always be kept tight.

FRONT WHEEL
(TWIN-LEADING SHOE)

The advantages of this brake is that with twin-leading shoes a greater effective pressure is obtained, this and the cooling window on the brake plate constitutes a highly efficient and long lasting brake.

Removal of Twin-leading Shoe Front Brake

This brake is only fitted to the 1968 A65 Lightning, Spitfire Mk. 4 Special, and Firebird Scrambler models which have clamp bottom forks. To remove the wheel, first disconnect the front brake cable from the lever on the brake anchor plate, this can be done by removing the brake cable spring pin and detaching the cable end from the cable stop, unscrew the four clamp bolts (two each side), take clamps off and remove wheel.

Front Wheel Replacement

Lift the wheel between the forks and locate the peg on the fork leg to the slot on the brake plate, at the same time locating the spindle in the fork bottoms, then pull down on the forks so that they hold the wheel while the caps are refitted. Fully tighten the offside cap making sure that the brake anchor dogs are fully located, then pump the forks up and down to position the nearside leg and tighten the bolts in the nearside cap.

Finally replace the brake cable and adjust if necessary using the adjuster on the handlebars. The tie rod between the brake cam levers is accurately set for correct operation before the machine leaves the factory, no attempt should be made to alter this setting.

FRONT HUB DISMANTLING (TWIN-LEADING SHOE — 1968)

Unscrew brake plate retaining nut and pull off plate complete with brake shoes. Unscrew bearing retainer on offside and remove circlip from the nearside. Now from the nearside drive out offside bearing by striking the end of the spindle with a hide-mallet. If a mallet is not available use a piece of hard wood to protect the spindle.

When the bearing has been removed from the spindle, replace the latter back in the hub and drive out the nearside bearing and dust cap.

Both bearings are the same size and therefore interchangeable.

Replacement bearings are simply fitted in the reverse manner but pressure must only be applied to the outer ring of the bearing. Also make certain that the grease retainer and backing ring are in position behind the bearings on the offside, and the grease retainer is behind the bearing on the nearside.

Front Brake Shoes (twin-leading shoe)

The brake plate is a push-fit on the spindle and retained with a nut.

To remove the brake shoes lever them upwards and outwards of the cams and fulcrum blocks.

The shoes are interchangeable, when refitting the shoes make sure the two abutment pads are in position on the fulcrum blocks.

Replacement brake shoes are available through the Exchange Service in the British Isles, but for those who cannot use this service, the notes on relining on page F.13 may be of some use.

A grease nipple is provided on the end of each cam spindle for lubricating the same. It is advisable to check that the holes are not blocked by dirt. Be careful not to over-lubricate, grease must not come in contact with the linings.




FIG. F.8. *Twin-leading shoe front brake (1968).*

REAR WHEEL REMOVAL (QUICK-RELEASE HUB)

The rear wheel can be removed without any effect on the brake adjustment or chain. Remove the spindle using a bar through the head, screwing anti-clockwise (right-hand thread). If the bush on the right-hand side does not fall clear, take it away then pull the wheel away from the brake drum and clear of the machine.

Do not unscrew the spindle nut on the left-hand side.




FIG. F.9. *Removing rear wheel.*

HUB SHELL BEARINGS

Insert a small diameter bar across the speedometer drive slots and unscrew the end cover.

The hub is fitted with two bearings which are a light press-fit on to the hollow spindle and into the hub shell. They are both the same size as the bearing used in the brake drum.

To remove the bearings unscrew the retaining ring on the left-hand side, this has a left-hand thread and is therefore turned in a clockwise direction.

Using a drift slightly under .875 in. diameter drive out the hollow spindle from the left-hand side, releasing the right-hand bearing short distance piece, inner collar, pen steel washer and the dust covers from the right-hand side.

The left-hand bearing with its thrust washer can now be driven out from the right-hand side.




FIG. F.10. *Bearing retainer.*

To examine the bearings, wash thoroughly in paraffin and blow out with a high pressure air line if possible. Examine carefully for signs of roughness indicating broken balls or damaged tracks, or excessive play.

Reassembly is simply the reverse of dismantling but, when pressing the bearings in, apply pressure only to the outside ring of the bearing and ensure that the retainer on the left-hand side is quite tight.

Note that the short end of the hollow spindle is on the left-hand side.




FIG. F.11. Section through rear hub.

REAR BRAKE DRUM (QUICK-RELEASE HUB)

The brake drum is retained in the fork end by the spindle nut and the nut securing the brake anchor strap to the lower chainguard bolt. This latter nut is self-locking, always replace on re-assembly.

To remove the drum, disconnect the rear chain and the brake rod, remove the spindle nut and the nut at the rear of the lower chainguard bolt. The complete assembly can now be removed from the fork end.

The brake plate and distance piece can be lifted from the spindle complete with the brake shoes. There is no need to disturb the cam spindle unless it is to be replaced in which case the position of the outrigger strap, spring, bush and lever should be noted for reassembly.

The brake shoes can be removed and replaced in the usual way and to remove the bearing take off the large distance piece, drive the spindle through and remove the bearing circlip from the

rear of the drum. The bearing can now be driven out from the front of the drum using a suitable drift.




FIG. F.12. Removing bearing circlip.

The rivets of the brake linings must be well below the surface, if any rivets are flush with the linings the drum will be scored and braking efficiency impaired.

Reassembly is simply the reverse of dismantling but, do not omit to grease the bearing, or replace the pen steel washer under the circlip so that it seats on the outer ring of the bearing, not the inner ring.

There should be no need to disturb the driving flange unless it is known to be worn and is being replaced.

To remove the flange flatten the locking plates and remove the six nuts, drive out the six bolts and remove the flange. When fitting the new flange see that it enters the drum squarely and that the mating faces are absolutely clean before replacing the six bolts. Do not omit to turn over the locking plates after tightening the nuts.




FIG. F.13. Replacing the drum.

DRUM REPLACEMENT

See that spindle is pressed well into the bearing, place the distance piece in position with the small diameter next to the bearing, then replace the cover plate complete with brake shoes. Fit the outer distance piece and place the assembly in the fork end.

If the chain adjustment was correct there is no need to make any alteration now but, do not tighten the spindle nut until the wheel has been replaced so that the whole assembly is in alignment.

Do not omit the nut from the brake anchor strap and chainguard bolt.

WHEEL REPLACEMENT

See that the dust covers are secure and that the rubber seal is in position on the left-hand side of the hub. If this seal is omitted, water can enter the driving flange and bearings and will make wheel removal difficult in addition to damaging the bearings.

Refit the speedometer gearbox and check that the driving pegs locate with the slot in the hub end cover.

Lift the wheel and engage the splines in the driver, push the wheel well home, and replace the right-hand outer collar, screw in the wheel spindle and secure so that the speedometer drive is in line with the swinging arm and facing forward.

Reconnect the speedometer cable.

If the brake drum has been removed, tighten the spindle nut and the anchor strap nuts.




FIG. F.14. Tightening the spindle.

WHEEL BUILDING

This is a job which is best left to the specialist as it is essential that the wheel is laced correctly and that when truing, the spokes are correctly tensioned.

It is however, possible for the less experienced to avoid trouble by periodically examining the wheels. As spokes and nipples bed down the tension will be lost and unless this is corrected the spokes will chafe and ultimately break.

Periodically test the tension either by "ringing" that is striking with a metal tool or by placing the fingers and thumb of one hand over two spokes at a time and pressing them together.

If tension has been lost there will be no ringing tone and the spokes will move freely across each other.

When a spoke needs tensioning the nipple through the rim must be screwed further on to the spoke but, at the same time, the truth of the wheel must be checked and it may be necessary to ease the tension at another part of the wheel in order to maintain its truth.

It will therefore be obvious that spoke replacement, spoke tensioning or wheel truing are not

operations to be treated lightly.

Careful examination of the wheel will show that for every spoke there is another pulling in the opposite direction and that the adjacent spoke goes to the opposite side of the hub.

Increasing the tension tends to pull the rim so, to counteract this, it is sometimes necessary to increase the tension on the spoke or spokes either side to maintain the truth of the wheel.

With a little care and patience it is possible for the unskilled to at least re-tension the spokes but, turn each nipple only a little at a time as, when once the spoke is under tension only a fraction of a turn is sometimes sufficient to throw the rim badly out of truth.

Quick-release rear wheels, are built with the rim central to the spoke flanges.

Quick-release front wheels are built with the edge of the brake drum 1-15/16 in. from the centre line of the rim.

190 mm. brake wheels using WM2 or WM1 alloy or steel rims are built with the edge of the rim $\frac{7}{8}$ in. from the right-hand hub barrel end.

WHEEL BALANCING

When a wheel is out of balance it means that there is more weight in one part than in another. This is very often due to variation in the tyre and at moderate speeds will not be noticed but at high speeds it can be very serious, particularly if the front wheel is affected.

Weights are available for attaching to the spokes to counteract any out-of-balance but, before starting, ensure that the wheel is absolutely free and revolves quite easily. If the rear wheel is being treated remove the driving chain.

With the wheel clear of the ground spin it slowly and allow it to stop on its own. Now mark the top of the wheel or tyre and repeat two or three times to check.




FIG. F.15. Balance weights.

If the wheel stops in the same place the extra weight must be added at the marked spot.

The next step is to ascertain how much weight is to be added, this can be done by sticking small pieces of plasticine to the nipples and re-check until the wheel will stop in any position without moving.

Having ascertained how much weight is required, a balance weight of exactly the same amount must be attached to the spokes at the spot originally marked.

If security bolts are to be used they should be fitted before balancing.

SECURITY BOLTS

Sometimes, particularly if a tyre is under-inflated, it will creep round the rim taking the tube with it and if not stopped will ultimately cause the valve to be pulled from the tube.

Therefore on high performance models it is usual to fit two security bolts equidistant round the rim from the valve, that is at 120° each side of the valve. Security bolts are not required on Spitfire Mk. II Special model, as the alloy wheel rims have "non-creep" serrations on the bearing flanges.

To fit the bolts remove the tyre and tube, mark




FIG. F.16. Tyre creeping.




FIG. F.17. Security bolt.

the rim positions and drill the rim between two nipples to the required size of the bolt.

After removing any burr from the holes, fit the bolts quite loosely and replace the tyre so that the covered portion of the security bolt is inside the tyre.

Check that the tyre is correctly positioned, inflate to the required pressure and tighten the bolt nuts on to the rim.

WHEEL ALIGNMENT

Steering will be affected if the wheels are the slightest bit out of alignment (out of track).

Since the front wheel cannot be adjusted in this respect, it is the rear wheel which must be aligned to the front wheel. This is necessary whenever the chain is adjusted or the wheel removed. It is necessary to adjust the rear brake whenever re-alignment has been carried out.




FIG. F.18. *Checking alignment.*

To check the alignment of the wheels a straight edge of timber or steel is required approximately 78 in. long.

The straight edge should be laid on blocks four to six inches high (alternately) each side of the machine.

If the tyres are the same size and the wheels in alignment the straight edge will be touching the tyres at four points on each side.

If the front tyre is of smaller section then it should be as drawing (B) Fig. F.18.

If the alignment is as either (A) or (C) then the rear chain adjusters must be moved as indicated by the arrows to correct the alignment.

Assuming that the chain adjustment is correct the movement of the rear wheel will be made on the right-hand side chain adjuster which should be screwed in or out as necessary after the spindle nuts have been slackened off.

A machine suffering accidental damage may have wheels so out of alignment that they cannot be corrected in this way. Frame, fork or wheel geometry may be basically upset, in these cases a specialist repairer can probably reset any offending assembly using information in Section D.

RENEWING BRAKE LININGS

Hold the shoe firmly in a vice and using a good sharp chisel cut off the peened over portion of the rivet.

Drive out the old rivets with a suitable pin punch. Reverse the shoe in the vice and draw-file the face of the shoe to remove any burrs.

Clamp the new lining in position and drill straight through with 5/32 in. diameter drill using the holes in the shoes as the jig.

Remove the clamps and holding the lining carefully in the vice counterbore or countersink, according to the type of rivet used, to no more than two-thirds the thickness of the lining, that is, if the lining is $\frac{3}{16}$ in. thick, then the counterbore must not be deeper than $\frac{1}{8}$ in.

Having prepared the linings for riveting, start at the centre and position the lining with one or more rivets.

Using either small "G" or toolmakers clamps close to the rivets and with a suitable mandrel in the vice, peen over the rivets working alternately outwards from the centre.

The mandrel in the vice must be flat on the end and the diameter no more than that of the rivet head. It will also help to bed the rivet down if a hollow punch is used before peening.

If the clamps are used correctly, that is, next to the rivet being worked on, the linings can be fitted tight to the shoe.




FIG. F.19. *Chopping out the rivets.*




FIG. F.20. *Peening over rivets.*

Incorrectly fitted linings having a gap between the lining and the shoe will result in a spongy brake.

When the riveting is completed file a good chamfer at each end to approximately half the depth of the lining and lightly draw-file the rest of the lining to remove any fraze from the drilling.

REMOVING AND REFITTING TYRES

TYRE REMOVAL

There are a few points about tyres which should be thoroughly understood.

- (1) The beads have wire cores which cannot be stretched over the rim flanges without damage.
- (2) Removal and replacement will be simpler if the beads are pressed right down into the well of the rim except at the point being "worked". The well is the centre section.
- (3) The tyre beads will slip over the rim quicker and damage will be avoided if the beads and the levers are lubricated with soapy water.

Unscrew and remove the valve core to deflate the tyre.

Some valve caps are designed for this purpose but, if the cap is plain and a core removal tool is not available, depress the centre of the valve and keep "treading" the tyre to expel the air.

Press each bead off its seat into the well of the rim.

Insert the lever at the valve position, and while levering, press the bead into the well diametrically opposite the valve.





FIG. F.21.

Commencing to remove the first bead. You cannot pull the cover bead at (A) over the rim flange until the cover bead at (B) is pushed off the bead seat (C) down into the well (D). Then the cover bead at (A) comes over the rim flange easily.

Insert a second lever close to the first and prise the bead over the flange holding the free part with the other lever.

Remove one lever and insert further along the tyre continuing every two to three inches until the bead is completely removed (see Fig. F.22).

FIG. F.22. *Removing the first bead.*

Take care when inserting levers not to pinch the inner tube as this will result in a puncture.

Lift the valve out of the rim and remove the tube.




FIG. F.23.

Stand the wheel upright, insert a lever between the remaining bead and the rim and pull the cover back over the flange as in Fig. F.23. Do not forget to press the bead diametrically opposite the lever into the centre of the rim and to apply a soapy solution to the rim flange.

TYRE REPLACEMENT

Before a tyre—new or used—is replaced, it should be carefully checked inside and outside for loose objects or nails, flints, glass and cuts. Do not forget that although there may be nothing visible outside there could be a nail projecting inside. When repairing a tyre or tube be patient and see that the area of the repair is absolutely clean before applying solution. A rag dampened with petrol will help to clean the area but, it must be completely dry before solution is applied.

Remember that when replacing the tyre, it is very easy to cause another puncture by nipping the inner tube with the levers.



FIG. F.24. *Cover and tube assembled ready for fitting.*

Some new tyres have balance adjustment rubbers inside the casing, they are not patches and should not be disturbed.

When there is a white spot near the bead it should be placed at the valve position or, if two security bolts are fitted, midway between the bolts.

If the spokes have been tensioned, or replaced, see that they are not projecting through the nipples. File flush any that are showing through.

Replace the rim tape with the rough side next to the rim. Place the tube in the tyre and inflate just sufficient to round it out without stretch.




FIG. F.25. *Commencing to fit the tyre.*

Too much air makes fitting difficult, and too little will make the tube more liable to be nipped by the levers. Dust the tube and inside the cover with dusting chalk.

Lubricate the cover beads and the rim flanges with a soap and water solution or liquid soap.

Pull the tube slightly out of the cover so that it protrudes about 1 in. beyond the beads for about 4 - 5 in. each side the valve as in Fig. F.24.

Squeeze the beads together at the valve to prevent the tube slipping back and offer the cover to the rim as shown in Fig. F.25, at the same time passing the valve through the holes in the tape and rim.




FIG. F.26. *Fitting the first bead.*




FIG. F.27. *Completing the fitting of the first bead.*

Allow the lower bead to go into the well of the rim and the upper bead to be above the rim flange.

Working from the valve outwards, press the lower bead over the rim flange by hand, moving along in short stretches, and ensuring that the bead lies right down in the well of the rim—this is most important—see Fig. F.26. If necessary use a tyre lever for the last few inches as in Fig. F.27.

Turn the wheel over and check that the bead is concentric with the rim before proceeding further.

Reverse the wheel again and press the upper bead into the well of the rim diametrically opposite the valve.

Insert a lever as close as possible to the point where the bead passes over the flange, and lever the bead over at the same time pressing the fitted part into the well of the rim.

Repeat progressively round the tyre until the bead is completely over the flange, finishing at the valve (see Fig. F.28).

Push the valve inwards to ensure that the tube adjacent to the valve is not trapped under the bead, then pull the valve back firmly into position. If security bolts are fitted treat as valve.

Before inflating, check that the fitting line on the tyre wall just above the bead on each side is concentric with the rim.

If necessary bounce the wheel to help seat the tyre but, see that there is adequate pressure to prevent damaging the tyre or tube and only use moderate force. If the tyre will not seat, it is better to release the pressure, apply soap solution to lubricate and re-inflate.

Inflate to the required pressure and check fitting lines again. Inflation should not be too rapid, particularly at the commencement, to allow the beads to seat correctly on the rim.

See that the valve protrudes squarely through the valve hole before screwing down the knurled nut and replace the dust cap.

Tighten down the security bolts (if fitted).




FIG. F.28. *Completing the fitting of the second bead.*

TYRE MAINTENANCE

Always maintain correct inflation pressures (see page GD.10). Use a tyre pressure gauge and check weekly when tyres are cold. The pressures quoted in the data pages are for a rider of 140 lbs. weight. If the rider's weight exceeds 140 lbs. pressure should be increased as follows:—

FRONT TYRE:—Add 1 lb. per square inch for every 28 lbs. above 140 lbs.

REAR TYRE:—Add 1 lb. per square inch for every 14 lbs. above 140 lbs.

For sustained high speeds normal pressures should be increased by 5 lbs. per square inch. If a pillion passenger or luggage is carried, the actual load on each tyre should be taken and the pressures increased in accordance with the table below. The load on each tyre can be found by placing each wheel in turn on a weighbridge with the rider or riders astride the machine.

Pressure should then be adjusted to the chart.

18, 19, 20 AND 21 INCH DIAMETER RIMS

Nominal Tyre Section (inches)	Inflation pressure (lb. per sq. in.)					
	16	18	20	24	28	32
	Load Per Tyre (lb.)					
3.00	160	185	210	255	300	350
3.25	200	230	260	320	380	440
3.50	280	310	335	390	450	500
4.00	260	395	430	500	570	640

SIDECAR ALIGNMENT

Alignment of the front and rear wheels has been described on page F.13 and the two straight edges used can also be used for aligning the sidecar.

The combination must stand on a flat smooth surface such as concrete or paving; place one of the straight edges against the front and rear wheels and the other against the sidecar wheel as Fig. F.29.




FIG. F.29. "Toe-in."

Straighten the front wheel so that it touches the straight edge at each side or, if the front tyre is of smaller section, the gap is equal each side.

It is of course useless trying to align a sidecar if the front and rear wheels are not in alignment. Now measure the distance between the straight edges at (A) and (B). The distance in front at (B) should be $\frac{3}{8}$ in. to $\frac{3}{4}$ in. less than at (A). If the alignment is incorrect adjustment is usually made at the front lower coupling and it is known as "toe-in."

In addition to aligning the wheels horizontally, the machine should also be aligned vertically, if the maximum enjoyment is to be obtained from the outfit.

The machine should "lean out" approximately 1 in. from the vertical.

To check, hang a plumb-line from the handle-bar, and measure the distance between top and bottom as in Fig. F.30.

Any adjustment necessary is usually carried out at the two upper sidecar connections. The measurement at (C) the top should be approximately 1 in. greater than at the bottom and should never be less.

If the machine is leaning inwards then the couplings must be adjusted to push the machine further out. To do this it may be necessary to move the connections along the sidecar chassis towards the machine, this however will depend on the type of sidecar used.




FIG. F.30. Vertical alignment.

INDEX

	<i>Page</i>
INTRODUCTION	G.2
ALTERNATOR	G.2
BATTERY INSPECTION AND MAINTENANCE	G.2-5
Description	G.2
(A) Dry Charged Batteries	G.3
(B) Routine Maintenance	G.3-5
COIL IGNITION SYSTEM	G.5-9
Description	G.5
(A) Checking the Low-tension Circuit for Continuity	G.5
(B) Fault Finding in the Low-tension Circuit	G.5-7
(C) Ignition Coils	G.7
(D) Contact Breaker	G.7-9
(E) Checking the High-tension Circuit	G.9
SPARKING PLUGS	G.9-11
CHARGING SYSTEM	G.11-15
Description	G.11
(A) Checking the D.C. Input to Battery	G.11
(B) Checking the Alternator Output	G.12
(C) Rectifier Maintenance and Testing	G.12-14
(D) Checking the Charging Circuit for Continuity	G.15
(E) Making a 1 ohm Load Resistor	G.15
ZENER DIODE CHARGE CONTROL	G.15-18
A.C. IGNITION (E.T.) AND A.C. LIGHTING SYSTEMS	G.18-21
Description	G.18
(A) A.C. Ignition	G.19-20
(B) Testing the A.C. Ignition System	G.20
(C) Checking the A.C. Alternator Output	G.20-21
(D) Direct Lighting System	G.21
ELECTRIC HORN	G.22
HEADLAMP	G.22
Description	G.22
Beam Adjustments	G.23
TAIL AND STOP LAMP UNIT	G.23
ADDITIONAL INFORMATION	G.23-24
ALTERNATOR AND STATOR DETAILS (Specifications and Output Figures)	G.24
WIRING DIAGRAMS	G.25-28
A.C. Ignition (E.T.) Machines 1966-67	G.25
1968 Firebird Scrambler for use with Capacitor	G.26
1968 A50 and A65 Coil Ignition (12 volt)—except Firebird Scrambler	G.27
1966/67 Coil Ignition (12 volt)	G.28

INTRODUCTION

The electrical system is supplied from an alternating current generator contained in the primary chaincase and driven from the crankshaft. Alternator model RM19 or RM21 is employed. For special purpose models fitted with two-way radio, or other additional current-consuming equipment, alternator RM20/19 provides the increased output necessary to balance the greater electrical loading. The generator output may be controlled by the lighting and ignition switches or (as with some RM19 and all RM21 alternators) a Zener Diode.

1966 models are 12 volt machines and have two MKZ9E batteries of 7 amp./hour at 10 hour rate or 8 amp./hour at 20 hour rate (later models are fitted with one PUZ5A 12 volt battery) con-

nected in series, with Zener Diode in circuit to regulate the battery current.

The current is then supplied to the ignition system which is controlled by a double contact breaker (model 4CA 1966-67 models and model 6CA 1968 models) driven from the timing idler gear.

The contact breaker feeds two model MA12 ignition coils, one for each cylinder.

The routine maintenance needed by the various components is set out in the following sections. All electrical components and connections including the earthing points to the frame of the machine must be clean and tight.

ALTERNATOR

The alternator consists of a spigot-mounted 6 coil laminated stator (which may be encapsulated) with a rotor carried on and driven by an extension of the crankshaft. The rotor has an hexagonal steel core, each face of which carries a high-energy permanent magnet keyed to a laminated pole tip. The pole tips are riveted circumferentially to brass or aluminium side plates, the assembly being cast in aluminium and machined to give a smooth external finish.

There are no rotating windings, commutator,

brushgear, bearings or oil seals and consequently the alternator requires no maintenance apart from occasionally checking that the snap connectors in the output cables are clean and tight.

If rotor removal is necessary, there is no need to fit magnetic keepers to the rotor poles. When removed, wipe off any swarf which may have been attracted to the pole tips and put the rotor in a clean place until required for refitting.

BATTERY INSPECTION AND MAINTENANCE

Battery model MKZ9E is a six volt unit and two are connected in series to give 12 volts. Later machines have one 12 volt battery. These are known as PUZ5A models.

The battery containers are moulded in translucent polystyrene through which the electro-

lyte can be seen. A coloured line on the side of the battery indicates the correct level at which the electrolyte must be maintained. In the case of model PUZ5A battery, polythene tubing is attached to the battery to lead the corrosive fumes away from any parts of the machine where they might cause damage.

G1. PART A**Dry Charged Batteries**

Battery models PUZ5A and MK9E are supplied dry-charged.

If a battery is required ready for use (filled with electrolyte) the model numbers are PU5A and MK9E. This is because the "Z" in each case indicates that the battery is dry.

In every case throughout this manual both battery models will be referred to as PUZ5A and MKZ9E.

These batteries leave the factory in the fully "dry-charged" condition. The following filling instructions must be carefully observed:—

With the acid battery and room temperature between 60°F and 100°F (15.5—37.7°C), remove the vent plugs and fill each cell in one operation to the coloured marker line with acid (electrolyte) of the correct strength.

Measure the temperature and specific gravity of the electrolyte in each of the cells.

Allow to stand for 20 minutes and again re-check the temperature and specific gravity of the electrolyte in each cell and compare the readings with those previously taken.

The battery is then ready for service unless the above checks show the electrolyte temperature to have risen by more than 10°F (5.5°C) or the specific gravity to have fallen by more than 10 "points", i.e., by more than 0.010 specific gravity. In this event, it will be necessary to recharge the battery at the appropriate charge rate (0.7 amperes) until the specific gravity values

remain constant for three successive hourly readings and all cells are gassing freely.

During charging, keep the electrolyte in each cell level with the coloured marker line by adding distilled water not acid.

G1. PART B.**Routine Maintenance**

Every 1,000 miles (1,600 km.) or monthly, or more regularly in hot climates wipe away dirt and moisture from the top of the battery.

Examine the terminals; if they are corroded scrape them clean and smear them with a film of petroleum jelly, or with a silicone grease.

The level of the electrolyte in each cell should be checked weekly or every 250 miles. If necessary lift the battery out of the carrier so that the coloured filling line can be seen. Add distilled water until the electrolyte reaches this line. NOTE:—On no account should the batteries be topped-up to the separator guard but only to the coloured line.

With this type of battery, the electrolyte can only be reached by a miniature hydrometer, which would indicate the state of charge. In some cases it may be necessary to tilt the battery to bring sufficient electrolyte above the separator guard. A reading should not be taken after adding distilled water, until the battery has been on charge for at least 30 minutes.

Great care should be taken when carrying out these operations not to spill any electrolyte or allow a naked flame near the battery. The mixture of oxygen and hydrogen given off by a battery on charge, and to a lesser extent when standing idle, can be dangerously explosive.




FIG. G.1. Battery (MKZ9E).




FIG. G.1A. Battery (PUZ5A).

The readings obtained from the battery electrolyte should be compared with those given in table A, page G.4. If a battery is suspected to

be faulty it is advisable to have it checked by a Lucas depot or agent.

A lead-acid battery slowly loses its charge whilst standing—the rate of loss being greater in hot climates. If a battery is not being used, it is important to give it freshening charges at the appropriate recharge rate mentioned in Section G1, Part A. These should be given fortnightly in temperate climates and weekly in the tropics.

(A) Specific Gravity of Electrolyte for filling Batteries MKZ9E and PUZ5A.

U.K. and climates normally below 80°F. (26.6°C.)		Tropical climates over 80°F. (26.6°C.)	
Filling	Fully charged	Filling	Fully charged
1.260	1.270—1.290	1.210	1.210—1.230

To obtain a specific gravity strength of 1.260 at 60°F (15.5°C), add one part by volume of 1.840 specific gravity acid to 3.2 parts of distilled water.

To obtain a specific gravity strength of 1.210 at 60°F (15.5°C), add one part by volume of 1.840 specific gravity acid to 4.3 parts of distilled water.

(B) Maximum Permissible Electrolyte Temperature During Charge.

Climates normally below 80°F. (27°C.)	Climates between 80—100°F. (27—38°C.)	Climates frequently above 100°F. (38°C.)
100°F. (38°C.)	110°F. (43°C.)	120°F. (49°C.)

Notes

The specific gravity of the electrolyte varies with the temperature. For convenience in comparing

specific gravities, they are always corrected to 60°F, which is adopted as a reference temperature. The method of correction is as follows.

For every 5°F below 60°F deduct .002 from the observed reading to obtain the true specific gravity at 60°F. For every 5°F above 60°F, add .002 to the observed reading to obtain the true

specific gravity at 60°F.

The temperature must be indicated by a thermometer having its bulb actually immersed in the electrolyte and not the ambient temperature. To take a temperature reading tilt the battery sideways and then insert the thermometer.

COIL IGNITION SYSTEM

Description

The coil ignition system comprises two ignition coils and a contact breaker fitted in the timing cover and driven by the idler pinion. The ignition coils are mounted at the rear of the engine one either side of the frame tubes. Access to the coils is achieved by removing the sidecovers (see page D.9). Apart from cleaning the coils inbetween the terminals and checking the low-tension and high-tension connections, the coils will not require any other attention. Testing the ignition coils is amply covered in G2, Part C, page G7, whilst testing the contact breaker is described in G2, Part D.

The best method of approach to a faulty ignition system, is that of first checking the low-tension circuit for continuity as shown in G2, Part A, and then following the procedure laid out in G2, Part B, to locate the fault(s).

Failure to locate a fault in the low-tension circuit indicates that the high-tension circuit or sparking plugs are faulty, and the procedure detailed in G2, Part E, must be followed. Before commencing any of the following tests, however, the contact breaker and sparking plugs must be cleaned and adjusted to eliminate this possible source of fault.

G2. PART A.

Checking the Low-tension Circuit for Continuity

To check whether there is a fault in the low-

tension circuit and to locate its position, the following tests should be carried out:—

Disconnect and remove the fuel tank (page B.5) removing the white lead which connects the (—) terminals of the left and right ignition coils. Then, with the wiring harness white lead connected to the (—) terminal of the left ignition coil only, turn the ignition switch to the IGN position. Slowly crank the engine and at the same time observe the ammeter needle, which should fluctuate between zero and a slight discharge, as the contacts open and close respectively.

Disconnect the wiring harness white lead from the left ignition coil and connect it to the SW terminal of the right ignition coil and then repeat the test. If the ammeter needle does not fluctuate in the described way when carrying out both tests, then a fault in either the low-tension circuit or one of the coils is indicated.

First, examine the contact breaker contacts for pitting, piling or presence of oxidation, oil or dirt etc. Clean and ensure that the gap is set correctly to .014—.016 in. (.35—.40 mm.) as described on page B.28.

G2. PART B.

Fault Finding in the Low-tension Circuit

To trace a fault in the low-tension circuit, crank the engine until both sets of contacts are opened,

or alternatively, place a piece of insulating material between both sets of contacts whilst the following test is carried out:—

For this test it is assumed that the fuel tank is removed and the wiring is fully connected as shown in the appropriate wiring diagram, pages G25—G28. With the aid of a 0—15 volt D.C. voltmeter and two test-prods make a point to point check along the low-tension circuit starting at the battery and working right through to the ignition coils, stage by stage, in the following manner.

NOTE:—The following tests assume that the Zener Diode, alternator rectifier or the emergency start capacitor (when fitted) is not the cause of battery-supply-voltage failure, failure of these units being either indicated by a discharge shown on the ammeter or a blown fuse (when fitted) proceed to paragraph 1. It is also assumed that at this stage it would be known (either by tests carried out in Section G2, Part A, or by obvious lack of high-tension voltage at the sparking plug(s)—whether the fault affected the operation of both sparking plugs or was confined to one only. In the former case proceed to paragraph 1, and in the latter case paragraph 6.

- (1) First, establish that the battery is earthed correctly by connecting the voltmeter across the battery negative terminal and the machine frame earth. No voltage or lower than battery voltage reading indicates that the red earthing lead or connection is faulty.
- (2) Turn the ignition switch to the IGN position and connect the voltmeter between either the left ignition coil (—) terminal and earth or the right ignition coil (—) terminal and earth, when battery voltage should be indicated (proceed to paragraph 6). No voltage reading indicates a circuit breakdown between the battery and both coil (—) terminals (proceed to paragraph 3).
- (3) Connect the voltmeter between both of the ammeter terminals in turn or, both sides of the fuse (when fitted) and earth. No reading

on the "load" side indicates that either the ammeter or fuse is faulty or there is a bad connection associated with the brown and blue lead from the battery, and a reading on the "battery" side only, indicates a faulty ammeter or fuse (ascertain and rectify the cause of failure).

- (4) Connect the voltmeter between ignition switch "feed" terminal and earth. No reading indicates that the brown and white (or brown and blue) lead between switch and ammeter, or fuse, has faulty connections.
- (5) Connect the voltmeter across ignition switch "load" terminal and earth. No reading indicates that the ignition switch is faulty and should be replaced. Battery voltage reading at this point but not at the ignition coil (—) terminals indicates that the white lead has become "open circuit" (broken or disconnected).
- (6) Check whether the interconnecting cable between each coil is satisfactory, then disconnect the black/white, and black/yellow lead(s) from the (+) terminal(s) of the ignition coil(s) or the one (if known) associated




FIG. G.2. Ignition coil test rig.

with the faulty side. Connect the voltmeter across the (+) terminal of the coil(s) and earth. No reading on the voltmeter in either case indicates that the coil primary winding is faulty and a replacement ignition coil should be fitted.

- (7) With both sets of contacts still open (or insulated from each other) reconnect the ignition coil leads and then connect the voltmeter across both sets of contacts in turn. No reading in either case indicates that there is a faulty cable connection or the internal insulation of one of the condensers (capacitors) has broken down. Renew the condenser and retest.
- (8) If the retest is satisfactory, switch off the ignition switch and remove the insulation piece from both sets of contacts if applicable.

G2. PART C.

Ignition Coils

The ignition coils consist of primary and secondary windings wound concentrically about a laminated soft iron core, the secondary winding being next to the core.

The primary and secondary windings of each coil have 310 turns and 17,000—17,600 turns respectively of enamel-covered wire, the secondary being much finer—also enamel-covered. Each layer is paper insulated from the next on both primary and secondary windings.

To test the ignition coil on the machine first ensure that the low-tension circuit is in order as described in G2, Part A, then disconnect the high-tension leads from the left and right sparking plugs.

Turn the ignition switch to the IGN position and crank the engine until the contacts (those with the black/yellow lead from the ignition coil) for the right cylinder are closed.

Flick the contact breaker lever open a number

of times whilst the high-tension lead from the right ignition coil is held about $\frac{1}{8}$ in. away from the cylinder head. If the ignition coil is in good condition a strong spark should be obtained, if no spark occurs this indicates the ignition coil to be faulty.

Repeat this test for the left high-tension lead and coil by cranking the engine until the contacts with the black/white lead from the left ignition coil are closed.

Before a fault can be attributed to an ignition coil it must be ascertained that the high-tension cables are not cracked or showing signs of deterioration, as this may often be the cause of misfiring etc. It is advisable to remove the ignition coils and test them by the method described below.

Bench Testing Ignition Coil

Connect the ignition coil into the circuit shown in Fig. G.2 and set the adjustable gap to 9 mm. With the contact breaker running at 100 r.p.m., not more than 5% missing should occur at the spark gap over a period of 15 seconds. The primary winding can be checked for short-circuit coils by connecting an ohmmeter across the low-tension terminals. The reading obtained should be within the figures quoted below (at 20°C).

Coil	Primary Resistance	
	Minimum	Maximum
MA12	3.0 ohms	3.4 ohms

G2. PART D.

Contact Breaker

Faults occurring at the contact breaker are in the main due to, incorrect adjustment of the contacts or the efficiency being impaired by




FIG. G.3. Contact breaker and condenser assembly (1966-67).




FIG. G.3A. Contact breaker (1968).

piling, pitting or oxidation of the contacts due to oil etc. Therefore, always ensure that the points are clean and that the gap is adjusted to the correct working clearance as described on page B.28.

To test for a faulty condenser, first turn the ignition switch to IGN position and then take voltage readings across each set of contacts with the contacts open. No reading indicates that the condenser internal insulation has broken down. Should the fault be due to a condenser having a reduction in capacity, indicated by excessive arcing when in use, and overheating of the contact faces, a check should be made by substitution.

On 1968 models the condensers are not fixed on to the contact breaker plate, they are in a self-contained pack situated under the seat above the battery carrier.

Particular attention is called to the periodic lubrication procedure for the contact breaker which is given on pages A.10-11. When lubricating the parts ensure that no oil or grease gets on to the contacts.




FIG. G.3B. Condenser pack (1968).

If it is felt that the contacts require surface grinding then the complete contact breaker unit should be removed as described on page B.28, and the moving contacts disconnected by unscrewing the securing nuts from the condenser terminals. Grinding is best achieved by using a fine carborundum stone or very fine emery cloth, afterwards wiping away any trace of dirt or metal dust with a clean petrol (gasoline) moistened cloth. The contact faces should be slightly domed to ensure point contact. There is no need to remove the pitting from the fixed contact. When refitting the moving contacts do not forget to refit the insulating shields to the condenser terminals and apply a smear of grease to the contact breaker cam and moving contact pivot post. Lubricate the one felt pad.

G2. PART E.

Checking the High-tension Circuit

If ignition failure or misfiring occurs, and the fault is not in the low-tension circuit, then check the ignition coils as described in Part C. If the coils prove satisfactory, ensure that the high-tension cables are not the cause of the fault.

If a good spark is available at the high-tension cable, then the sparking plug suppressor cap or the sparking plug itself may be the cause of the fault. Clean the sparking plug and adjust the electrodes to the required setting as described on pages G.11 and then reset the engine for running performance. If the fault recurs then it is likely the suppressor caps are faulty and these should be renewed.

SPARKING PLUGS

It is recommended that the sparking plugs be inspected, cleaned and tested every 5,000 miles (8,000 km.) and new ones fitted every 10,000 miles (16,000 km.).

To remove the sparking plugs a box spanner—13/16 in. (19.5 mm.) across flats—should be used

Firebird Scrambler only

These models are fitted with standard electrical equipment described on preceding pages, which can be modified to incorporate a capacitor. This enables the engine to be run with or without a battery. Hence for use in competitive events the rider can remove the battery if he so desires.

The system is also suitable for emergency operation in case of battery failure, since engines can be started without the battery and run as normal with full use of the standard lighting, except for parking.

In operation, the energy pulses from the alternator are stored by the capacitor to ensure that sufficient current flows through the ignition coil at the moment the contact points open, thus ensuring an adequate spark.

Running without the Battery

Before running the engine with the battery disconnected, it is essential that the battery negative (—) lead is bound up with insulation tape to prevent short-circuiting by contact with the frame of the machine.

NOTE:—Periodically check that the capacitor is serviceable by disconnecting the battery, when the engine should start and continue to run in the normal manner with full lighting also available.

SPECIAL NOTE:—The capacitor is not supplied as standard equipment, but suitable leads are provided for the addition of the capacitor, if required. Normally, these leads are inoperative and are taped to the main harness.

and if any difficulty is encountered a small amount of penetrating oil should be placed at the base of the sparking plug and time allowed for penetration. When removing the sparking plugs identify each plug with the cylinder from which it was removed so that any faults on examination can be traced back to the cylinder concerned.

Due to certain features of engine design the sparking plugs will probably show slight differing deposits and colouring characteristics.

Next examine the plugs for signs of petrol (gasoline) fouling. This is indicated by a dry, sooty, black deposit which is usually caused by over-rich carburation, although ignition system defects such as a discharged battery, faulty contact breaker, coil or condenser defects, or a broken or worn out cable may be additional causes. For this purpose it is recommended that any adjustments to carburation etc., which may be carried out to gain the required colour characteristics should always be referred to the left cylinder.

Examine both plugs for signs of oil fouling. This will be indicated by a wet, shiny, black deposit on the central insulator. This is caused by excessive oil in the combustion chamber during combustion and indicates that the piston rings or cylinder bores are worn.

To rectify this type of fault the above mentioned items should be checked with special attention given to carburation system. Again, the left plug should be used as the indicator. The right plug will almost always have a darker characteristic.

Overheating of the sparking plug electrodes is indicated by severely eroded electrodes and a white, burned or blistered insulator. This type of fault can be caused by weak carburation or over-advanced ignition timing, although plugs which have been operating whilst not being screwed down sufficiently can be easily become overheated due to heat that is normally dissipated through to the cylinder head not having an adequate conducting path. Overheating is normally symptomised by pre-ignition, short plug life, and "pinking" which can ultimately result in piston crown failure. Unnecessary damage can result from over-tightening the plugs. To achieve a good seal between the plug and cylinder head, screw the plug in by hand on to its gasket, then lightly tighten with a box-spanner.




FIG. G.4. *Sparking plug diagnosis.*

A plug of the correct grade will bear a light flaky deposit on the outer rim and earth electrode, and these and the base of the insulator will be light chocolate brown in colour. A correct choice of plug is marked (A). (B) shows a plug which appears bleached, with a deposit like cigarette ash; this is too "hot-running" for the performance of the engine and a cooler-running type should be substituted.

A plug which has been running too "cold" and has not reached the self-cleaning temperature is shown at (C). This has oil on the base of the insulator and electrodes, and should be replaced by a plug that will burn off deposits and remove the possibility of a short-circuit. The plug marked (D) is heavily sooted, indicating that the mixture has been too rich, and a further carburation check should be made. At illustration (E) is seen a plug which is completely worn out and in need of replacement.

To clean the plugs it is preferable to make use of a properly designed proprietary plug cleaner. The makers instructions for using the cleaner should be followed carefully.

When the plugs have been carefully cleaned, examine the central insulators for cracking and the centre electrode for excessive wear. In such cases the plugs have completed their useful life and new ones should be fitted.

Finally, before refitting the sparking plugs the electrodes should be adjusted to the correct gap setting of .025 in. (.635 mm.). Before refitting sparking plugs the threads should be cleaned by means of a wire brush and a minute amount of graphite grease smeared on to the threads. This will prevent any possibility of thread seizure occurring.

If the ignition timing and carburation settings are correct and the plugs have been correctly fitted, but overheating still occurs then it is possible that carburation is being adversely affected by an air leak between the carburetter, manifold and the cylinder head. This possibility must be checked thoroughly before taking any further action. When it is certain that none of

the above mentioned faults are the cause of overheating then the plug type and grade should be considered.

Normally the type of plugs quoted in General Data are satisfactory for general use of the machine, but in special isolated cases, conditions may demand a plug of a different heat range. Advice is readily available to solve these problems from the plug manufacturer who should be consulted.

NOTE:—If the machine is of the type fitted with an air filter or cleaner and this has been removed it will affect the carburation of the machine.

CHARGING SYSTEM

Description

On 1966 and later models, all of which have a 12 volt electrical system and Zener Diode charge control, the alternator leads are connected differently. The alternator gives "maximum" output with the lighting switch in all switch positions, the coils being permanently connected across the rectifier. Excessive charge is absorbed by the Zener Diode which is connected in parallel with the battery.

To locate a fault in the charging circuit, first check the charging rate as described in Part A. Proceed then to test the alternator as described in Part B. If the alternator is satisfactory, the fault must lie in the charging circuit, hence the rectifier must be checked as given in Part C, and then the wiring and connections as shown in Part D.

G4. PART A.

Checking the D.C. Input to Battery

For this test the battery must be in good condition and a good state of charge, therefore, before conducting the test, ensure that the battery is up

to the required standard, or alternatively fit a good replacement battery.

Disconnect the Zener Diode (when fitted).

Connect a D.C. ammeter (0—15 amp.) in series between the battery main lead (brown/blue) and battery negative terminal and then start the engine and run it at approximately 3,000 r.p.m. (equivalent to 45 m.p.h. in top gear).

NOTE:—Ensure that the ammeter is well insulated from the surrounding earth points otherwise a short-circuit may occur.

Operate the lighting switch and observe the ammeter readings, for each position of the switch. The observed figures should not be less than those tabulated in Fig. G.16 for the particular model. If the readings are equal to or higher than those given, then the alternator and charging circuit are satisfactory. If the readings are lower than those quoted, then the alternator must be tested as described in Part B below.

G4. PART B.

Checking the Alternator A.C. Output

Disconnect the three alternator output cables underneath the engine (two cables in the case of RM21 alternator) and run the engine at 3,000 r.p.m. (equivalent to 45 m.p.h. in top gear).

Connect an A.C. voltmeter (0—15 volts) with 1 ohm load resistor in parallel with the alternator leads as shown in the table, Fig. G.16 and observe the voltmeter readings. A suitable 1 ohm load resistor can be made from a piece of nichrome wire as shown in Section G4, Part E, page G.15.

From the results obtained, the following deductions can be made:—

- (1) If the readings are all equal to or higher than those quoted for the particular model then the alternator is satisfactory.
- (2) A low reading on any group of coils (in the case of model RM19 alternator) indicates that some turns of the coils are short-circuited.
- (3) A low reading in the case of model RM21 alternator and for all parts of the test (model RM19) indicates that the rotor has become partially demagnetised. Check that this has not been caused by a faulty rectifier, and only then fit a new rotor.
- (4) In the case of model RM19 alternator a zero reading for any group of coils indicates that a coil has become disconnected, is open circuit, or is earthed. In the case of model RM21 alternator the internal cable connections are open-circuit or shorted.
- (5) A reading obtained between any one lead and earth indicates that coil windings or connections have become earthed.

If any of the above mentioned faults occur, always check the stator leads for possible chain

damage before contemplating renewing the stator.

It is not a practical or economic proposition to attempt to repair a faulty stator winding of the encapsulated type.

It is also beyond the scope of this manual to give instructions for the repair of faulty stator windings of the type which are not encapsulated. However, the windings specification is given in the table, Fig. G.16 for those obliged to attempt repair work.

G4. PART C.

Rectifier Maintenance and Testing

The rectifier is a silicon semi-conductor device which allows current to flow in one direction only. It is connected to provide full wave rectification of alternator output current.

The rectifier requires no maintenance beyond checking that the connections are clean and tight. The nuts clamping the rectifier plates together must not under any circumstances be slackened. A separate nut is used to secure the rectifier to the motor-cycle and it is important to check periodically that the rectifier is firmly attached to its mounting bracket.




FIG. G.5. Refitting the rectifier.

When tightening the rectifier securing nut, hold the spanner as shown in Fig. G.5, for if the plates are twisted, the internal connections will be broken. Note that the circles marked on the fixing bolt and nut indicate that the thread form is $\frac{1}{4}$ in. U.N.F.

Testing the Rectifier

To test the rectifier, first disconnect the brown/white lead(s) from the rectifier centre terminal and insulate the end of the lead(s) to prevent any possibility of a short-circuit occurring, and then connect a D.C. voltmeter (with 1 ohm load resistor in parallel) between the rectifier centre terminal and earth.

Disconnect the alternator green/black lead and reconnect to rectifier green/black terminal by means of a jumper lead.

NOTE:—Voltmeter positive terminal to frame earth (ground) and negative terminal to centre terminal on rectifier.

Ensure that all the temporary connections are well insulated to prevent a short-circuit occurring then turn the ignition switch to IGN position and start the engine.

With the engine running at approximately 3,000 r.p.m. (approximately 45 m.p.h. in top gear) observe the voltmeter readings. The reading obtained should be at least 7.5 volt minimum.

- (1) If the reading is equal to or slightly greater than that quoted, then the rectifier elements in the forward direction are satisfactory.
- (2) If the reading is excessively higher than the figures given, then check the rectifier earthing bolt connection. If the connection is good then a replacement rectifier should be fitted.
- (3) If the reading is lower than the figures quoted or zero readings are obtained, then the rectifier or the charging circuit wiring is faulty and the rectifier should be disconnected and bench tested so that the

fault can be located.

Note that all of the above conclusions assume that alternator A.C. output figures were satisfactory. Any fault at the alternator will, of course, reflect on the rectifier test results. Similarly any fault in the charging circuit wiring may indicate that the rectifier is faulty. The best method of locating a fault is to disconnect the rectifier and bench test it as shown below.

Bench Testing the Rectifier

For this test the rectifier should be disconnected and removed. Before removing the rectifier, disconnect the leads from the battery terminals to avoid the possibility of a short-circuit occurring.

Connect the rectifier to a fully charged 12 volt battery of approximately 50 ampere/hours capacity at the 10 hour rate, and 1 ohm load resistor, and then connect the D.C. voltmeter in the V2 position, as shown in Fig. G.7.

Note the battery voltage (should be 12 volt) and then connect the voltmeter in V1 position whilst the following tests are conducted.

A voltmeter in position V1 will measure the volt drop across the rectifier plate. In position V2 it will measure the supply voltage to check that it is the recommended 12 volts on load.

In Fig. G.8, the rectifier terminal markings (1), (2) and (3) are as shown physically in Figs. G.6 and G.7, while terminal (4) represents the rectifier centre bolt. (1) and (3) are the A.C. input




FIG. G.6. Rectifier (showing terminal connections for bench tests 1 and 2).




FIG. G.7. Bench testing the rectifier.

terminals while (2) and (4) are the D.C. output terminals (—ve and +ve respectively).

TEST 1

With the test leads, make the following connections but keep the testing time as short as possible to avoid overheating the rectifier cell: (a) 1 and 2; (b) 1 and 4; (c) 3 and 4; (d) 3 and 2. Each reading should not be greater than 2.5 volts with the battery polarity as shown.

TEST 2

Reverse the leads or battery polarity and repeat test 1. The reading obtained should not be more than 1.5 volts below battery voltage (V_2), i.e., 10.5 volts minimum.

If the readings obtained are not within the figures given, then the rectifier internal connections are shorting or aged and the rectifier should be renewed.




FIG. G.8. Rectifier test sequence for checking forward resistance and back leakage.

G4. PART D.**Checking the Charging Circuit for Continuity**

These three tests utilise the machines own battery to test for continuity or breakdown in the A.C. section of the charging system.

For this series of tests, the battery must be in a good state of charge and the **alternator leads must be disconnected** at the snap-connectors underneath the engine, so that there is no possibility of demagnetising the rotor.

- (1) First, check that there is voltage at the rectifier centre terminal by connecting a D.C. voltmeter, with 1 ohm load resistor in parallel, between the rectifier centre terminal and earth, remember (+ve) positive earth (ground). The voltmeter should read battery volts. If it does not, there is a faulty connection in the wiring and test (1), (3) and (4) in G2, Part B, should be carried out to locate the fault.
- (2) Connect the green/black lead from the wiring harness (underneath the engine) to the rectifier centre terminal, by means of a jumper lead. Turn the ignition switch to IGN position and the lighting switch to HEAD position, and connect a D.C. voltmeter (with 1 ohm resistor in parallel) between green/yellow lead at rectifier from harness and earth. The voltmeter should read battery voltage. If it does not, the leads to ignition switch terminals 17 and 18 should be checked and the leads to the lighting switch terminals 5 and 7 should also be checked. With the lighting switch in PILOT position no reading should be

obtained between green/yellow and earth or green/white and earth at the rectifier. This last test only applies to the earlier switched alternator circuits.

G4. PART E.**Constructing a 1 ohm Load Resistor**

The resistor used in the following tests must be accurate and constructed so that it will not over-heat otherwise the correct values of current or voltage will not be obtained.

A suitable resistor can be made from 4 yards (3½ metres) of 18 s.w.g. (.048 in., i.e. 1.2 mm. diameter) nichrome wire by bending it into two equal parts and calibrating it as follows:—

- (1) Fix a heavy gauge flexible lead to the folded end of the wire and connect this lead to the positive terminal of a 6 volt battery.
- (2) Connect a D.C. voltmeter (0--10 volts) across the battery terminals and an ammeter (0—10 amp.) between the battery negative terminal and the free ends of the wire resistance, using a crocodile clip to make the connection.
- (3) Move the clip along the wires, making contact with both wires until the ammeter reading is numerically equal to the number of volts shown in the voltmeter. The resistance is then 1 ohm. Cut the wire at this point, twist the two ends together and wind the wire on an asbestos former approximately 2 in. (5 cm.) diameter so that each turn does not contact the one next to it.

ZENER DIODE CHARGE CONTROL

(12 volt machines only)

Description —

The Zener Diode alternator output regulating system provides automatic control of the charging current. It will only operate successfully on

a 12 volt system where it is connected in parallel with the battery as shown in the wiring diagram, pages G.26-28.




FIG. G.9. Zener Diode.

Assuming the battery is in a low state of charge its terminal voltage (the same voltage is across the Diode) will also be low, therefore the maximum charging current will flow into the battery from the alternator. At first none of the current is by-passed by the diode because of it being non-conducting due to the low battery

terminal volts. However, as the battery is quickly restored to a full state of charge, the system voltage rises until at 14 volts the Zener Diode becomes partially conducting, thereby providing an alternative path for a small part of the charging current. Small increases in battery voltage result in large increases in Zener conductivity until, at approximately 15 volts the bulk (about 5 amperes) of the alternator output is by-passing the battery. The battery will continue to receive only a portion of the alternator output as long as the system voltage is relatively high.

Depression of the system voltage, due to the use of headlamp or other lighting equipment, causes the Zener Diode current to decrease and the balance to be diverted and consumed by the component in use.

If the electrical loading is sufficient to cause the system voltage to fall below 14 volts, the Zener Diode will revert to a high resistance state of non-conductivity and the full generated output will go to meet the demands of the battery.

ZENER DIODE CONVERSION KIT

Description

1966 A65 12 volt models with the Zener Diode mounted under the twin seat can now be converted to the latest type where the improved heat sink is mounted underneath the steering head.

A conversion kit 00-5168 consisting of the parts listed below is available on demand:—

Conversion Kit Parts

68-9428	Heat sink	1 off
68-9429	Diode retaining clip	1 off
2-923	Plain washer	2 off
42-4476	Self-locking nut	1 off
68-5187	Bolt	1 off
54942747	Lucar connection	1 off
54190119	Lucar cover	1 off

Fitting Instructions

- (1) Remove the steering damper anchor plate and drill $\frac{7}{16}$ in. diameter hole in line with existing holes at 2 in. centres from the large holes.
- (2) Disconnect and cut off the white Diode lead at harness junction and retain for future use (approximately 5 in.). Insulate the stub at harness junction.
- (3) Remove the red Diode to rectifier lead and retain, then remove the red battery earth lead from the Diode and reconnect to rectifier centre fixing stud.
- (4) Remove the Diode and old heat sink, discard the heat sink and bolt, refit the Diode under the steering head as follows.

- (5) Pass the new bolt No. 68-5187 with washer 2-923 under the head downwards through the frame lug (it may be necessary to open up the hole slightly), damper anchor plate, and front end of engine steady stay and secure with lockwasher 36-382 and nut 2-49. Paint must be removed locally between clamped faces to ensure a good electrical contact.




FIG. 10. Zener Diode conversion kit.

- (6) Assemble Diode and retaining clip to the new heat sink on the same side as the stop peg, with the $\frac{5}{16}$ in. diameter hole in line with the long bolt hole. The Lucar connector must be on the right-hand side viewed from the saddle.
- (7) Fit the heat sink assembly with the leg in the $\frac{7}{16}$ in. diameter hole in the anchor plate and one end of the earth lead (from 3) between the Diode clip and the heat sink. Secure with washer 2-923 and nut 42-4476. Connect the loose end of red earth lead under Diode clamping nut.
- (8) Remove brown/white lead with white band from ignition switch and cut off Lucar connector close to connector.
- (9) Take the 5 in. length of white lead already removed and the brown/white band lead and fit and solder both wires into a double Lucar connector No. 54942747 with cover No. 54190119. Reconnect to the ignition switch. The other end of the white lead connect to the Diode. Take care to avoid bare connection with adjacent earthed items.

Maintenance

The Zener Diode is mounted on an aluminium heat sink with an area of 25 sq. in. except in cases when a model 2MC emergency start capacitor is fitted, when the minimum heat sink size is $6 \times 6 \times \frac{1}{8}$ thick aluminium or copper plate (an alternative shape having a total surface area of 72 sq. in. Providing the Diode and the heat sink are kept clean and provided with an adequate air flow, to ensure maximum efficiency, no maintenance will be necessary.

The earthing stud, which secures the Diode to the heat sink plate, must not be subjected to a tightening torque greater than the figures quoted on page GD.31. The earth wire must be fitted under the fixing nut, not between the Diode and heat sink.




FIG. G.11. Zener Diode heat sink.

Checking Performance of Zener Diode

The following procedure enables the Zener Diode to be tested on the machine. Only suitably calibrated first-grade moving coil instruments should be used.

NOTE:—It is essential that the batteries are in good condition and in reasonably good state of charge. If the battery condition is uncertain, it should be temporarily replaced by a good battery for this test.

- (1) Withdraw the white (or brown/white) cable from the Zener Diode terminal blade.

- (2) Connect a suitable ammeter between the end of the cable removed and the Zener Diode terminal blade, using a suitable jumper lead. *N.B.*—The ammeter red or positive lead must be connected to the Zener Diode.
- (3) Connect a suitable voltmeter between the Zener Diode terminal blade and the heat sink. *N.B.*—The voltmeter red or positive lead must be connected to the heat sink.
- (4) Check that all lights are switched off.
- (5) Start the engine and gradually increase the speed while observing both meters:
 - (a) When the voltage across the Zener Diode reaches 12.75 volts, the Zener current ammeter must indicate zero.
 - (b) Increase engine speed until a Zener current of 2 amperes is indicated on the ammeter. At this value, a satisfactory Zener Diode should cause a reading on the voltmeter of between 14.4 and 16.4 volts.
- (6) If the Zener current ammeter in test (a) registers any current at all before the Zener voltmeter indicates a voltage of 12.75 volts across the Zener, then a replacement Zener Diode must be fitted. If test (a) proves satisfactory but in test (b) a higher voltage than that stated is registered on the voltmeter, before the Zener current ammeter registers 2 amperes, then a replacement Zener Diode must be fitted.

A.C. IGNITION (E.T.) AND LIGHTING SYSTEMS

Description

The A.C. magneto (energy transfer) system consists of two 3E.T. ignition coils, a contact breaker and an alternator specially wound for A.C. ignition and lighting. There are five leads from the alternator, two for ignition purposes and three for direct lighting purposes. The circuit diagram, on page G.25 illustrates the stator coil connections.

The main features of the A.C. ignition system for twin cylinder machines is that the ignition coil and contact breaker points are connected in parallel. In practice this means that when the contacts are closed the generated current flows from the alternator through the first set of contacts and then via earth through the second set, and so back to the alternator. When one set of contacts opens the current has to pass

through an ignition coil primary winding and via earth through the second set of contacts which are arranged to be closed at the same instant. From this it can be seen that the availability of a spark at either cylinder is dependent upon both contacts being clean and adjusted correctly (see Fig. G.12).

Another feature is that the energy transfer system operates on a rising current in the ignition coil primary winding and not falling primary current as in the conventional coil ignition system.

G6. PART A.

A.C. Ignition

The accurate and efficient working of the A.C. ignition system is dependent not only upon the piston/spark relationship that is involved but also the rotor/stator relationship at the instant of ignition. The stator is fixed to the left crank-case and requires no maintenance other than to check that the leads are not rubbing on either of the chains.

The rotor is located on the crankshaft by means of a dowel fitted to the timing disc. When the rotor is removed care should be taken to refit it in the appropriate position with the rotor hole located as shown in the table below, in accordance with ignition timing requirements.

Dowel Location	Ignition Timing Full Advanced	Dowel Remarks
S	34° B.T.C.	500 c.c. 650 c.c.

N.B.—Never try to improve the ignition timing of an A.C. ignition machine. Settings are critical and optimum performances are determined by the engine and ignition system designers at the development stage.




FIG. G.12.

The 3E.T. coil, condensers (capacitors), and high-tension leads must be kept clean and free from dirt or water. Also it is important that the sparking plug is maintained at the correct gap setting and that the centre electrode is kept clean.




FIG. G.13.

Both sets of contact breaker contacts must be kept clean and adjusted correctly to the gap setting given in General Data. A fault at either set of contacts will adversely affect the ignition spark at both cylinders.

G6. PART B.

Testing the A.C. Ignition System

First, ensure that the timing, contact breaker and plug gaps are satisfactory, and then disconnect both high-tension leads and check that a spark is available by holding each of the cables about $\frac{3}{16}$ in. (4 mm.) from the cylinder head in turn and operate the kickstarter. A good spark should be produced. If it is not, then the 3E.T. coil and alternator ignition supply are suspect.

As it is not possible to test the 3E.T. coils accurately on the machine, the following test procedure should be adopted.

Two 6 volt external batteries are used for the next two tests, in conjunction with the A.C. ignition coils on the machine.

To prevent overheating occurring in the primary windings, each test should be undertaken in as short a time as possible, and the batteries connected in circuit only when actually necessary to run the test.

- (1) Disconnect the five alternator leads under the engine.
- (2) Unplug the black/yellow lead from the condenser at the right-hand side coil (under the petrol/gasoline tank).
- (3) Connect the black/yellow lead to the positive (+ve) terminal of a 6 volt test battery.
- (4) Connect the negative (—ve) battery lead to the condenser terminal.
- (5) Unplug the black/white lead from the condenser at the left-hand side coil (under the

petrol/gasoline tank).

- (6) Connect the black/white lead to the positive (+ve) terminal of a second 6 volt test battery.
- (7) Connect the negative (—ve) terminal of the second test battery to the left-hand condenser terminal.
- (8) Remove the sparking plug wire from each plug in turn and with battery wires connected, open and close the contact breaker points. If the coils and condensers are satisfactory, a good spark will jump from the plug lead to earth (ground).
- (9) If a poor spark (or no spark) is noted, check all wiring connections, and repeat (8) above. If the system still does not spark, instal new condensers and repeat (8). If still there is no spark, check the ignition coils by substitution.

G6. PART C.

Checking the Alternator Output (A.C. ignition models)

To facilitate a check to be made on the alternator output, a separate ignition circuit must be used as given in Section G6, Part B above, so that the engine can be run at 3,000 r.p.m. (approximately 45 m.p.h. in top gear).

Pay careful regard to the warning given in the previous Section G6, Part B, concerning the possible overheating of the A.C. ignition coil primary windings.

The preferred alternative method is to use two MA6 ignition coils, bolted together, with the machines contact breaker leads, black/white, black/yellow connected to the (+ve) terminals on the test ignition coils. The test coil (—ve) terminals are linked together and fed to a test battery (—ve) negative terminal and the battery (+ve) positive connected to the ignition coils

cases. A jumper lead is also required between battery (+ve) positive, and motor-cycle frame earth (ground). The high-tension leads are connected to the appropriate sparking plugs.

With all five alternator leads disconnected under the engine, start up the engine and run at 3,000 r.p.m. (equivalent to approximately 45 m.p.h. in top gear). Connect an A.C. voltmeter (0–10 volts) with a 1 ohm resistor in parallel between the pairs of alternator leads given in table, Fig. G.16, page G.24.

- (1) If the readings are equal to or higher than the figures quoted for the particular model, then the alternator is satisfactory.
- (2) A low reading on any group of coils indicates either that the leads concerned are chafed through or damaged due to rubbing on the chains or that some of the coil turns are short-circuited.
- (3) Low readings from all parts of the test indicates a partially demagnetised rotor. In this case the rotor must be renewed.
- (4) A zero reading for any group of coils indicates that a coil has become disconnected and is open-circuit, in which case the stator should be replaced.
- (5) A reading obtained between any one stator lead and earth (ground) indicates that some coil turns have become earthed (grounded) to the engine.

In this case, brush the stator with paraffin (kerosene) or petrol (gasoline). **Do not leave to soak.** Re-test on the machine. If still faulty, replace the stator.

If any fault does occur always check the stator leads for possible chain damage before attempting repair or renewing the stator. It is beyond the scope of this manual to give instruction for repair of faulty stator windings. However the winding specification is given in table, Fig. G.16 to provide the required information for local repair work, should a correct replacement stator not be immediately available.

G6. PART D.

Direct Lighting System

The electrical power for the direct lighting system is supplied by three of the five alternator leads, namely the red, brown and brown/blue.

The leads are connected as shown in the wiring diagram (page G.25). In order that no one pair of coils is overloaded, the electrical loads are connected as shown and no deviation from the standard arrangement shown should be made.

An apparent loss or reduction of power at any of the lights may well be due to a high resistance caused by a loose or faulty connection. In the event of a fault occurring, always check the wiring connections, giving particular attention to the red earth (ground) lead from the alternator and headlamp. Note that a short-circuit in the brown stop lamp lead will result in the ignition system failing, hence the stop lamp switch connections should be always kept clean and dry.

In the event of a fault occurring which cannot be traced to the circuit connections the alternator should be checked as described in Section G6, Part C, page G.20.

ELECTRIC HORN (Models 6H and 8H)

Description

The horn is of a high frequency single-note type and is operated by direct current from the battery. (On A.C. models a similar horn specifically designed for A.C. current is fitted.) The method of operation is that of a magnetically operated armature, which impacts on the cone face, and causes the tone disc of the horn to vibrate. The magnetic circuit is made self-interrupting by contacts which can be adjusted externally.


If the horn fails to work, check the mounting bolts etc., and horn connection wiring. Check the battery for state of charge. A low supply voltage at the horn will adversely effect horn performance. If the above checks are made and the fault is not remedied, then adjust the horn as follows.

Horn Adjustment

When adjusting and testing the horn, do not depress the horn push for more than a fraction of a second or the circuit wiring may be overloaded.

A small serrated adjustment screw situated near the terminals (see Fig. G.14) is provided to take up wear in the internal moving parts of the horn. To adjust, turn this screw anti-clockwise until the horn just fails to sound, and then turn it back (clockwise) about one-quarter to half a turn.

ADJUSTMENT SCREW

FIG. G.14. *Horn adjustment screw.***HEADLAMP****Description**

The headlamp is of the pre-focus bulb light unit type and access is gained to the bulb and bulb holder by withdrawing the rim and light unit assembly. To do this slacken the screw at the top of the headlamp shell just behind and adjacent to the rim and prise off the rim and light unit assembly.

The bulb can be removed by first pressing the cylindrical cap inwards and turning it anti-

clockwise. The cap can then be withdrawn and the bulb is free to be removed.

When fitting a new bulb, note that it locates by means of a cut-away and projection arrangement. Also note that the cap can only be replaced one way, the tabs being staggered to prevent incorrect reassembly. Check the replacement bulb voltage and wattage specification and type before fitting.

Focusing with this type of unit is unnecessary and there is no provision for such.

Beam Adjustments

The beam must in all cases be adjusted as specified by local lighting regulations. In the United Kingdom the Transport Lighting Regulations reads as follows:—

A lighting system must be arranged so that it can give a light which is incapable of dazzling any person standing on the same horizontal plane as the vehicle at a greater distance than twenty-five feet from the lamp, whose eye level is not less than three feet—six inches above that plane.

The headlamp must therefore be set so that the main beam is directed straight ahead and parallel with the road when the motor-cycle is fully loaded. To achieve this, place the machine on a level road pointing towards a wall at a distance of 25 feet away, with a rider and passenger, on the machine, slacken the two small screws on the adaptor rim at either side and tilt the beam unit until the beam is focused at approximately two feet, six inches from the base of the wall. Do not forget that the headlamp should be on "full beam" lighting during this operation.

TAIL AND STOP LAMP UNIT

Access to the bulbs in the tail and stop lamp unit is achieved by unscrewing the two slotted screws which secure the lens. The bulb is of the double filament offset pin type and when a replacement is carried out, ensure that the bulb is fitted correctly. Check that the two supply leads are connected correctly and check the

earth (ground) lead to the bulb holder is in satisfactory condition.

When refitting the lens, do not overtighten the fixing screws or the lens may fracture as a result.

ADDITIONAL INFORMATION

Alternator model RM19 having Stator Part No. 47162 (B.S.A. Nos. 19-8018 and 19-8019).

Fitted to A65 Lightning, Thunderbolt, Spitfire Mk. II Special and A50 Royal Star models.

Number of coils ... 6
Winding per coil ... 140 turns of 22 s.w.g.

Energy Transfer Ignition Coil model 3E.T., Part Nos. 45149 and 45150 (B.S.A. Nos. 19-1711 and 19-1746).

Fitted to A65 Hornet and A50 Wasp models.

Encapsulated alternators cannot be rewound.

Resistance of
primary winding ... 0.45—0.55 ohm

Contact Breaker Unit model 4CA Part Nos. 47583 and 47612.

Part number 47583 is fitted to coil ignition machines and 47612 to energy transfer ignition machines. Both carry centrifugally operated timing advance mechanisms, the tests for which are as follows:—

47583 (B.S.A. Nos. 19-8113 and 19-8112)

- (1) Set rotary spark gap to spark at zero degrees at less than 100 rev./min.
- (2) Run contact breaker unit at 1,800 rev./min. Advance to be between $10\frac{1}{2}^{\circ}$ — $12\frac{1}{2}^{\circ}$.
- (3) Decelerate and check at the following speeds.

Rev./min.	Degrees
1,700	10— $12\frac{1}{2}$
1,300	8— $10\frac{1}{2}$
800	$1\frac{1}{2}$ — $4\frac{1}{2}$

No advance to occur below 450 rev./min.

Lucas part number of control springs—
54413020.

47612 (B.S.A. Nos. 19-8113 and 19-8111)

(1) Set rotary spark gap to spark at zero degrees
at less than 100 rev./min.

(2) Run contact breaker unit at 1,750 rev./min.
Advance to be between 4°—6°.

(3) Decelerate and check at the following speeds.

Rev./min.	Degrees
1,200	6 (max.)
850	4—6
600	0—3
500	0—1½

No advance to occur below 375 rev./min.

Lucas part number of control springs—
54415641.

ALTERNATOR AND STATOR DETAILS

Specifications and Output Figures

MODELS	SYSTEM VOLTAGE	IGNITION TYPE	ALTERNATOR MODEL	STATOR NUMBER
A50 and A65 (various)	12-volt	Coil	RM.19	47162
A50 Wasp. A65 Hornet	6-volt	A.C. IGN	RM.19	47197
All 1968 models	12-volt	Coil	RM.21	47205

FIG. G.15. Electrical system details.

STATOR NO.	SYSTEM VOLTAGE	Approximate D.C. input to battery amp. at 3,000 rpm with Zener Diode disconnected			Alternator output minimum A.C. volts across 1 ohm resistance at 3,000 rpm			STATOR COIL DETAILS		
		OFF	PILOT	HEAD Mainbeam	A	B	C	NO. OF COILS	TURNS PER COIL	S.W.G.
47162 47197	12-volt	4.8	3.8	0.8	4.0	6.5	8.5	6	140	22
47197	6-volt	Not applicable			5.0	2.0	5.0	Not applicable, encapsulated alternators cannot be rewound		
47205	12-volt	5.0	4.0	1.0	—	9.0	—	Not applicable, encapsulated alternators cannot be rewound		

Coil Ignition Machines

A — White/green and green/black.
B — White/green and green/yellow.
C — White/green and green/black—green/yellow connected.

A.C. Ignition Machines

A — Red and brown/blue.
B — Black/yellow and black/white.
C — Black/yellow and brown.

FIG. G.16. Alternator (minimum output and stator details).

A5065

ELECTRICAL SYSTEM

G25





FIG. G.17. Wiring diagram for "energy transfer" ignition system.



A5065

ELECTRICAL SYSTEM

G27




FIG. G.19. Wiring diagram for 1968 models except Firebird Scrambler.




FIG. G.20. Wiring diagram 12-volt.

NOTE—IGNITION SWITCH—On machines for U.S.A. the single Lucar blade behind the switch accepts the feed cable only (coloured brown with identification tag). On all other machines the single Lucar blade accepts the ignition cable only.

A5065

SERVICE TOOLS

HI

INDEX

ENGINE	<i>Page</i> H.2-5
TRANSMISSION	H.6
FRONT FORKS	H.7-8

ENGINE





FIG. H.1.
*Valve seat cutter pilot No. 61-3293,
cutter No. 61-3301 and
holder No. 61-3290.*

FIG. H.2.
Valve grinding tool No. 61-5035.



ENGINE




FIG. H.3.
*Gudgeon pin bush extractor
and fitting tool
No. 61-3652.*




FIG. H.4.
*Piston ring slippers,
model A50 No. 61-3682,
model A65 No. 61-3707.
(2 per set required).*

ENGINE

FIG. H.5.
*Contact breaker cam
extractor No. 61-5005.*




FIG. H.6.
*Valve guide fitting and
extracting punch
No. 61-3382.*






FIG. H.7.
*Valve spring compressor
No. 61-3341.*

FIG. H.8.
*Tappet circlip fitting
tool No. 61-3702.*



ENGINE




FIG. H.9.
*Crankshaft balance
weights (2 per set),
No. 61-3710 (650 c.c. models),
No. 61-3711 (500 c.c. models).*




FIG. H.10.
*Universal pinion
extractor No. 61-3676.*

TRANSMISSION

FIG. H.11.
Clutch sleeve extractor
No. 61-3766.




FIG. H.12.
Camshaft bush extractor
No. 61-3776.




FIG. H.13.
Clutch nut screwdriver
No. 61-3700.





FIG. H.14.
Clutch locking tool
No. 61-3768.



FRONT FORKS




FIG. H.15.
*Steering head adjuster
tool No. 61-3008.*

FIG. H.17.
*Damper dismantling and
assembly tool No. 61-3503.*





FIG. H.16.
*Fork leg fitting and
removal tool No. 61-3350.*



FRONT FORKS




FIG. H.18.
*Oil seal holder fitting and
removal tool No. 61-3005.*




FIG. H.19.
*Oil seal extractor
punch No. 61-3006.*




FIG. H.20.
*Oil seal assembly
tool No. 61-3007.*




FIG. H.21.
*Fork damper rod recovery
tool
No. 61-3765.*